

ISO 2648:2020-01 (E)

Wool - Determination of fibre length distribution parameters - Capacitance method

Contents	Page
Foreword	iv
1 Scope	1
2 Normative references	1
3 Terms and definitions	1
4 Principle	2
5 Apparatus	2
6 Conditioning and testing atmosphere	3
6.1 Conditioning atmosphere	3
6.2 Testing atmosphere	4
7 Sampling and preparation of laboratory sample	4
7.1 Sampling	4
7.2 Preparation of laboratory sample	4
7.2.1 General	4
7.2.2 Slivers of combed wool weighing between 15 g/m and 30 g/m	4
7.2.3 Rovings or slivers weighing less than 15 g/m	4
7.2.4 Rovings or slivers weighing more than 30 g/m	5
8 Procedure	5
8.1 Preparation of test specimen	5
8.2 Measurement	5
9 Calculation and expression of results	6
9.1 Analogue system	6
9.1.1 Calculation of Hauteur (H) and Barbe (B)	6
9.1.2 Calculation of coefficient of variation of Hauteur CV_H	6
9.1.3 Percentage of short fibres	7
9.1.4 Use of the nomograms	7
9.2 Digital system	7
9.2.1 General	7
9.2.2 Calculation of Hauteur (H)	7
9.2.3 Calculation of the coefficient of variation of Hauteur, CV_H	7
9.2.4 Calculation of Barbe (B)	8
9.2.5 Calculation of the coefficient of variation of Barbe, CV_B	8
9.2.6 Tuft diagram	8
9.2.7 Fibre length attributes (L values and K values)	8
10 Test report	9
11 Precision	9
11.1 Precision of the method	9
11.2 Within and between laboratory variation for Hauteur and Barbe	9
11.3 95 % confidence intervals for Hauteur and Barbe	10
11.4 MPD% values for Hauteur and Barbe based on k measurements	10
Annex A (normative) Preparation of top and sliver	12
Annex B (normative) Test specimen preparation	15
Annex C (informative) Precision of the method	17
Bibliography	21