ISO 2648:2020-01 (E)

Wool - Determination of fibre length distribution parameters - Capacitance method

Contents

Page

Foreword ... iv

1 Scope ... 1

2 Normative references ... 1

3 Terms and definitions ... 1

4 Principle ... 2

5 Apparatus ... 2

6 Conditioning and testing atmosphere ... 3
6.1 Conditioning atmosphere ... 3
6.2 Testing atmosphere ... 4

7 Sampling and preparation of laboratory sample ... 4
7.1 Sampling ... 4
7.2 Preparation of laboratory sample ... 4
7.2.1 General ... 4
7.2.2 Slivers of combed wool weighing between 15 g/m and 30 g/m ... 4
7.2.3 Rovings or slivers weighing less than 15 g/m ... 4
7.2.4 Rovings or slivers weighing more than 30 g/m ... 5

8 Procedure ... 5
8.1 Preparation of test specimen ... 5
8.2 Measurement ... 5

9 Calculation and expression of results ... 6
9.1 Analogue system ... 6
9.1.1 Calculation of Hauteur (***H***) and Barbe (***B***) ... 6
9.1.2 Calculation of coefficient of variation of Hauteur CV_H ... 6
9.1.3 Percentage of short fibres ... 7
9.1.4 Use of the nomograms ... 7
9.2 Digital system ... 7
9.2.1 General ... 7
9.2.2 Calculation of Hauteur (***H***) ... 7
9.2.3 Calculation of the coefficient of variation of Hauteur, CV_H ... 7
9.2.4 Calculation of Barbe (***B***) ... 8
9.2.5 Calculation of the coefficient of variation of Barbe, CV_B ... 8
9.2.6 Tuft diagram ... 8
9.2.7 Fibre length attributes (L values and K values) ... 8

10 Test report ... 9

11 Precision ... 9
11.1 Precision of the method ... 9
11.2 Within and between laboratory variation for Hauteur and Barbe ... 9
11.3 95 % confidence intervals for Hauteur and Barbe ... 10
11.4 MPD% values for Hauteur and Barbe based on k measurements ... 10

Annex A (normative) **Preparation of top and sliver** ... 12

Annex B (normative) **Test specimen preparation** ... 15

Annex C (informative) **Precision of the method** ... 17

Bibliography ... 21