

# DIN EN 18071:2026-04 (E)

## Inland navigation vessels - Methanol bunkering

---

<b>Contents</b>		<b>Page</b>
European foreword .....		3
Introduction .....		4
<b>1</b>	<b>Scope .....</b>	<b>5</b>
<b>2</b>	<b>Normative references .....</b>	<b>5</b>
<b>3</b>	<b>Terms and definitions .....</b>	<b>5</b>
<b>4</b>	<b>Abbreviated terms .....</b>	<b>8</b>
<b>5</b>	<b>Transfer systems design requirements .....</b>	<b>9</b>
5.1	Vessel requirements .....	9
5.2	Bunkering facility requirements .....	9
5.3	Transfer equipment requirements .....	9
5.4	Emergency shutdown system .....	10
5.5	Identification of transfer equipment .....	10
5.6	Transfer system design analysis .....	10
5.7	Maintenance .....	11
5.8	Maintenance manual .....	11
<b>6</b>	<b>Methanol bunkering processes and procedures .....</b>	<b>11</b>
6.1	Risk assessment .....	11
6.1.1	General .....	11
6.1.2	Conditions .....	12
6.1.3	Methodology .....	12
6.1.4	Acceptable bunkering operations parameters .....	12
6.2	Vessel safety assessments .....	13
6.3	Mooring .....	13
6.4	Transfer procedures .....	13
<b>7</b>	<b>Management systems .....</b>	<b>16</b>
<b>8</b>	<b>Personnel training .....</b>	<b>16</b>
8.1	Vessel personnel training requirements .....	16
8.2	Additional training requirements for personnel involved in bunkering operations .....	16
8.3	Port terminal or Mobile facility personnel .....	17
8.4	Training records .....	17
<b>9</b>	<b>Documentation .....</b>	<b>17</b>
9.1	General .....	17
9.2	Procedures manuals .....	17
<b>Annex A (normative) Methanol bunker checklists .....</b>		<b>18</b>
<b>Annex B (informative) Methanol bunker delivery note .....</b>		<b>25</b>
<b>Bibliography .....</b>		<b>26</b>