

ISO 18962:2026-01 (E)

Ships and marine technology - Installation and operational requirements for swappable batteries on ships

Contents		Page
Foreword		iv
1	Scope	1
2	Normative references	1
3	Terms and definitions	1
4	Requirements	2
4.1	General requirements	2
4.2	Installation	2
4.3	Operation	2
4.3.1	Vibration and mechanical shock	2
4.3.2	Immersion into water	2
4.3.3	Exposure to fire	3
4.3.4	Protection against internal overheating	3
4.3.5	Lashing	3
4.3.6	Measures in case of emergency	3
4.3.7	Human safety	3
5	Testing	4
5.1	Test conditions	4
5.2	Installation	4
5.3	Operation	4
5.3.1	Vibration and mechanical shock	4
5.3.2	Immersion into water	4
5.3.3	Exposure to fire	4
5.3.4	Protection against internal overheating	5
5.3.5	Lashing	5
6	Supplementary information	5
Bibliography		6