

# ISO 16315:2026-02 (E)

## Small craft - Electrical systems used for electrical propulsion

---

<b>Contents</b>		<b>Page</b>
Foreword		v
Introduction		vi
<b>1</b>	<b>Scope</b>	<b>1</b>
<b>2</b>	<b>Normative references</b>	<b>1</b>
<b>3</b>	<b>Terms and definitions</b>	<b>2</b>
<b>4</b>	<b>General requirements</b>	<b>5</b>
4.1	General	5
4.2	Components of an electric propulsion system	6
4.3	Electric propulsion systems	6
4.4	Configuration of electrical systems sharing a common energy source for propulsion and service power	8
4.4.1	DC systems	8
4.4.2	AC systems	8
4.5	Environmental factors	9
4.6	Electrical ratings	9
4.7	Equipment	10
4.7.1	Transformers	10
4.7.2	Converters	10
4.7.3	Motors	10
4.8	Enclosures	10
4.9	Identification of equipment and conductors	10
4.10	Electromagnetic compatibility (EMC)	11
4.11	Electrical equipment in the vicinity of batteries	11
4.12	Hazardous areas	12
4.13	Fire protection	12
<b>5</b>	<b>Controls, monitoring, system alerts and trip alarms</b>	<b>12</b>
5.1	Electrical/electronic controls for electric propulsion systems	12
5.1.1	Controls	12
5.1.2	Emergency stop	13
5.1.3	Fault trip reset	13
5.2	Instruments, alerts and trip alarms	13
5.2.1	General	13
5.2.2	Operating mode and status	14
5.2.3	System alerts	14
5.2.4	Fault trip alarms	14
<b>6</b>	<b>Protection against electric shock</b>	<b>14</b>
6.1	Protection against direct contact	14
6.2	Automatic disconnection of supply to the electric propulsion system under fault-to-earth conditions (earthed two-wire DC systems and earthed neutral AC systems)	15
6.3	Fault-to-earth monitoring for DC fully insulated systems and DC three-wire systems	15
6.4	Fault-to-earth tripping in AC non-neutral earthed systems (IT-type system)	16
<b>7</b>	<b>Protection against overcurrent</b>	<b>16</b>
7.1	General	16
7.2	Characteristics of protective devices	16
7.3	Overcurrent protection devices in the outgoing circuit(s) from a battery	17
7.4	Overcurrent protection devices in fully insulated systems	17

7.4.1	Single pole overcurrent protection.....	17
7.4.2	Dual pole overcurrent protection.....	17
<b>8</b>	<b>Battery monitoring and installation.....</b>	<b>17</b>
8.1	General arrangements.....	17
8.2	Isolation of batteries or battery banks.....	18
8.3	Operational switching of battery(s) or battery bank(s).....	18
8.4	Permanently energized circuits.....	18
8.5	Ventilation.....	19
<b>9</b>	<b>Electrical installation.....</b>	<b>19</b>
9.1	General.....	19
9.2	Segregation of electrical propulsion system cables.....	19
<b>10</b>	<b>Testing.....</b>	<b>19</b>
10.1	General.....	19
10.2	Earthing and bonding.....	20
10.3	Insulation resistance.....	20
10.3.1	General.....	20
10.3.2	DC electrical propulsion systems.....	20
10.3.3	AC electrical propulsion systems.....	20
10.3.4	Switchboards, panel boards and distribution boards.....	20
10.3.5	Power and lighting final circuits.....	20
10.3.6	Generators and motors.....	21
10.3.7	Transformers.....	21
10.4	Electrical/electronic controls systems for propulsion motor control.....	21
10.5	On load test and inspection of electrical propulsion systems, and associated switch gear and control gear.....	21
10.6	Voltage drop.....	21
	<b>Annex A (normative) Information and instructions for the owner's manual.....</b>	<b>22</b>
	<b>Annex B (normative) Installation documentation.....</b>	<b>23</b>
	<b>Annex C (informative) Electromagnetic compatibility documents.....</b>	<b>24</b>
	<b>Bibliography.....</b>	<b>25</b>