ISO 14404-2:2024-09 (E)

Calculation method of carbon dioxide emission intensity from iron and steel production - Part 2: Steel plant with electric arc furnace (EAF)

Contents

Page

Foreword iv

Introduction v

1 Scope 1

2 Normative references 1

3 Termsanddefinitions 1
3.1 Emissions 1
3.2 Gas fuel 2
3.3 Liquid fuel 2
3.4 Solid fuel 3
3.5 Auxiliary material 3
3.6 Energy carriers 4
3.7 Ferrous containing materials 4
3.8 Alloys 5
3.9 Other imported/exported materials 5
3.10 Others 5

4 Symbols 6

5 Principles 7
5.1 General 7
5.2 Relevance 7
5.3 Completeness 7
5.4 Consistency 7
5.5 Accuracy 7
5.6 Transparency 7

6 Boundary 8
6.1 General 8
6.2 Category 1 8
6.3 Category 2 9
6.4 Category 3 9
6.5 Category 4 9

7 Calculation 9
7.1 General 9
7.2 Calculation procedure 9
7.2.1 Data collection of crude steel production 9
7.2.2 Data collection direct and/or upstream CO2 emission sources 10
7.2.3 Data collection of credit CO2 emission sources 11
7.2.4 Calculation 12

Annex A (informative) Calculation of energy consumption and intensity 15

Annex B (informative) Example of template for using different emission factors or emission sources from Table 4 17

Annex C (informative) Example of CO2 emission and intensity calculations for steel plant -- Data of a steel plant 19

Annex D (informative) Decarbonization strategies and its impact on CO2 calculation method 22

Bibliography 23