DIN EN 16241:2014-06 (E)

Railway applications - Slack adjuster

Contents

Page

Foreword 4

1 Scope 5

2 Normative references 5

3 Terms and definitions 5

4 Design and manufacture 6
4.1 Requirements 6
4.1.1 General 6
4.1.2 Maintenance of block to tread clearance 6
4.1.3 Take up 6
4.1.4 Pay out 6
4.1.5 Shock and Vibration 6
4.1.6 Space envelope 7
4.1.7 Maximum load absorption 9
4.2 Service life 9
4.3 Ambient temperature 10
4.4 Other environmental conditions 10
4.4.1 General 10
4.4.2 Humidity 10
4.4.3 Rain 10
4.4.4 Snow, ice and hail 10
4.4.5 Solar radiation 11
4.4.6 Resistance to pollution 11
4.5 External appearance 11

5 Materials 11

6 Type test methods 11
6.1 Sampling for type test 11
6.2 Test requirements 12
6.3 Test procedure 12
6.3.1 Principle 12
6.3.2 Check of physical and geometrical characteristics 12
6.3.3 Operation 12
6.3.4 Operation at extreme temperatures 13
6.3.5 Maximum load absorption 14
6.3.6 Life test 14
6.4 Approval validity 14
6.5 Test Report 15

7 Routine test 15

8 In-Service assessment 15

9 Designation 15

10 Identification and marking 15

Annex A (informative) In-service trial 16

A.1 General 16
A.2 Test set-up and sampling 16
A.3 Procedure 16
A.4 Pass/fail criteria 16

Annex ZA (informative) Relationship between this European Standard and the Essential Requirements of EU Directive 2008/57/EC 17

Bibliography 21