ISO/TR 9212:2015-06 (E)

Hydrometry - Methods of measurement of bedload discharge

Contents

Page

Foreword iv

Introduction v

1 Scope 1

2 Normative references 1

3 Termsanddefinitions 1

4 Measurement of bedload 1
4.1 General 1
4.2 Direct measurement methods 1
4.3 Indirect measurement methods 2

5 Design and strategy of measurement of bedload discharge 2

6 Site selection 2

7 Bedload samplers and traps 3
7.1 Bedload samplers 3
7.1.1 Requirements of an ideal bedload sampler 3
7.1.2 Basket or box type sampler 3
7.1.3 Frame and net sampler 4
7.1.4 Pressure-difference sampler 4
7.1.5 Advantages and disadvantages 5
7.1.6 Characteristics of bedload samplers 9
7.2 Measurement using bedload trap 10
7.2.1 Vortex tube bedload trap 10
7.2.2 Pit and Trough trap 11
7.2.3 Advantages and disadvantages 12

8 Procedures for measurement of bedload discharge using bedload samplers 12
8.1 General 12
8.2 Sample identification 13
8.3 Calculations 14
8.4 Errors 15

9 Indirect measurement of bedload 16
9.1 General 16
9.2 Differential measurement 16
9.3 Volumetric measurement 16
9.4 Dune-tracking 17
9.4.1 Moving boat 17
9.4.2 In situ echo sounder 17
9.4.3 Accuracy of the dune-tracking methods 18
9.5 Tracers 18
9.6 Remote sensing LiDAR 18
9.7 Acoustic instruments 19
9.8 Acoustic Doppler current profiler 19

Annex A (informative) Bedload-surrogate monitoring technologies[8] 20

Bibliography 24