ISO 7870-4:2011-07 (E)

Control charts - Part 4: Cumulative sum charts

Contents

Page

Foreword iv

Introduction v

1 Scope 1

2 Normative references 1

3 Terms and definitions, abbreviated terms and symbols 1
3.1 Terms and definitions 1
3.2 Abbreviated terms 2
3.3 Symbols 3

4 Principal features of cumulative sum (cusum) charts 4

5 Basic steps in the construction of cusum charts -- Graphical representation 5

6 Example of a cusum plot -- Motor voltages 5
6.1 The process 5
6.2 Simple plot of results 6
6.3 Standard control chart for individual results 7
6.4 Cusum chart -- Overall perspective 7
6.5 Cusum chart construction 8
6.6 Cusum chart interpretation 9
6.7 Manhattan diagram 12

7 Fundamentals of making cusum-based decisions 12
7.1 The need for decision rules 12
7.2 The basis for making decisions 13
7.3 Measuring the effectiveness of a decision rule 14

8 Types of cusum decision schemes 16
8.1 V-mask types 16
8.2 Truncated V-mask 16
8.3 Alternative design approaches 22
8.4 Semi-parabolic V-mask 23
8.5 Snub-nosed V-mask 24
8.6 Full V-mask 24
8.7 Fast initial response (FIR) cusum 25
8.8 Tabular cusum 25

9 Cusum methods for process and quality control 27
9.1 The nature of the changes to be detected 27
9.2 Selecting target values 28
9.3 Cusum schemes for monitoring location 29
9.4 Cusum schemes for monitoring variation 39
9.5 Special situations 47
9.6 Cusum schemes for discrete data 49

Annex A (informative) Von Neumann method 56

Annex B (informative) Example of tabular cusum 57

Annex C (informative) Estimation of the change point when a step change occurs 61

Bibliography 63