DIN EN ISO 13790:2008-09 (E)

Energy performance of buildings - Calculation of energy use for space heating and cooling (ISO 13790:2008)

Contents

Page

Foreword 4

Introduction 5

1 Scope 8

2 Normative references 9

3 Terms and definitions 10
3.1 Time steps, periods and seasons 10
3.2 Spaces, zones and areas 10
3.3 Temperatures 11
3.4 Energy 12
3.5 Building heat transfer 14
3.6 Building heat gains and recoverable system thermal losses 14
3.7 Building energy balance 15

4 Symbols 15

5 Outline of the calculation procedures 18
5.1 Energy balance of building and systems 18
5.2 Main structure of calculation procedure 19
5.3 Different types of calculation method 22
5.4 Main characteristics of the different methods 22
5.5 Overall energy balances for building and systems 23

6 Definition of boundaries and zones 23
6.1 General 23
6.2 Boundary of the building for the calculation 24
6.3 Thermal zones 24
6.4 Determination of conditioned floor area, Af 27

7 Building energy need for space heating and cooling 28
7.1 Calculation procedure 28
7.2 Energy need for heating and cooling 29
7.3 Multiple steps to integrate or isolate interactions 34
7.4 Length of heating and cooling seasons for operation of season-length-dependent provisions 36

8 Heat transfer by transmission 40
8.1 Calculation procedure 40
8.2 Total heat transfer by transmission per building zone 40
8.3 Transmission heat transfer coefficients 41
8.4 Input data and boundary conditions 44

9 Heat transfer by ventilation 45
9.1 Calculation procedure 45
9.2 Total heat transfer by ventilation per building zone -- Seasonal or monthly method 45
9.3 Ventilation heat transfer coefficients 46
9.4 Input data and boundary conditions 52

10 Internal heat gains 54
10.1 Calculation procedure 54
10.2 Overall internal heat gains 54
10.3 Internal heat gain elements -- All methods 56
10.4 Input data and boundary conditions 56

11 Solar heat gains 60
11.1 Calculation procedure 60
11.2 Overall solar heat gains 61
11.3 Solar heat gain elements 62
11.4 Input data and boundary conditions 64

12 Dynamic parameters 68
12.1 Calculation procedure 68
12.2 Dynamic parameters 69
12.3 Boundary conditions and input data 74

13 Indoor conditions 75
13.1 Different modes 75
13.2 Calculation procedures 76
13.3 Boundary conditions and input data 83

14 Energy use for space heating and cooling 83
14.1 Annual energy needs for heating and cooling, per building zone 83
14.2 Annual energy needs for heating and cooling, per combination of systems 83
14.3 Total system energy use for space heating and cooling and ventilation systems 84

15 Report 88
15.1 General 88
15.2 Input data 88
15.3 Results 89

Annex A (normative) Parallel routes in normative references 92

Annex B (normative) Multi-zone calculation with thermal coupling between zones 96

Annex C (normative) Full set of equations for simple hourly method 100

Annex D (normative) Alternative formulation for monthly cooling method 105

Annex E (normative) Heat transfer and solar heat gains of special elements 107

Annex F (normative) Climate-related data 118

Annex G (informative) Simplified methods and standard input data 120

Annex H (informative) Accuracy of the method 134

Annex I (informative) Explanation and derivation of monthly or seasonal utilization factors 143

Annex J (informative) Worked example; simple hourly and monthly methods 155

Annex K (informative) Flow charts of the calculation procedures 161

Bibliography 168