ISO 10300-1:2001-08 (E)

Calculation of load capacity of bevel gears - Part 1: Introduction and general influence factors

Contents

Page

Foreword iv

Introduction v

1 Scope 1

2 Normative references 1

3 Terms and definitions 2

4 Symbols and abbreviations 2

5 Application 10

6 External force and application factor, KA 13

7 Dynamic factor, Kv 15

8 Face load factors, KH>, KF> 25

9 Transverse load factors, KH=, KF= 27

Annex A (normative) Calculation of bevel gear geometry 34

Annex B (informative) Values for application factor, KA 45

Annex C (informative) Contact patterns 46