ISO 10300-2:2001-08 (E)

Calculation of load capacity of bevel gears - Part 2: Calculation of surface durability (pitting)

Contents

Page

Foreword iv

Introduction v

1 Scope 1

2 Normative references 1

3 Terms and definitions 2

4 Symbols and abbreviated terms 2

5 Pitting damage-assessment requirements and safety factors 2

6 Gear-tooth rating formulae 3

7 Zone factor, ZH 4

8 Mid-zone factor, ZM-B 5

9 Elasticity factor, ZE 7

10 Load-sharing factor, ZLS 7

11 Spiral-angle factor, Zb 7

12 Bevel gear factor, ZK 8

13 Size factor, ZX 8

14 Lubricant-film influence factors, ZL, Zv, ZR 8

15 Work-hardening factor, ZW 12

16 Life factor, ZNT 13

Annex A (informative) Load sharing factor, ZLS 16