ISO 6336-2:2006-09 (E)

Calculation of load capacity of spur and helical gears - Part 2: Calculation of surface durability (pitting)

Contents

Page

Foreword iv

Introduction v

1 Scope 1

2 Normative references 1

3 Terms, definitions, symbols and abbreviated terms 2

4 Pitting damage and safety factors 2

5 Basic formulæ 3
5.1 General 3
5.2 Safety factor for surface durability (against pitting), SH 3
5.3 Contact stress, H 3
5.4 Permissible contact stress, HP 5

6 Zone factor, ZH, and single pair tooth contact factors, ZB and ZD 9
6.1 Zone factor, ZH 9
6.2 Single pair tooth contact factors, ZB and ZD, for u 2 10
6.3 Single pair tooth contact factors, ZB and ZD, for > 2 11

7 Elasticity factor, ZE 11

8 Contact ratio factor, Z 12
8.1 Determination of contact ratio factor, Z 13
8.2 Calculation of transverse contact ratio, , and overlap ratio, ... 14

9 Helix angle factor, Z 15

10 Strength for contact stress 16
10.1 Allowable stress numbers (contact), H lim, for Method B 16
10.2 Allowable stress number values for Method BR 16

11 Life factor, ZNT (for flanks) 16
11.1 Life factor ZNT: Method A 17
11.2 Life factor ZNT: Method B 17

12 Influence of lubricant film, factors ZL, Zv and ZR 18
12.1 General 18
12.2 Influence of lubricant film: Method A 19
12.3 Influence of lubricant film, factors ZL, Zv and ZR: Method B 19

13 Work hardening factor, ZW 24
13.1 Work hardening factor, ZW: Method A 24
13.2 Work hardening factor, ZW: Method B 25

14 Size factor, ZX 29

Annex A (informative) Start of involute 30

Bibliography 33