

ISO 21218:2013-03 (E)

Intelligent transport systems - Communications access for land mobiles (CALM) - Access technology support

Contents		Page
Foreword		v
Introduction		vi
1	Scope	1
2	Normative references	1
3	Terms and definitions	1
4	Abbreviated terms	2
5	Communication module adaptation	4
5.1	General	4
5.2	Communication adaptation layer	4
5.3	CI management adaptation entity	5
5.4	CI security adaptation entity	5
6	Communication interface	5
6.1	Architecture	5
6.2	Classification of CIs	5
6.3	Link Identifier	7
6.4	Procedures	8
6.4.1	General	8
6.4.2	Registration	8
6.4.3	Deregistration	9
6.4.4	Inactivation	10
6.4.5	Activation	10
6.4.6	Suspension	10
6.4.7	Resuming	11
6.4.8	Connection	11
6.4.9	Disconnection	11
6.4.10	CI state machine	11
6.4.11	Cross-CI prioritization	13
6.4.12	Protection of CI	15
6.4.13	Regulatory information management	16
7	Virtual communication interface	16
7.1	Concept	16
7.2	VCI identifier	20
7.3	Procedures	20
7.3.1	Creation of VCI	20
7.3.2	Reset of VCI	20
7.3.3	Deletion of VCI	20
7.3.4	Association of peer with Link-ID	21
7.3.5	Change of I-Parameter settings	21
8	Communication SAP	22
8.1	LLC Types of Operation	22
8.2	Addressing	23
8.2.1	SAP addresses	23

8.2.2	IN-SAP source and destination addresses	24
8.2.3	SNAP	25
8.3	Service primitives (informative)	26
8.3.1	IN-UNITDATA.request	26
8.3.2	IN-UNITDATA.indication	26
8.3.3	IN-UNITDATA-STATUS.indication	27
8.4	Priority	28
8.5	Access parameters	29
8.6	Transmission status	29
9	Management SAP	29
10	Conformance	30
11	Test methods	30
Annex A (normative) I-Parameters		31
Annex B (normative) ASN.1 definitions		37
B.1	Use of modules	37
B.2	ASN.1 modules	37
Annex C (normative) Extended universal 64 bit identifier		47
C.1	EUI-64 format	47
C.2	Encapsulation of 48-bit MAC addresses	48
C.3	Encapsulation of identifiers specific to ITS	48
Bibliography		50