

# DIN EN ISO 19014-3:2019-06 (E)

## Earth-moving machinery - Functional safety - Part 3: Environmental performance and test requirements of electronic and electrical components used in safety-related parts of the control system (ISO 19014-3:2018)

---

<b>Contents</b>		<b>Page</b>
<b>European foreword</b>		<b>4</b>
<b>Foreword</b>		<b>5</b>
<b>Introduction</b>		<b>6</b>
<b>1</b>	<b>Scope</b>	<b>7</b>
<b>2</b>	<b>Normative references</b>	<b>7</b>
<b>3</b>	<b>Terms and definitions</b>	<b>8</b>
<b>4</b>	<b>Functional status classifications</b>	<b>8</b>
4.1	Class A	8
4.2	Class B	8
4.3	Class C	8
4.4	Class D	8
<b>5</b>	<b>Tests and requirements</b>	<b>8</b>
5.1	General	8
5.2	Dust	9
5.2.1	Purpose	9
5.2.2	Test method	9
5.3	Chemical resistance	9
5.3.1	Purpose	9
5.3.2	Test method	9
5.4	Salt spray	10
5.4.1	Purpose	10
5.4.2	Test method	10
5.5	Pressure wash	10
5.5.1	Purpose	10
5.5.2	Test method	10
5.6	Random vibration	10
5.6.1	Purpose	10
5.6.2	Test method	10
5.7	Operating shock	11
5.7.1	Purpose	11
5.7.2	Test method	11
5.8	Temperature cycles	12
5.8.1	Purpose	12
5.8.2	Test method	12
5.9	Thermal shock	13
5.9.1	Purpose	13
5.9.2	Test method	13
5.10	Humidity cycles	14
5.10.1	Purpose	14
5.10.2	Test method	14
5.11	Overvoltage condition	14
5.11.1	Purpose	14
5.11.2	Test method	14
5.12	Undervoltage condition (reset behaviour at voltage drop)	14
5.12.1	Purpose	14
5.12.2	Test method	14

5.13	Electromagnetic compatibility.....	14
5.13.1	Purpose.....	14
5.13.2	Test method.....	15
5.14	Reverse polarity.....	15
5.14.1	Purpose.....	15
5.14.2	Test method.....	15
<b>Annex A (informative) Test checklist.....</b>		<b>16</b>
<b>Bibliography.....</b>		<b>17</b>