

# ISO 4064-5:2014-06 (E)

## Water meters for cold potable water and hot water - Part 5: Installation requirements

---

<b>Contents</b>		<b>Page</b>
Foreword .....		iv
<b>1</b>	<b>Scope .....</b>	<b>1</b>
<b>2</b>	<b>Normative references .....</b>	<b>1</b>
<b>3</b>	<b>Terms and definitions .....</b>	<b>1</b>
<b>4</b>	<b>Criteria for the selection of water meters .....</b>	<b>2</b>
<b>4.1</b>	<b>General considerations .....</b>	<b>2</b>
<b>4.2</b>	<b>Information to be provided by the manufacturer .....</b>	<b>2</b>
<b>4.3</b>	<b>Meters operating in parallel or in a group .....</b>	<b>2</b>
<b>5</b>	<b>Associated fittings .....</b>	<b>3</b>
<b>5.1</b>	<b>General .....</b>	<b>3</b>
<b>5.2</b>	<b>Upstream of the meter .....</b>	<b>3</b>
<b>5.3</b>	<b>Downstream of the meter .....</b>	<b>3</b>
<b>6</b>	<b>Installation .....</b>	<b>4</b>
<b>6.1</b>	<b>General requirements .....</b>	<b>4</b>
<b>6.2</b>	<b>Installation requirements .....</b>	<b>4</b>
<b>6.3</b>	<b>Water quality (suspended particles) .....</b>	<b>5</b>
<b>6.4</b>	<b>Electromagnetic meters .....</b>	<b>5</b>
<b>6.5</b>	<b>Meters operating in parallel or in a group .....</b>	<b>5</b>
<b>6.6</b>	<b>Security of operation .....</b>	<b>5</b>
<b>7</b>	<b>Hydraulic disturbances .....</b>	<b>5</b>
<b>7.1</b>	<b>General considerations .....</b>	<b>5</b>
<b>7.2</b>	<b>Methods to eliminate disturbances .....</b>	<b>6</b>
<b>8</b>	<b>First operation of new or repaired water meters .....</b>	<b>7</b>
<b>8.1</b>	<b>General considerations .....</b>	<b>7</b>
<b>8.2</b>	<b>Meters operating in parallel or in a group .....</b>	<b>7</b>
<b>8.3</b>	<b>Protection of the meter .....</b>	<b>7</b>
<b>8.4</b>	<b>Safety of personnel and users .....</b>	<b>9</b>
<b>8.5</b>	<b>Comfort of personnel -- Access to the water meter and fittings .....</b>	<b>10</b>
Bibliography .....		12