

ISO 3547-5:2020-05 (E)

Plain bearings - Wrapped bushes - Part 5: Checking the outside diameter

Contents		Page
Foreword		iv
Introduction		v
1	Scope	1
2	Normative references	1
3	Terms and definitions	1
4	Symbols and units	1
5	Outside diameter, D_o	2
6	Purpose of checking	2
7	Methods of checking	2
7.1	General	2
7.2	Checking method A — Measurement of outside diameter, D_o	3
7.3	Checking method B — Gauging of outside diameter, D_o	3
7.4	Checking method D — Measurement of outside diameter, $D_o > 120$ mm	3
8	Selection of checking method for outside diameter	3
9	ISO 3547-2:2017, test A — Outside diameter, D_o	3
9.1	Measuring equipment	3
9.2	Requirements for checking the block and the setting plug	5
9.3	Determination of correction factor, C	10
9.4	Procedure	10
9.5	Measuring errors	11
9.5.1	General	11
9.5.2	Errors due to measuring equipment	11
9.5.3	Errors due to the bush	11
9.5.4	Errors due to human factors	11
9.6	Summary of the factors relating to the measurement of the outside diameter, D_o , of the bush	11
9.6.1	Checking load, F_{ch}	11
9.6.2	Diameter of the checking block, $d_{ch,1}$, and of the setting plug, $d_{ch,2}$	11
9.6.3	Upper limiting value and lower limiting value for Δz	11
9.6.4	Correction factor, C	12
9.6.5	Conversion of the indicated measured value, Δz , for outside diameter	12
10	ISO 3547-2:2017, test B — Outside diameter, D_o	12
10.1	Gauging equipment	12
10.2	Requirements for measuring equipment	12
10.3	Procedure	13
10.4	Measuring errors	13
11	ISO 3547-2, test D — Outside diameter, $D_o > 120$ mm	13
11.1	Gauging equipment	13
11.2	Measuring equipment	13
11.3	Procedure	14
11.4	Measuring errors	14
12	Specifications on drawings of bushes	14
13	Specifications for control of the checking equipment	14
13.1	Gauging equipment	14
13.2	Measuring equipment	14
Bibliography		15