

# DIN ISO 16000-41:2024-08 (E)

## Indoor air - Part 41: Assessment and classification (ISO 16000-41:2023)

---

<b>Contents</b>	<b>Page</b>
National foreword.....	3
National Annex NA (informative) Bibliography.....	6
Foreword.....	7
Introduction.....	8
<b>1 Scope</b> .....	<b>9</b>
<b>2 Normative references</b> .....	<b>9</b>
<b>3 Terms and definitions</b> .....	<b>9</b>
<b>4 General</b> .....	<b>10</b>
4.1 Procedure.....	10
4.2 Parameters.....	11
<b>5 Indoor air quality</b> .....	<b>11</b>
<b>6 Quality classes</b> .....	<b>11</b>
<b>7 Criteria for the definition of the quality classes</b> .....	<b>12</b>
7.1 General.....	12
7.2 Main parameters.....	12
7.3 Secondary parameters.....	13
<b>8 Assessment plan</b> .....	<b>14</b>
8.1 Overview.....	14
8.2 Documentation and reports.....	15
8.3 Purpose of measurements.....	16
8.3.1 Possible reasons.....	16
8.3.2 Concretisation of assessment.....	16
8.4 Preliminary survey.....	16
8.4.1 General.....	16
8.4.2 Basic investigation.....	17
8.4.3 Local inspections.....	17
8.4.4 Conditions for the omission of the measurement of parameters.....	18
8.5 Investigation plan.....	18
8.5.1 General.....	18
8.5.2 Normative specifications.....	18
8.5.3 Determination of sampling points.....	19
8.5.4 Utilization of the interior room.....	19
8.5.5 Seasonal fluctuations and ventilation.....	19
8.5.6 Complementary outside air measurements.....	20
8.6 Investigation.....	20
8.7 Report.....	20
8.8 Division in quality classes.....	20
<b>Annex A (informative) Quality classes for main parameters</b> .....	<b>21</b>
<b>Annex B (informative) Standards for the preliminary survey and the design of investigation plans</b> .....	<b>28</b>
<b>Bibliography</b> .....	<b>31</b>