ISO 21433:2025-10 (E)

Plain bearings - Handling of plain bearings

Contents

Page

Foreword ..... **v**

Introduction ..... **vi**

1 Scope **1**

2 Normative references **1**

3 Terms and definitions **1**

4 Storage and transportation **1**

4.1 General 1

4.2 Storage and transportation by packing 1

4.2.1 General 1

4.2.2 Purpose of packing 1

4.2.3 Packing method 2

4.2.4 Packing material 2

4.2.5 Unpacking 2

4.3 Storage and transportation in containers 2

4.3.1 General 2

4.3.2 Purpose of storage and transportation in containers 2

4.3.3 Points to notice at storage and transportation 3

4.3.4 Other methods of storage and transportation 3

4.3.5 Attachment of test and quality certificate 3

4.4 Selection of rust inhibitors and cleaning agents 3

4.5 Storage environment 3

4.5.1 Warehouse or storage room 3

4.5.2 Ambient temperature of storage room 3

4.5.3 Environmental humidity for storage room 3

4.5.4 First-in first-out 3

4.6 Handling 4

4.7 Documentation 4

5 Method of installation of plain bearings **4**

5.1 Points to consider during plain bearings installation 4

5.1.1 Plain bearings 4

5.1.2 Housing 4

5.1.3 Press-fit method 4

5.1.4 Screw–fixing method 5

5.1.5 Keyed joint method 5

5.1.6 Retaining ring fixing method 5

5.1.7 Shrink fitting by cooling 5

5.1.8 Shrink fitting by heating 5

5.1.9 Points to notice during installation of plain bearings 5

5.1.10 Points to notice after installation of plain bearings 6

5.2 Mating shaft and assembly inspection 6

5.2.1 Mating shaft 6

5.2.2 Installation of shaft 6

5.2.3 Check of operation 6

6 Operation **6**

6.1 Cleaning (flushing) of lubrication system 6

6.2 Running-in 6

6.3 Supervision during operation 7
6.3.1 Control and check items 7
6.3.2 Record 7
7 Replacement of plain bearings 7
7.1 General 7
7.2 Dismounting of plain bearings 7
7.3 Replacement by new plain bearings 7
Bibliography 9