

ISO 11783-12:2019 (E)

Tractors and machinery for agriculture and forestry — Serial control and communications data network — Part 12: Diagnostics services

Contents

	Foreword
	Introduction
1	Scope
2	Normative references
3	Terms and definitions
4	Symbols and abbreviated terms
5	General description
6	Requirements
6.1	ISO 11783 diagnostics
6.2	Network information
6.3	Network statistics
6.4	Control function information
6.5	Functionalities
6.6	Control function diagnostics
6.7	ISO Latin 1 character set
Annex A	(normative) Diagnostic information parameter definitions
A.1	ECU part number
A.2	ECU serial number
A.3	Number of software identification fields
A.4	Software identification
A.5	ECU manufacturer name
A.6	Diagnostic protocol identification
A.7	ECU location
A.8	ECU type
A.9	Number of functionalities
A.10	Functionalities
A.11	Functionality generation
A.12	Number of option bytes
A.13	ECU hardware ID
A.14	Product identification code
A.15	Product identification brand
A.16	Product identification model
Annex B	(normative) Diagnostic information message definitions
B.1	ECU identification information
B.2	Software identification
B.3	ISOBUS certification
B.4	ISO 11783 NAME
B.5	Diagnostic protocol
B.6	Active diagnostic trouble codes (DM1)
B.7	Previously active diagnostic trouble codes (DM2)
B.8	Diagnostic data clear/reset previously active DTCs (DM3)
B.9	Control function functionalities
B.10	Product identification

Annex C (normative) Network configuration

- C.1 Network configuration**
- C.2 Diagnostic connector**

Annex D (informative) Network configuration screen examples — Network information screens

- D.1 Network information screen**
- D.2 Network statistics screen**
- D.3 Network diagnostic screen**
- D.4 Connected system functionalities screen**
- D.5 Implement capable functionalities screen**
- D.6 Functionality alarm mask**

Annex E (normative) Failure mode indicator definitions

- E.1 Overview**
- E.2 Definitions used for the FMI descriptions**
- E.3 FMI descriptions**
 - E.3.1 FMI = 0 (Data valid but above normal operation range — Most severe level)**
 - E.3.2 FMI = 1 (Data valid but below normal operational range — Most severe level)**
 - E.3.3 FMI = 2 (Data erratic, intermittent or incorrect)**
 - E.3.4 FMI = 3 (Voltage above normal or shorted to high source)**
 - E.3.5 FMI = 4 (Voltage below normal or shorted to low source)**
 - E.3.6 FMI = 5 (Current below normal or open circuit)**
 - E.3.7 FMI = 6 (Current above normal or grounded circuit)**
 - E.3.8 FMI = 7 (Mechanical system not responding or improperly adjusted)**
 - E.3.9 FMI = 8 (Abnormal frequency or pulse width or period)**
 - E.3.10 FMI = 9 (Abnormal update rate)**
 - E.3.11 FMI = 10 (Abnormal rate of change)**
 - E.3.12 FMI = 11 (Root cause not known)**
 - E.3.13 FMI = 12 (Bad intelligent unit or component)**
 - E.3.14 FMI = 13 (Out of calibration)**
 - E.3.15 FMI = 14 (Special instructions)**
 - E.3.16 FMI = 15 (Data valid but above normal operating range — Least severe level)**
 - E.3.17 FMI = 16 (Data valid but above normal operating range — Moderately severe level)**
 - E.3.18 FMI = 17 (Data valid but below normal operating range — Least severe level)**
 - E.3.19 FMI = 18 (Data valid but below normal operating range — Moderately severe level)**
 - E.3.20 FMI = 19 (Received network data in error)**
 - E.3.21 FMI = 20-30 (Reserved for future assignment)**
 - E.3.22 FMI = 31 (Condition exists)**

Page count: 31