

# DIN CEN/TR 16798-8:2018-03 (E)

Energy performance of buildings - Ventilation for buildings - Part 8: Interpretation of the requirements in EN 16798-7 - Calculation methods for the determination of air flow rates in buildings including infiltration (Module M5-5); English version CEN/TR 16798-8:2017

---

<b>Contents</b>		<b>Page</b>
European foreword.....		4
Introduction .....		7
1 Scope.....		9
2 Normative references.....		9
3 Terms and definitions .....		9
4 Symbols, subscripts and abbreviations.....		9
4.1 Symbols.....		9
4.2 Subscripts.....		10
4.3 Abbreviations .....		11
5 Brief description of the methods.....		11
5.1 Output of the method.....		11
5.1.1 General.....		11
5.1.2 Energy use outputs .....		11
5.1.3 Indoor air quality outputs.....		11
5.1.4 Summer comfort using ventilative cooling.....		11
5.2 General description of the methods.....		12
5.2.1 Multiple ventilation zones .....		12
5.2.2 Airflows within a ventilation zone.....		12
5.2.3 Separation of the ventilation zones into elementary spaces.....		12
5.3 Selection criteria between the methods .....		13
6 Calculation method, method 1 — Determination of air flow rates based on detailed building characteristics .....		14
6.1 Output data.....		14
6.2 Calculation intervals .....		14
6.3 Input data.....		14
6.4 Calculation procedure, method 1 .....		14
6.4.1 Applicable time intervals and states of operation .....		14
6.4.2 Operating conditions calculation .....		15
6.4.3 Calculation of air flow rates.....		17
7 Method 2 - Determination of air flow rates based on statistical approach .....		21
8 Quality control .....		21
9 Compliance check.....		21
10 Worked out examples, method 1 — Example 1.....		22
10.1 Description .....		22
10.2 Calculation details .....		22
10.3 Observations.....		22
Annex A (informative) Input and method selection data sheet — Template .....		23
A.1 General.....		23
A.2 References .....		23
A.3 Input data method 1 .....		23
A.4 Input data method 2.....		23

<b>Annex B</b> (informative) <b>Input and method selection data sheet — Default choices</b> .....	<b>24</b>
<b>B.1</b> <b>General</b> .....	<b>24</b>
<b>B.2</b> <b>References</b> .....	<b>24</b>
<b>B.3</b> <b>Input data method 1</b> .....	<b>24</b>
<b>B.4</b> <b>Input data method 2</b> .....	<b>24</b>
<b>Annex C</b> (informative) <b>Extract and supply air volume flow rate from a ventilation zone</b> <b>(<math>Q_{V;ETA;dis}</math>, <math>Q_{V;SUP;dis}</math>) — Calculation flowchart</b> .....	<b>25</b>
<b>Annex D</b> (informative) <b>Calculation examples — Example 1</b> .....	<b>26</b>
<b>Bibliography</b> .....	<b>41</b>