

# ISO/IEC 11572:2000-03 (E)

## Information technology — Telecommunications and information exchange between systems — Private Integrated Services Network — Circuit mode bearer services — Inter-exchange signalling procedures and protocol

---

<b>Contents</b>	<b>Page</b>
Foreword	vii
Introduction	viii
<b>1</b> Scope	<b>1</b>
<b>2</b> Conformance	<b>1</b>
<b>3</b> Normative references	<b>1</b>
<b>4</b> Terms and definitions	<b>1</b>
<b>5</b> List of acronyms	<b>3</b>
<b>6</b> General principles	<b>3</b>
<b>6.1</b> Protocol model	<b>4</b>
<b>6.2</b> Services provided to Call Control	<b>4</b>
<b>6.3</b> Services required of the Signalling Carriage Mechanism	<b>5</b>
<b>7</b> Protocol Control states	<b>5</b>
<b>7.1</b> States for circuit-mode Call Control	<b>5</b>
<b>7.1.1</b> Null State (0)	<b>5</b>
<b>7.1.2</b> Call Initiated (1)	<b>5</b>
<b>7.1.3</b> Overlap Sending (2)	<b>5</b>
<b>7.1.4</b> Outgoing Call Proceeding (3)	<b>5</b>
<b>7.1.5</b> Call Delivered (4)	<b>5</b>
<b>7.1.6</b> Call Present (6)	<b>5</b>
<b>7.1.7</b> Call Received (7)	<b>5</b>
<b>7.1.8</b> Connect Request (8)	<b>5</b>
<b>7.1.9</b> Incoming Call Proceeding (9)	<b>6</b>
<b>7.1.10</b> Active (10)	<b>6</b>
<b>7.1.11</b> Disconnect Request (11)	<b>6</b>
<b>7.1.12</b> Disconnect Indication (12)	<b>6</b>
<b>7.1.13</b> Release Request (19)	<b>6</b>
<b>7.1.14</b> Overlap Receiving (25)	<b>6</b>
<b>7.2</b> States for layer management	<b>6</b>
<b>7.2.1</b> Null State (Rest 0)	<b>6</b>
<b>7.2.2</b> Restart Request (Rest 1)	<b>6</b>
<b>7.2.3</b> Restart (Rest 2)	<b>6</b>
<b>8</b> Call Control	<b>6</b>
<b>8.1</b> States for Transit PINX Call Control	<b>7</b>
<b>8.1.1</b> TCC_Idle (0)	<b>7</b>
<b>8.1.2</b> TCC_Await Digits (1)	<b>7</b>
<b>8.1.3</b> TCC_Await Additional Digits (2)	<b>7</b>
<b>8.1.4</b> TCC_Overlap (3)	<b>7</b>
<b>8.1.5</b> TCC_Incoming Call Proceeding (4)	<b>7</b>
<b>8.1.6</b> TCC_Transit Call Proceeding (5)	<b>7</b>
<b>8.1.7</b> TCC_Call Alerting (6)	<b>7</b>
<b>8.1.8</b> TCC_Call Active (7)	<b>7</b>
<b>8.1.9</b> TCC_Await Incoming Release (8)	<b>7</b>
<b>8.1.10</b> TCC_Await Outgoing Release (9)	<b>7</b>
<b>8.1.11</b> TCC_Await Two-Way Release (10)	<b>7</b>
<b>8.1.12</b> TCC_Await Incoming Disconnect (11)	<b>7</b>

<b>8.1.13</b>	TCC_Await Outgoing Disconnect (12)	<b>7</b>
<b>8.1.14</b>	TCC_Await Two-Way Disconnect (13)	<b>8</b>
<b>9</b>	General procedures	<b>8</b>
<b>9.1</b>	Use of the services of Signalling Carriage Mechanism	<b>8</b>
<b>9.1.1</b>	Establishment of a Signalling Carriage Mechanism connection	<b>8</b>
<b>9.1.2</b>	Transfer of data	<b>8</b>
<b>9.1.3</b>	Signalling Carriage Mechanism reset	<b>8</b>
<b>9.1.4</b>	Signalling Carriage Mechanism failure	<b>8</b>
<b>9.2</b>	Handling of protocol error conditions	<b>8</b>
<b>9.2.1</b>	Protocol discriminator error	<b>8</b>
<b>9.2.2</b>	Message too short	<b>8</b>
<b>9.2.3</b>	Call reference error	<b>8</b>
<b>9.2.4</b>	Message type or message sequence errors	<b>9</b>
<b>9.2.5</b>	General information element errors	<b>9</b>
<b>9.2.6</b>	Mandatory information element errors	<b>10</b>
<b>9.2.7</b>	Non-mandatory information element errors	<b>10</b>
<b>9.2.8</b>	Signalling Carriage Mechanism reset	<b>11</b>
<b>9.2.9</b>	Signalling Carriage Mechanism failure	<b>11</b>
<b>9.3</b>	Status and status enquiry protocol procedures	<b>12</b>
<b>9.3.1</b>	Status enquiry procedure	<b>12</b>
<b>9.3.2</b>	Receiving a STATUS message	<b>12</b>
<b>10</b>	Circuit-switched Call Control procedures	<b>14</b>
<b>10.1</b>	Call establishment	<b>14</b>
<b>10.1.1</b>	Call request	<b>14</b>
<b>10.1.2</b>	Information channel selection	<b>15</b>
<b>10.1.3</b>	Overlap sending	<b>15</b>
<b>10.1.4</b>	Call proceeding	<b>16</b>
<b>10.1.5</b>	Call confirmation indication	<b>17</b>
<b>10.1.6</b>	Call connected	<b>17</b>
<b>10.1.7</b>	Use of the PROGRESS message	<b>17</b>
<b>10.1.8</b>	Failure of call establishment	<b>18</b>
<b>10.2</b>	Call clearing	<b>18</b>
<b>10.2.1</b>	Terminology	<b>18</b>
<b>10.2.2</b>	Exception conditions	<b>18</b>
<b>10.2.3</b>	Clearing	<b>19</b>
<b>10.2.4</b>	Clear collision	<b>19</b>
<b>10.3</b>	Call collisions	<b>19</b>
<b>10.4</b>	Transit PINX Call Control requirements	<b>19</b>
<b>10.4.1</b>	Receipt of address information	<b>20</b>
<b>10.4.2</b>	State TCC_Await_Digits	<b>20</b>
<b>10.4.3</b>	State TCC_Await_Additional_Digits	<b>21</b>
<b>10.4.4</b>	State TCC_Overlap	<b>22</b>
<b>10.4.5</b>	Channel through connection procedures	<b>22</b>
<b>10.4.6</b>	State TCC_Incoming_Call_Proceeding	<b>23</b>
<b>10.4.7</b>	State TCC_Transit_Call_Proceeding	<b>23</b>
<b>10.4.8</b>	State TCC_Call_Alerting	<b>24</b>
<b>10.4.9</b>	State TCC_Call_Active	<b>24</b>
<b>10.4.10</b>	Call clearing at a Transit PINX	<b>24</b>
<b>10.4.11</b>	Handling of Basic Call information elements at a Transit PINX	<b>25</b>

<b>10.5</b>	<b>Originating PINX Call Control requirements</b>	<b>26</b>
<b>10.5.1</b>	Transmission of the SETUP message	26
<b>10.5.2</b>	Agreement of the information channel	27
<b>10.5.3</b>	Receipt of Progress indicators	27
<b>10.5.4</b>	Receipt of ALERTING message	27
<b>10.5.5</b>	Receipt of CONNECT message	27
<b>10.5.6</b>	Call clearing initiated by the Originating PINX	27
<b>10.5.7</b>	Receipt of an indication of call clearing	27
<b>10.6</b>	<b>Terminating PINX Call Control requirements</b>	<b>28</b>
<b>10.6.1</b>	Receipt of the SETUP message	28
<b>10.6.2</b>	Transmission of ALERTING message	28
<b>10.6.3</b>	Transmission of Progress indicators	28
<b>10.6.4</b>	Transmission of CONNECT message	28
<b>10.6.5</b>	Call clearing initiated by the Terminating PINX	29
<b>10.6.6</b>	Receipt of an indication of call clearing	29
<b>10.7</b>	<b>Incoming Gateway PINX Call Control requirements</b>	<b>29</b>
<b>10.7.1</b>	Transmission of the SETUP message	29
<b>10.7.2</b>	Interworking indications in the SETUP Message	30
<b>10.7.3</b>	Agreement of the information channel	30
<b>10.7.4</b>	Receipt of Progress indicators	30
<b>10.7.5</b>	Receipt of ALERTING message	30
<b>10.7.6</b>	Receipt of CONNECT message	30
<b>10.7.7</b>	Call clearing initiated by the Incoming Gateway PINX	31
<b>10.7.8</b>	Receipt of an indication of call clearing	31
<b>10.8</b>	<b>Outgoing Gateway PINX Call Control requirements</b>	<b>31</b>
<b>10.8.1</b>	Receipt of the SETUP message	31
<b>10.8.2</b>	Connection of the information channel	32
<b>10.8.3</b>	Transmission of interworking indications	32
<b>10.8.4</b>	Transmission of ALERTING message	32
<b>10.8.5</b>	Transmission of CONNECT message	32
<b>10.8.6</b>	Call clearing initiated by the Outgoing Gateway PINX	33
<b>10.8.7</b>	Receipt of an indication of call clearing	33
<b>11</b>	<b>Procedures for layer management</b>	<b>33</b>
<b>11.1</b>	<b>Restart procedures</b>	<b>33</b>
<b>11.1.1</b>	Sending RESTART	33
<b>11.1.2</b>	Receipt of RESTART	34
<b>11.1.3</b>	Restart collision	34
<b>12</b>	<b>Protocol timers</b>	<b>35</b>
<b>13</b>	<b>Functional definition of messages</b>	<b>36</b>
<b>13.1</b>	<b>Messages for general procedures</b>	<b>37</b>
<b>13.1.1</b>	STATUS	37
<b>13.1.2</b>	STATUS ENQUIRY	37
<b>13.2</b>	<b>Messages for Circuit Mode Call Control</b>	<b>38</b>
<b>13.2.1</b>	ALERTING	38
<b>13.2.2</b>	CALL PROCEEDING	38
<b>13.2.3</b>	CONNECT	38
<b>13.2.4</b>	CONNECT ACKNOWLEDGE	39
<b>13.2.5</b>	DISCONNECT	39
<b>13.2.6</b>	INFORMATION	39
<b>13.2.7</b>	PROGRESS	39
<b>13.2.8</b>	RELEASE	40
<b>13.2.9</b>	RELEASE COMPLETE	40

<b>13.2.10</b>	<b>SETUP</b>	<b>40</b>
<b>13.2.11</b>	<b>SETUP ACKNOWLEDGE</b>	<b>41</b>
<b>13.3</b>	<b>Messages for layer management</b>	<b>41</b>
<b>13.3.1</b>	<b>RESTART</b>	<b>41</b>
<b>13.3.2</b>	<b>RESTART ACKNOWLEDGE</b>	<b>41</b>
<b>14</b>	<b>General message format and coding of information elements</b>	<b>41</b>
<b>14.1</b>	<b>Overview</b>	<b>42</b>
<b>14.2</b>	<b>Protocol discriminator</b>	<b>42</b>
<b>14.3</b>	<b>Call reference</b>	<b>43</b>
<b>14.4</b>	<b>Message type</b>	<b>44</b>
<b>14.5</b>	<b>Other information elements for Basic Call control (codeset 0)</b>	<b>44</b>
<b>14.5.1</b>	<b>Coding rules</b>	<b>44</b>
<b>14.5.2</b>	<b>Extension of codesets</b>	<b>46</b>
<b>14.5.3</b>	<b>Locking shift procedure</b>	<b>47</b>
<b>14.5.4</b>	<b>Non-locking shift procedure</b>	<b>47</b>
<b>14.5.5</b>	<b>Bearer capability</b>	<b>48</b>
<b>14.5.6</b>	<b>Call state</b>	<b>50</b>
<b>14.5.7</b>	<b>Called party number</b>	<b>51</b>
<b>14.5.8</b>	<b>Called party subaddress</b>	<b>52</b>
<b>14.5.9</b>	<b>Calling party number</b>	<b>53</b>
<b>14.5.10</b>	<b>Calling party subaddress</b>	<b>53</b>
<b>14.5.11</b>	<b>Cause</b>	<b>54</b>
<b>14.5.12</b>	<b>Channel identification</b>	<b>57</b>
<b>14.5.13</b>	<b>Connected number</b>	<b>60</b>
<b>14.5.14</b>	<b>Connected subaddress</b>	<b>60</b>
<b>14.5.15</b>	<b>High layer compatibility (layers 4-7)</b>	<b>61</b>
<b>14.5.16</b>	<b>Low layer compatibility (layers 1-3)</b>	<b>61</b>
<b>14.5.17</b>	<b>Progress indicator</b>	<b>61</b>
<b>14.5.18</b>	<b>Restart indicator</b>	<b>62</b>
<b>14.5.19</b>	<b>Sending complete</b>	<b>63</b>
<b>14.6</b>	<b>Information elements of codeset 5</b>	<b>63</b>
<b>Annex A</b>	<b>(normative) Protocol Implementation Conformance Statement (PICS) for ISO/IEC 11572</b>	<b>64</b>
<b>Annex B</b>	<b>(informative) Use of the cause information element</b>	<b>75</b>
<b>Annex C</b>	<b>(informative) Examples of message sequences</b>	<b>78</b>
<b>Annex D</b>	<b>(informative) Manufacturer specific information</b>	<b>82</b>
<b>Annex E</b>	<b>(informative) SDL diagram for the procedures over a symmetrical link between two peer PINX's</b>	<b>83</b>
<b>Annex F</b>	<b>(informative) SDL diagram for the procedures on either side of a Transit-PINX</b>	<b>104</b>
<b>Annex G</b>	<b>(informative) Bibliography</b>	<b>120</b>
<b>Annex ZA</b>	<b>(normative) Segmentation and reassembly procedures</b>	<b>121</b>
<b>Annex ZB</b>	<b>(normative) Additional progress descriptions</b>	<b>131</b>
<b>Annex ZC</b>	<b>(normative) Party category functionality</b>	<b>135</b>