

# ISO 26021-1:2022-02 (E)

## Road vehicles - End-of-life activation of in-vehicle pyrotechnic devices - Part 1: Application and communication interface

---

<b>Contents</b>	<b>Page</b>
<b>Foreword</b> .....	<b>vii</b>
<b>Introduction</b> .....	<b>viii</b>
<b>1 Scope</b> .....	<b>1</b>
<b>2 Normative references</b> .....	<b>1</b>
<b>3 Terms and definitions</b> .....	<b>2</b>
<b>4 Symbols and abbreviated terms</b> .....	<b>3</b>
4.1 Symbols.....	3
4.2 Abbreviated terms.....	3
<b>5 Conventions</b> .....	<b>5</b>
<b>6 Basic principles and use cases overview</b> .....	<b>5</b>
6.1 Basic principles.....	5
6.2 Use case groups and associated use cases.....	6
<b>7 Use cases definition (UC)</b> .....	<b>7</b>
7.1 UCG 1 – Perform communication interface discovery.....	7
7.1.1 UC 1.1 – Discover DoCAN communication interface.....	7
7.1.2 UC 1.2 – Discover DoIP communication interface.....	7
7.2 UCG-2 – Perform authentication.....	7
7.2.1 UC 2.1 – Perform PDT authentication.....	7
7.2.2 UC 2.2 – Perform fixed-address PCU/PCU(s) authentication.....	8
7.3 UCG 3 – Perform system initialisation (Sys-Init).....	8
7.3.1 UC 3.1 – Report PCU hardware deployment method.....	8
7.3.2 UC 3.2 – Report number of PCU(s).....	9
7.3.3 UC 3.3 – Report address information of PCU(s).....	9
7.3.4 UC 3.4 – Report vehicle identification number.....	9
7.3.5 UC 3.5 – Report dismantling documentation of PCU.....	10
7.4 UCG 4 – Perform PCU initialisation (PCU-Init).....	10
7.4.1 UC 4.1 – Report PCU deployment loop identification table.....	10
7.4.2 UC 4.2 – Initiate safetySystemDiagnosticSession.....	11
7.4.3 UC 4.3 – Keep-alive safetySystemDiagnosticSession.....	11
7.4.4 UC 4.4 – Unlock security of PCU.....	12
7.4.5 UC 4.5 – Execute PCU(s) scrapping program module loader.....	12
7.5 UCG 5 – Perform PCU and ACL sequence (PCU- and ACL-Scrapping).....	13
7.5.1 UC 5.1 – Report ACL deployment sequence (ACL-Init).....	13
7.5.2 UC 5.2 – Write dismantling documentation into PCU (Device-Deploy).....	13
7.5.3 UC 5.3 – Perform ACL deployment confirmation sequence (Device-Deploy).....	14
7.5.4 UC 5.4 – Perform PCU pyrotechnic device scrapping via loop identification (Device-Deploy).....	14
7.6 UCG 6 – Terminate PCU pyrotechnic device deployment (PCU-End).....	15
7.6.1 UC 6.1 – Terminate PCU pyrotechnic device scrapping via communication interface.....	15
7.6.2 UC 6.2 – Terminate PCU pyrotechnic device scrapping via ACL.....	15
<b>8 Application (APP)</b> .....	<b>16</b>
8.1 APP – Preconditions of end-of-life activation of pyrotechnic devices.....	16
8.2 APP – Overview of end-of-life activation of pyrotechnic devices sequence.....	17
8.3 APP – Software provisions.....	19
8.3.1 APP – Scrapping program module (SPM).....	19
8.3.2 APP – Scrapping program module loader (SPL).....	19

8.3.3	APP – PCU loop identification table.....	19
8.4	APP – Mapping of use cases to requirements.....	20
8.5	APP – Application timing definition.....	21
8.6	APP – Discovery of communication interface (Com I/F-Discovery).....	22
8.6.1	APP – Overview of discovery of communication interface (Com-Discovery).....	22
8.6.2	APP – Setup DoCAN communication interface.....	22
8.6.3	APP – Setup DoIP communication interface.....	24
8.6.4	APP – Determination of DoCAN or DoIP communication interface in the vehicle.....	25
8.7	APP – Perform authentication – Optional (Sys-Auth).....	26
8.7.1	APP – Overview of the authentication – Optional (Sys-Auth).....	26
8.7.2	APP – PDT authentication against fixed-address PCU – Optional (Sys-Auth).....	26
8.7.3	APP – Fixed-address PCU authentication against PDT – Optional (Sys-Auth).....	27
8.8	APP – Perform system initialisation (Sys-Init).....	27
8.8.1	APP – Overview of the system initialisation (Sys-Init).....	27
8.8.2	APP – Report PcuHardwareDeploymentMethod (Sys-Init).....	28
8.8.3	APP – Report number of PCUs (Sys-Init).....	28
8.8.4	APP – Report DoCAN address information of PCUs (Sys-Init).....	28
8.8.5	APP – Report DoIP address information of PCUs (Sys-Init).....	30
8.8.6	APP – Report vehicle identification number (Sys-Init).....	31
8.8.7	APP – Report dismantling documentation of PCU (Sys-Init).....	31
8.9	APP – Perform PCU initialisation (PCU-Seq).....	31
8.9.1	APP – Overview of the PCU initialisation (PCU-Seq).....	31
8.9.2	APP – Report PCU deployment loop identification table (PCU-Seq).....	32
8.9.3	APP – Initiate safetySystemDiagnosticSession (PCU-Seq).....	33
8.9.4	APP – Keep-alive safetySystemDiagnosticSession (PCU-Seq).....	33
8.9.5	APP – Unlock security of PCU (PCU-Seq).....	33
8.9.6	APP – Execute PCU scrapping program module loader (PCU-Seq).....	33
8.10	APP – Perform PCU and ACL scrapping (Device-Deploy).....	34
8.10.1	APP – Overview of the PCU- and ACL-Scrapping (Device-Deploy).....	34
8.10.2	APP – Report ACL deployment sequence (ACL-Prep).....	34
8.10.3	APP – Write dismantling documentation into PCU (Device-Deploy).....	35
8.10.4	APP – Confirm ACL deployment sequence (Device-Deploy).....	35
8.10.5	APP – Perform device scrapping (Device-Deploy).....	35
8.10.6	APP – Evaluation of device scrapping (Device-Deploy).....	35
8.10.7	APP – Next pyrotechnic device (Device-Deploy).....	36
8.11	APP – Terminate PCU and ACL pyrotechnic device deployment (PCU-End).....	36
8.11.1	APP – Overview of the PCU- and ACL-Termination (PCU-End).....	36
8.11.2	APP – Terminate PCU pyrotechnic device scrapping (PCU-End).....	36
8.11.3	APP – Terminate PCU pyrotechnic device scrapping via ACL (PCU-End).....	37
8.12	APP – Terminate system deployment (Sys-End).....	37
<b>9</b>	<b>Service interface (SI) definition between application and OSI layers.....</b>	<b>37</b>
9.1	SI — A_Data.req, A_Data.ind, and A_Data.conf service interface (SI).....	37
9.2	SI — A_Data.req, A_Data.ind, and A_Data.conf service interface (SI) parameter mapping.....	38
9.3	Service interface parameters (SIP).....	39
9.3.1	SIP – General.....	39
9.3.2	SIP – Data type definitions.....	39
9.3.3	SIP – Mtype, message type.....	39
9.3.4	SIP – TAtype, target address type.....	39
9.3.5	SIP – AE, address extension.....	39
9.3.6	SIP – TA, target address.....	39
9.3.7	SIP – SA, source address.....	40
9.3.8	SIP – Length, length of PDU.....	40
9.3.9	SIP – PDU, protocol data unit.....	40
9.3.10	SIP – Result, result.....	40
<b>10</b>	<b>Application layer (AL).....</b>	<b>40</b>
10.1	AL – Applicable ISO 14229-1 UDS functionality.....	40
10.2	AL – PCU timing parameters.....	41
10.3	AL – Authentication.....	41
10.3.1	AL – Requirements specification – PDT authentication.....	41

10.3.2	AL – Requirements specification – Fixed-address PCU/PCU(s) authentication.....	42
10.4	AL – ReadDataByIdentifier – Read PCU hardware deployment method.....	42
10.4.1	AL – Requirements specification – Read PCU hardware deployment method.....	42
10.4.2	AL – Message sequence requirements – Read PcuHardwareDeploymentMethod.....	43
10.4.3	AL – Message sequence example – Read PcuHardwareDeploymentMethod.....	43
10.5	AL – ReadDataByIdentifier – Read NumberOfPcu in vehicle.....	44
10.5.1	AL – Requirements specification – Read NumberOfPcu in vehicle.....	44
10.5.2	AL – Message sequence requirements – Read number of PCUs in vehicle.....	44
10.5.3	AL – Message sequence example – Read NumberOfPcu in vehicle.....	45
10.6	AL – ReadDataByIdentifier – Read PcuAddressInfo.....	45
10.6.1	AL – Requirements specification – Read PcuAddressInfo.....	45
10.6.2	AL – Message sequence requirements – Read PcuAddressInfo of PCU.....	46
10.6.3	AL – Message sequence example – Read PcuAddressInfo of DoCAN PCU.....	46
10.6.4	AL – Message sequence example – Read PcuAddressInfo of DoIP PCU.....	47
10.7	AL – ReadDataByIdentifier – Report VIN from PCU.....	48
10.7.1	AL – Requirements specification – Report VIN from PCU.....	48
10.7.2	AL – Message sequence requirements – Report VIN from PCU.....	48
10.7.3	AL – Message sequence example – Report VIN from PCU.....	48
10.8	AL – ReadDataByIdentifier – Report dismantler information.....	49
10.8.1	AL – Requirements specification – Report dismantler information.....	49
10.8.2	AL – Message sequence requirements – Report dismantler information.....	50
10.8.3	AL – Message sequence example – Report dismantler information.....	50
10.9	AL – ReadDataByIdentifier – Read deployment loop identification table.....	50
10.9.1	AL – Requirements specification – Read deployment loop identification table.....	50
10.9.2	AL – Message sequence requirements – Read deployment loop identification table.....	51
10.9.3	AL – Message sequence example – Read deployment loop identification table.....	52
10.10	AL – DiagnosticSessionControl – safetySystemDiagnosticSession.....	53
10.10.1	AL – Requirements specification – safetySystemDiagnosticSession.....	53
10.10.2	AL – Message sequence requirements – safetySystemDiagnosticSession.....	53
10.10.3	AL – Message sequence example – safetySystemDiagnosticSession.....	53
10.11	AL – TesterPresent.....	54
10.11.1	AL – Requirements specification – TesterPresent.....	54
10.11.2	AL – Message sequence requirements – TesterPresent.....	54
10.11.3	AL – Message sequence example – TesterPresent.....	55
10.12	AL – SecurityAccess.....	55
10.12.1	AL – Requirements specification – SecurityAccess.....	55
10.12.2	AL – Message sequence requirements – SecurityAccess.....	56
10.12.3	AL – Message sequence example – SecurityAccessType = RequestSeed.....	57
10.12.4	AL – Message sequence example – SecurityAccessType = SendDeploymentKey.....	57
10.13	AL – WriteDataByIdentifier – Write dismantler information.....	58
10.13.1	AL – Requirements specification – Write dismantler identification information.....	58
10.13.2	AL – Message sequence requirements – Write dismantler identification information.....	58
10.13.3	AL – Message sequence example – Write dismantler identification information.....	59
10.14	AL – RoutineControl.....	59
10.14.1	AL – Requirements specification – RoutineControl.....	59
10.14.2	AL – Message sequence requirements – RoutineControl.....	61
10.14.3	AL – Message sequence example – ExecuteSPL with SF = startRoutine.....	61
10.14.4	AL – Message sequence example – ExecuteSPL with SF = requestRoutineResult.....	62
10.14.5	AL – Message sequence example – DeployLoopRoutineID with SF = startRoutine.....	62

10.14.6	AL - Message sequence example - DeployLoopRoutineID with SF = requestRoutineResult.....	63
10.15	AL - ACL request deployment sequence (optional).....	64
10.15.1	AL - Requirements specification - ACL request deployment sequence.....	64
10.15.2	AL - Message sequence requirements - ACL request deployment sequence.....	64
10.16	AL - ACL confirm deployment sequence (optional).....	64
10.16.1	AL - Requirements specification - ACL confirm deployment sequence.....	64
10.16.2	AL - Message sequence requirements - ACL confirm deployment sequence (optional).....	65
10.17	AL - ACL terminate deployment sequence (optional).....	65
10.17.1	AL - Requirements specification - ACL terminate deployment sequence (optional).....	65
10.17.2	AL - Message sequence requirements - ACL terminate deployment sequence.....	65
10.18	AL - EcuReset.....	66
10.18.1	AL - Requirements specification - EcuReset.....	66
10.18.2	AL - Message sequence requirements - EcuReset.....	66
10.18.3	AL - Message sequence example - hardReset.....	66
<b>11</b>	<b>Presentation layer (PL).....</b>	<b>67</b>
11.1	PL - Data type UNUM8.....	67
11.2	PL - Data type UNUM16.....	67
11.3	PL - Data type UNUM32.....	67
11.4	PL - Data type UCHAR8.....	67
<b>12</b>	<b>Session layer (SL).....</b>	<b>67</b>
12.1	SL - Timing parameters.....	67
12.2	SL - Error detection.....	68
<b>13</b>	<b>Transport layer (TL).....</b>	<b>68</b>
13.1	TL - DoCAN.....	68
13.2	TL - DoIP.....	68
<b>14</b>	<b>Network layer (NL).....</b>	<b>68</b>
14.1	NL - DoCAN.....	68
14.2	NL - DoIP.....	69
<b>15</b>	<b>Data link layer (DLL).....</b>	<b>69</b>
15.1	DLL - CAN L_Data frame padding bytes.....	69
15.2	DLL - ACL with bidirectional communication.....	69
15.2.1	DLL - tP4_Sender timing specification.....	69
15.2.2	DLL - Bit rate and byte format specification.....	69
<b>16</b>	<b>Physical layer (PHY).....</b>	<b>70</b>
16.1	PHY - Connection between PDT and vehicle PCU(s).....	70
16.2	PHY - Conformance to CAN.....	71
16.3	PHY - Conformance to Ethernet.....	71
16.4	PHY - In-vehicle ACL with bidirectional communication (optional).....	71
16.4.1	PHY - Determine ACLType.....	71
16.4.2	PHY - ACL_CommMode hardware provision.....	71
16.4.3	PHY - ACL_CommMode conformance to ISO 14230-1.....	72
16.5	PHY - In-vehicle ACL with PWM signal (optional).....	74
16.5.1	PHY - Determine ACLType.....	74
16.5.2	PHY - ACL_PWMMode hardware provision.....	74
16.5.3	PHY - ACL PWM signal specification.....	75
<b>Annex A (informative)</b>	<b>Typical configuration of PDT and vehicle PCU.....</b>	<b>79</b>
<b>Annex B (informative)</b>	<b>Network architecture examples.....</b>	<b>81</b>
<b>Bibliography.....</b>		<b>88</b>