

ISO 20683-1:2016-08 (E)

Aircraft ground equipment - Nose gear towbarless towing vehicle (TLTV) - Design, testing and maintenance requirements - Part 1: Main line aircraft

Contents		Page
Foreword		v
Introduction		vi
1	Scope	1
2	Normative references	1
3	Terms and definitions	2
4	Design requirements	4
4.1	General	4
4.2	Towing loads	4
4.3	Pick-up and holding system	5
4.4	Oversteering protection	5
4.5	Nose wheels retention	6
4.6	Safety	6
4.6.1	General	6
4.6.2	Pick-up, release and associated loads	6
4.6.3	Acceleration, deceleration and associated loads	6
4.6.4	Emergency braking	7
4.6.5	Oversteer limits	7
4.6.6	Oversteer alerting and/or protection	7
4.7	Testing operations	8
4.7.1	Snubbing and jerking	8
4.7.2	Vibrations	8
4.7.3	Aircraft braking	8
4.7.4	Stability	8
4.8	Nose gear steering angle limit	9
4.9	Vehicle classification	9
4.10	Placarding	9
5	Testing requirements	9
5.1	General	9
5.2	Testing objectives	9
5.3	Aircraft configuration	10
5.4	Calibration	10
5.4.1	General	10
5.4.2	Aircraft calibration	10
5.4.3	TLTV calibration	13
5.4.4	Oversteering calibration	14
5.5	Testing procedures	14
5.5.1	General	14
5.5.2	Data recording	14
6	Evaluation	15
6.1	Evaluation criteria	15
6.2	Normal condition testing	15
6.2.1	Testing methods	15
6.2.2	Tests number	15
6.2.3	Pushback	15

6.2.4	Maintenance towing	16
6.2.5	Pick-up and release	16
6.2.6	Test evaluation	16
6.3	Stability testing	17
6.4	Extreme condition testing	17
6.4.1	Testing methods	17
6.4.2	Static load tests	17
6.4.3	Maximum acceleration and braking	17
6.5	Oversteer testing	18
7	Maintenance	18
7.1	General	18
7.2	Maintenance manual	19
7.3	Requirements	19
7.4	Calibration	20
7.5	Special tools	20
7.6	Training	20
7.7	Maintenance records	20
8	Quality control	21
9	Traceability and accountability	22
10	Modifications	22
11	Operating instructions	23
	Bibliography	24