

# ISO 22472:2016-09 (E)

## Ships and marine technology - Guidelines for the operation and installation of voyage data recorder (VDR)

---

<b>Contents</b>		<b>Page</b>
Foreword .....		v
<b>1</b>	<b>Scope .....</b>	<b>1</b>
<b>2</b>	<b>Normative references .....</b>	<b>1</b>
<b>3</b>	<b>Terms, definitions and abbreviated terms .....</b>	<b>2</b>
<b>3.1</b>	<b>Terms and definitions .....</b>	<b>2</b>
<b>3.2</b>	<b>Abbreviated terms .....</b>	<b>4</b>
<b>4</b>	<b>VDR interface .....</b>	<b>4</b>
<b>4.1</b>	<b>General .....</b>	<b>4</b>
<b>4.2</b>	<b>Input signals required for VDR interfaces .....</b>	<b>4</b>
<b>4.2.1</b>	<b>Signals defined in applicable parts of IEC 61162 series .....</b>	<b>4</b>
<b>4.2.2</b>	<b>Signals other than IEC 61162 format .....</b>	<b>5</b>
<b>4.2.3</b>	<b>Bridge audible sound captured by microphones .....</b>	<b>6</b>
<b>4.2.4</b>	<b>VHF radio connection .....</b>	<b>6</b>
<b>4.2.5</b>	<b>Radar display connection .....</b>	<b>6</b>
<b>4.2.6</b>	<b>ECDIS display connection .....</b>	<b>6</b>
<b>4.3</b>	<b>Main alarms .....</b>	<b>7</b>
<b>4.4</b>	<b>AIS .....</b>	<b>7</b>
<b>4.5</b>	<b>Bridge alert management interface .....</b>	<b>7</b>
<b>5</b>	<b>Details of interfaces between sensors and VDR .....</b>	<b>7</b>
<b>5.1</b>	<b>General .....</b>	<b>7</b>
<b>5.2</b>	<b>Date and time (IEC 61996-1:2013, 4.6.1) .....</b>	<b>7</b>
<b>5.3</b>	<b>Ship's position (IEC 61996-1:2013, 4.6.2) .....</b>	<b>8</b>
<b>5.4</b>	<b>Speed (IEC 61996-1:2013, 4.6.3) .....</b>	<b>8</b>
<b>5.5</b>	<b>Heading (IEC 61996-1:2013, 4.6.4) .....</b>	<b>8</b>
<b>5.6</b>	<b>Bridge audio (IEC 61996-1:2013, 4.6.5) .....</b>	<b>9</b>
<b>5.7</b>	<b>VHF communication audio (IEC 61996-1:2013, 4.6.6) .....</b>	<b>9</b>
<b>5.8</b>	<b>Radar data-post-display selection (IEC 61996-1:2013, 4.6.7) .....</b>	<b>9</b>
<b>5.9</b>	<b>ECDIS (IEC 61996-1:2013, 4.6.8) .....</b>	<b>11</b>
<b>5.10</b>	<b>Depth (Echo sounder) (IEC 61996-1:2013, 4.6.9) .....</b>	<b>12</b>
<b>5.11</b>	<b>Main alarms on the bridge (IEC 61996-1:2013, 4.6.10) .....</b>	<b>12</b>
<b>5.12</b>	<b>Rudder order and response (IEC 61996-1:2013, 4.6.11) .....</b>	<b>13</b>
<b>5.12.1</b>	<b>Rudder order and response from HCS or TCS (if installed) .....</b>	<b>13</b>
<b>5.12.2</b>	<b>Rudder order and response from steering system .....</b>	<b>13</b>
<b>5.13</b>	<b>Engine and thruster order and response (IEC 61996-1:2013, 4.6.12) .....</b>	<b>14</b>
<b>5.13.1</b>	<b>Engine order and response .....</b>	<b>14</b>
<b>5.13.2</b>	<b>Thruster order and response .....</b>	<b>14</b>
<b>5.14</b>	<b>Hull openings (doors) status (IEC 61996-1:2013, 4.6.13) .....</b>	<b>15</b>
<b>5.15</b>	<b>Watertight and fire door status (IEC 61996-1:2013, 4.6.14) .....</b>	<b>15</b>
<b>5.15.1</b>	<b>Watertight and fire door status .....</b>	<b>15</b>
<b>5.16</b>	<b>Accelerations and hull stresses (IEC 61996-1:2013, 4.6.15) .....</b>	<b>16</b>
<b>5.17</b>	<b>Wind speed and direction (IEC 61996-1:2013, 4.6.16) .....</b>	<b>16</b>
<b>5.18</b>	<b>AIS data (IEC 61996-1:2013, 4.6.17) .....</b>	<b>16</b>
<b>5.19</b>	<b>Rolling motion (IEC 61996-1:2013, 4.6.18) .....</b>	<b>17</b>
<b>5.20</b>	<b>Configuration (IEC 61996-1:2013, 4.6.19) .....</b>	<b>17</b>
<b>5.21</b>	<b>Electronic logbook (IEC 61996-1:2013, 4.6.20) .....</b>	<b>17</b>

<b>6</b>	<b>Installation .....</b>	<b>18</b>
<b>6.1</b>	<b>Required VDR equipment .....</b>	<b>18</b>
<b>6.2</b>	<b>Power supply of the VDR and interfaces .....</b>	<b>18</b>
<b>6.2.1</b>	<b>Power supply from the ship's emergency source of electrical power .....</b>	<b>18</b>
<b>6.2.2</b>	<b>Power supply from the reserve power source .....</b>	<b>18</b>
<b>6.3</b>	<b>Installation of the protective capsule and float free capsule (IEC 61996-1:2013, 5.1.1) .....</b>	<b>18</b>
<b>6.4</b>	<b>Positions of microphones (IEC 61996-1:2013, 4.6.5) .....</b>	<b>19</b>
<b>6.5</b>	<b>Cable connections .....</b>	<b>19</b>
<b>6.6</b>	<b>Ship specific documentation .....</b>	<b>19</b>
<b>6.6.1</b>	<b>Planning and approval documentation .....</b>	<b>19</b>
<b>7</b>	<b>Acceptance test (Commissioning) .....</b>	<b>20</b>
<b>8</b>	<b>Performance Tests .....</b>	<b>20</b>
<b>8.1</b>	<b>General .....</b>	<b>20</b>
<b>8.2</b>	<b>Operational Performance Test (IEC 61996-1:2013, 5.12) .....</b>	<b>20</b>
<b>8.3</b>	<b>Annual Performance Test .....</b>	<b>20</b>
<b>9</b>	<b>Download and playback equipment for investigation authorities .....</b>	<b>21</b>
<b>9.1</b>	<b>General .....</b>	<b>21</b>
<b>9.2</b>	<b>Information for use by an investigation authority (IEC 61996-1) .....</b>	<b>21</b>
	<b>Annex A (informative) Mandatory alarms (IEC 61996-1:2013, Annex B) .....</b>	<b>22</b>
	<b>Annex B (informative) LAN image protocol (IEC 61996-1:2013, Annex E) .....</b>	<b>25</b>
	<b>Annex C (informative) Network for image transmission (IEC 61996-1:2013, Annex F) .....</b>	<b>30</b>
	<b>Annex D (informative) ECDIS display source information (IEC 61996-1:2013, Annex G) .....</b>	<b>33</b>
	<b>Annex E (informative) Manufacturer's documentation (IEC 61996-1:2013, 5.5) .....</b>	<b>38</b>
	<b>Annex F (informative) Performance test report (IMO Circular MSC.1/Circ.1222 Appendix) .....</b>	<b>40</b>
	<b>Bibliography .....</b>	<b>45</b>