ISO/IEC 14165-331:2007-07 (E)

Information technology – Fibre channel – Part 331: Virtual interface (FC-VI)

CONTENTS

FOREWORD 10

Introduction 11

1 Scope 12

2 Normative references 12

3 Terms, definitions and abbreviations 12
- 3.1 FC-VI terms and definitions 12
- 3.2 VI Definitions 14
- 3.3 Abbreviations 15
- 3.4 Editorial conventions 15

4 Structure and concepts 17
- 4.1 Fibre channel structure and concepts 17
- 4.2 FC-VI structure and concepts 17

5 FC-VI protocol overview 21
- 5.1 FC-VI information units 21
- 5.2 FC-VI message transfer operation 21
- 5.2.1 FC-VI message transfer 21
- 5.2.2 FC-VI send message transfer operation 22
- 5.2.3 FC-VI RDMA write message transfer operation 24
- 5.2.4 FC-VI RDMA read message transfer operation 26
- 5.2.5 IU reception at an FC-VI edpoint 27
- 5.3 FC-VI connection setup operation 29
- 5.3.1 FC-VI client-server and peer-peer connection setup 29
- 5.3.2 FC-VI client-server connection setup 29
- 5.3.3 FC-VI Peer-to-Peer Connection Establishment 31
- 5.3.4 FC_VI concurrent peer-to-peer connection setup 33
- 5.3.5 FC-VI Disconnect Operation 35
- 5.4 Exchange ID reuse 36
- 5.5 Sequence ID reuse 37
- 5.6 Frame synonym detection 37
- 5.7 VI message length 38
- 5.8 FC-FS header usage for FC-VI 39
- 5.8.1 FC-FS header usage 39
- 5.8.2 CS_CTL field 39
- 5.8.3 TYPE field 39
- 5.8.4 F_CTL field 39
- 5.8.5 DF_CTL field 39
- 5.8.6 SEQ_CNT field 39
- 5.8.7 Parameter field 40
- 5.9 FC-VI device_header 40
- 5.9.1 FC-VI device_header description 40
- 5.9.2 FCVI_HANDLE field 40
- 5.9.3 FCVI_OPCODE field 41
- 5.9.4 FCVI_FLAGS field 41
- 5.9.4.1 FCVI_FLAGS field description 41
- 5.9.4.2 FCVI_FLAGS for message request IUs 41
- 5.9.4.3 FCVI_FLAGS for message response IUs 42
- 5.9.4.4 FCVI_FLAGS for connect request IUs 42
- 5.9.4.5 FCVI_FLAGS for connect response IUs 43

5.9.4.6 FCVI_FLAGS for disconnect IUs 44
5.9.5 Reserved fields 45
5.9.6 FCVI_MSG_ID field 45
5.9.7 FCVI_PARAMETER field 46
5.9.7.1 FCVI_PARAMETER field format 46
5.9.7.2 Connect response reason codes 48
5.9.7.2.1 Connect response non-error reason codes 48
5.9.7.2.2 Connect response error reason codes 48
5.9.7.3 Message response / disconnect reason codes 48
5.9.7.3.1 Descriptor error reason codes 48
5.9.7.3.2 Remote FC-VI port non-descriptor errors 49
5.9.7.3.3 Reserved for future expansion 50
5.9.7.3.4 Vendor unique reason codes 50
5.9.8 FCVI_RMT_VA field 50
5.9.9 FCVI_RMT_VA_HANDLE field 50
5.9.10 FCVI_TOT_LEN field / FCVI_CONNECTION_ID field 50
6 FC-VI Information Unit (IU) formats 51
6.1 FC-VI IU overview 51
6.2 FCVI_SEND_RQST IU 51
6.2.1 FCVI_SEND_RQST IU description 51
6.2.2 FCVI_SEND_RQST Device_Header information 51
6.3 FCVI_SEND_RESP IU 51
6.3.1 FCVI_SEND_RESP IU description 51
6.3.2 FCVI_SEND_RESP Device_Header information 52
6.4 FCVI_WRITE_RQST IU 52
6.4.1 FCVI_WRITE_RQST IU overview 52
6.4.2 FCVI_WRITE_RQST IU Device_Header information 52
6.5 FCVI_WRITE_RESP IU 53
6.5.1 FCVI_WRITE_RESP IU description 53
6.5.2 FCVI_WRITE_RESP IU Device_Header information 53
6.6 FCVI_READ_RQST IU 53
6.6.1 FCVI_READ_RQST IU description 53
6.6.2 FCVI_READ_RQST IU Device_Header information 53
6.7 FCVI_READ_RESP IU 54
6.7.1 FCVI_READ_RESP IU description 54
6.7.2 FCVI_READ_RESP IU Device_Header information 54
6.8 FCVI_CONNECT_RQST IU 55
6.8.1 FCVI_CONNECT_RQST IU description 55
6.8.2 FCVI_CONNECT_RQST Device_Header information 55
6.8.3 FCVI_CONNECT_RQST Payload Information 55
6.9 FCVI_CONNECT_RESP1 IU 57
6.9.1 FCVI_CONNECT_RESP1 IU description 57
6.9.2 FCVI_CONNECT_RESP1 Device_Header information 57
6.9.3 FCVI_CONNECT_RESP1 Payload Information 58
6.10 FCVI_CONNECT_RESP2 IU 59
6.10.1 FCVI_CONNECT_RESP2 IU description 59
6.10.2 FCVI_CONNECT_RESP2 Device_Header information 59
6.11 FCVI_CONNECT_RESP3 IU 59
6.11.1 FCVI_CONNECT_RESP3 IU description 59
6.11.2 FCVI_CONNECT_RESP3 Device_Header information 59
6.12 FCVI_DISCONNECT_RQST IU 60
6.12.1 FCVI_DISCONNECT_RQST IU description 60

6.12.2 FCVI_DISCONNECT_RQST Device_Header information 60
6.13 FCVI_DISCONNECT_RESP IU 61
6.13.1 FCVI_DISCONNECT_RESP IU description 61
6.13.2 FCVI_DISCONNECT_RESP Device_Header information 61
7 FC-VI Addressing and naming 62
7.1 FC-VI Addressing and naming overview 62
7.2 FCVI_NET_ADDRESS format 62
7.3 FCVI_ATTRIBUTES format 63
7.4 FC-VI address resolution 65
7.5 FARP ELS 66
7.6 Name server queries 67
7.7 Validation of host address to N_Port Identifier mappings 67
7.7.1 Address mapping overview 67
7.7.2 Point-to-point topology 67
7.7.3 Private loop topology 67
7.7.4 Public loop topology 68
7.7.5 Fabric topology 68
8 FC-VI Error detection and recovery 69
8.1 FC-VI error detection and recovery overview 69
8.2 FC-VI endpoint states 69
8.3 FCVI_ULP_TIMEOUT definition 69
8.4 Message transfer error detection and recovery rules 70
8.4.1 Message error detection 70
8.4.2 Message transfer error recovery 70
8.5 Connection setup error detection and recovery rules 71
8.5.1 Connection setup error handling overview 71
8.5.2 Connection setup error detection 71
8.5.3 Connection setup error recovery 71
8.5.4 Connection setup originator retry rules 72
8.6 Disconnect operation error detection and recovery rules 72
8.6.1 Disconnect operation error handling overview 72
8.6.2 Disconnect operation error detection 72
8.6.3 Disconnect operation error recovery rules 73
Annex A (normative) Concurrent matching peer requests example 74
A.1 Overview 74
A.2 Case 1 75
A.3 Case 2 75
A.4 Case 3 76
A.5 Case 4 76
A.6 Case 5 77
A.7 Case 6 78
Annex B (informative) FC-VI message transfer error handling examples 79
B.1 Overview 79
B.2 Message transfer error handling operation 79
B.2.1 Message transfer error handling operation overview 79
B.2.2 Message transfer error definitions 79
B.2.3 Error Detection and Recovery Rule Processing 80
B.2.4 Message responder and message originator error recovery actions 80
B.2.5 Message responder error detection actions 81
B.2.6 Message originator Class 2 error detection actions 83
B.2.6.1 Message originator Class 2 error detection overview 83

B.2.6.2 Message response timeout at message originator 84
B.3 Message transfer error detection and recovery examples 84
B.3.1 Error examples overview 84
B.3.2 Mrcv > Mexp error example 85
B.3.2.1 Mrcv > Mexp example description 85
B.3.2.2 Mrcv > Mexp: In-order fabric and unreliable 85
B.3.2.3 Mrcv > Mexp: In-order fabric and reliable delivery 85
B.3.2.4 Mrcv > Mexp: Out-of-order fabric 86
B.3.3 Mrcv = Mexp error example 86
B.3.3.1 Mrcv = Mexp example description 86
B.3.3.2 Mrcv = Mexp: In-order fabric and unreliable 87
B.3.3.3 Mrcv = Mexp: Out-of-order fabric 87
Annex C (informative) Connection setup error handling examples Overview 89
C.1 Connection setup error handling definitions 89
C.2 Connect request originator and connect request responder rules 89
C.3 Connect request originator rules 89
C.4 Connect request responder rules 91
C.4.1 Connect request responder retry rules 92
C.5 Error detection and recovery examples for connection setup 93
C.5.1 Overview 93
C.5.2 FC-VI connection setup timers 94
C.5.3 VipConnectRequest completion 95
C.5.4 VipConnectAccept completion 95
C.5.5 Enabling message transmission and reception 95
C.5.6 Client timeout of VipConnectRequest 96
C.5.7 Lost FCVI_CONNECT_RQST IU 96
C.5.7.1 Lost FCVI_CONNECT_RQST IU example 96
C.5.7.2 Retried connection setup 97
C.5.8 Lost FCVI_CONNECT_RESP1 IU 98
C.5.9 Lost FCVI_CONNECT_RESP2 IU 99
C.5.9.1 Lost FCVI_CONNECT_RESP2 IU example 99
C.5.9.2 Server timing out connection setup 100
C.5.10 Lost FCVI_CONNECT_RESP3 IU 101
C.5.10.1 Lost FCVI_CONNECT_RESP3 IU example 101
Annex D (informative) Disconnect operation error handling examples 102
D.1 Disconnect operation example description 102
D.2 FC-VI disconnect operation example 103
Annex E (informative) Message streaming for reliable reception 105
Annex F (informative) Enabling Message transmission in the FC-VI NIC 106

Documents for VI Architecture (see Clause 2 for further explanation)
Virtual Interface Architecture Specification, V1.0 (VI-ARCH) 111
Virtual Interface (VI) Architecture Developer’s Guide, V1.0 (VI-DG) 195
Virtual Interface (VI) Architecture Developer’s Guide Error Table Supplement, V1.0 291
IP Version 6 Addressing Architecture, RFC 2373, July 1998 (RFC2373) 321

Table 1 – FC-VI Information unit summary 21
Table 2 – Peer B actions based on connect responses from peer A 36
Table 3 – 16-byte FC-VI device_header 40
Table 4 – 32-byte FC-VI device_header 40
Table 5 – FCVI_FLAGS Bit definitions for message request IUs 41
Table 6 – FCVI_FLAGS Bit definitions for message response IUs 42
Table 7 – FCVI_FLAGS Bit definitions for connect request IUs 42
Table 8 – FC-VI connection mode definition 43
Table 9 – FCVI_FLAGS Bit definitions for connect response IUs 43
Table 10 – FCVI_FLAGS Bit definitions for disconnect IUs 44
Table 11 – FCVI_PARAMETER field for connect response and disconnect IUs 46
Table 12 – Reason code for CONN_STS 47
Table 13 – FCVI_CONNECT_RQST IU payload format 56
Table 14 – FCVI_CONNECT_RESP1 IU Payload Format 58
Table 15 – FCVI_NET_ADDRESS Format 63
Table 16 – FCVI_ATTRIBUTES format 63
Table 17 – Format of FCVI_ATTR_FLAGS in FCVI_ATTRIBUTES 64
Table 18 – FCVI_QOS format 64
Table A.1 – Peer B actions based on connect responses from peer A 74

Figure 1 – FC-VI addressing objects 20
Figure 2 – FC-VI send for Unreliable Delivery or Reliable Delivery 23
Figure 3 – FC-VI send for Reliable Reception 24
Figure 4 – FC-VI RDMA write for Unreliable Delivery or Reliable Delivery 25
Figure 5 – FC-VI RDMA write for Reliable Reception 26
Figure 6 – FC-VI RDMA read for Reliable Reception and Reliable Delivery 27
Figure 7 – Concurrent Receive Streams at a FC-VI Endpoint 28
Figure 8 – FC-VI client-server connection setup 30
Figure 9 – Peer-to-peer connection setup 32
Figure 10 – Peer-to-peer connection setup, concurrent matching peer requests 34
Figure 11 – FC-VI disconnect operation 36
Figure 12 – FC-FS header for send operation 38
Figure A.1 – Case 1 75
Figure A.2 – Case 2 75
Figure A.3 – Case 3 76
Figure A.4 – Case 4 77
Figure A.5 – Case 5 77
Figure A.6 – Case 6 78
Figure B.1 – Mrcv > Mexp 85
Figure B.2 – Mrcv = Mexp 87
Figure C.1 – Client-server connection setup 93
Figure C.2 – Client timeout of VipConnectRequest 96
Figure C.3 – Lost FCVI_CONNECT_RQST IU 97
Figure C.4 – Lost FCVI_CONNECT_RESP1 IU 98
Figure C.5 – Lost FCVI_CONNECT_RESP2 99
Figure C.6 – Lost FCVI_CONNECT_RESP3 IU 101
Figure D.1 – FC-VI disconnect operation 103