

ISO/IEC 29341-8-14:2008-11 (E)

Information technology_ - UPnP Device Architecture_ - Part_ 8-14: Internet Gateway Device Control Protocol_ - Wide Area Network Cable Link Configuration Service

CONTENTS

FOREWORD	4
ORIGINAL UPNP DOCUMENTS (informative)	6
1. Overview and Scope	8
2. Service Modeling Definitions	9
2.1. ServiceType	9
2.2. State Variables	9
2.2.1. CableLinkConfigState	10
2.2.2. LinkType	11
2.2.3. DownstreamFrequency	11
2.2.4. DownstreamModulation	11
2.2.5. UpstreamFrequency	11
2.2.6. UpstreamModulation	11
2.2.7. UpstreamChannelID	11
2.2.8. UpstreamPowerLevel	11
2.2.9. BPIEncryptionEnabled	11
2.2.10. ConfigFile	11
2.2.11. TFTPServer	11
2.2.12. Relationships Between State Variables	11
2.3. Eventing and Moderation	12
2.3.1. Event Model	12
2.4. Actions	13
2.4.1. GetCableLinkConfigInfo	13
2.4.2. GetDownstreamFrequency	14
2.4.3. GetDownstreamModulation	14
2.4.4. GetUpstreamFrequency	15
2.4.5. GetUpstreamModulation	15
2.4.6. GetUpstreamChannelID	16
2.4.7. GetUpstreamPowerLevel	16
2.4.8. GetBPIEncryptionEnabled	17
2.4.9. GetConfigFile	17
2.4.10. GetTFTPServer	18
2.4.11. Non-Standard Actions Implemented by a UPnP Vendor	18
2.4.12. Relationships Between Actions	18
2.4.13. Common Error Codes	18
2.5. Theory of Operation	19
2.5.1. Connection Initiation	19
2.5.2. Deployment Scenarios	22
3. XML Service Description	23
4. Test	26

LIST OF TABLES

Table 1: State Variables	9
Table 1.1: AllowedValueList for CableLinkConfigState	10
Table 1.2: AllowedValueList for LinkType	10
Table 1.3: AllowedValueList for DownstreamModulation	10
Table 1.4: AllowedValueList for UpstreamModulation	10
Table 2: Event Moderation	12
Table 3: Actions	13
Table 4: Arguments for GetCableLinkConfigInfo	13
Table 5: Arguments for Get GetDownstreamFrequency	14
Table 6: Arguments for GetDownstreamModulation	14
Table 7: Arguments for GetUpstreamFrequency	15
Table 8: Arguments for GetUpstreamModulation	15
Table 9: Arguments for GetUpstreamChannelID	16
Table 10: Arguments for GetUpstreamPowerLevel	16
Table 11: Arguments for GetBPIEncryptionEnabled	17
Table 12: Arguments for GetConfigFile	17
Table 13: Arguments for GetTFTPServer	18
Table 14: Common Error Codes	18