ISO/IEC 29341-8-18:2008-11 (E)

Information technology_- UPnP Device Architecture_- Part_8-18: Internet Gateway Device Control Protocol_- Wide Area Network Internet Protocol Connection Service

CONTENTS

FOREWORD 4

ORIGINAL UPNP DOCUMENTS (informative) 6

1. Overview and Scope 8

2. Service Modeling Definitions 9

2.1. ServiceType 9

2.2. State Variables 9

2.2.1. ConnectionType 12
2.2.2. PossibleConnectionTypes 12
2.2.3. ConnectionStatus 12
2.2.4. Uptime 12
2.2.5. LastConnectionError 12
2.2.6. AutoDisconnectTime 12
2.2.7. IdleDisconnectTime 13
2.2.8. WarnDisconnectDelay 13
2.2.9. RSIPAvailable 13
2.2.10. NATEnabled 13
2.2.11. ExternalIPAddress 13
2.2.12. PortMappingNumberOfEntries 13
2.2.13. PortMappingEnabled 13
2.2.14. PortMappingLeaseDuration 13
2.2.15. RemoteHost 13
2.2.16. ExternalPort 14
2.2.17. InternalPort 14
2.2.18. PortMappingProtocol 14
2.2.19. InternalClient 14
2.2.20. PortMappingDescription 14
2.2.21. Relationships Between State Variables 15

2.3. Eventing and Moderation 16

2.3.1. Event Model 16

2.4. Actions 17

2.4.1. SetConnectionType 17
2.4.2. GetConnectionTypeInfo 18
2.4.3. RequestConnection 18
2.4.4. RequestTermination 19
2.4.5. ForceTermination 20
2.4.6. SetAutoDisconnectTime 20
2.4.7. SetIdleDisconnectTime 21
2.4.8. SetWarnDisconnectDelay 21
2.4.9. GetStatusInfo 22
2.4.10. GetAutoDisconnectTime 22
2.4.11. GetIdleDisconnectTime 23
2.4.12. GetWarnDisconnectDelay 23
2.4.13. GetNATRSIPStatus 24
2.4.14. GetGenericPortMappingEntry 24
2.4.15. GetSpecificPortMappingEntry 25
2.4.16. AddPortMapping 26
2.4.17. DeletePortMapping 27
2.4.18. GetExternalIPAddress 28
2.4.19. Non-Standard Actions Implemented by a UPnP Vendor 28
2.4.20. Relationships Between Actions 28
2.4.21. Common Error Codes 28

2.5. Theory of Operation 29
2.5.1. Connection Initiation 29
2.5.2. Connection Termination 30
2.5.3. Connection Scenarios 31
2.5.4. Non-UPnP compliant clients 33
2.5.5. VPN connections 33
3. XML Service Description 34
4. Test 41

LIST OF TABLES

Table 1: State Variables 9
Table 1.1: AllowedValueList for `PossibleConnectionTypes` 10
Table 1.2: AllowedValueList for `ConnectionStatus` 11
Table 1.3: AllowedValueList for `LastConnectionError` 11
Table 1.4: AllowedValueList for `PortMappingProtocol` 11
Table 2: Event Moderation 16
Table 3: Actions 17
Table 4: Arguments for `SetConnectionType` 17
Table 5: Arguments for `GetConnectionTypeInfo` 18
Table 6: Arguments for `SetAutoDisconnectTime` 20
Table 7: Arguments for `SetIdleDisconnectTime` 21
Table 8: Arguments for `SetWarnDisconnectDelay` 21
Table 9: Arguments for `GetStatusInfo` 22
Table 10: Arguments for `GetAutoDisconnectTime` 22
Table 11: Arguments for `GetIdleDisconnectTime` 23
Table 12: Arguments for `GetWarnDisconnectDelay` 23
Table 13: Arguments for `GetNATRSIPStatus` 24
Table 14: Arguments for `GetGenericPortMappingEntry` 24
Table 15: Arguments for `GetSpecificPortMappingEntry` 25
Table 16: Arguments for `AddPortMapping` 26
Table 17: Arguments for `DeletePortMapping` 27
Table 18: Arguments for `GetExternalIPAddress` 28
Table 19: Common Error Codes 28