ISO/IEC 29341-9-11:2008-11 (E)

Information technology_- UPnP Device Architecture_- Part_9-11: Imaging Device Control Protocol_- Feeder Service

CONTENTS

FOREWORD 4

ORIGINAL UPNP DOCUMENTS (informative) 6

1. Overview and Scope 8

2. Service Modeling Definitions 9

2.1. ServiceType 9

2.2. Service State Table 9

2.2.1. Model 9
2.2.2. State 9
2.2.3. FailureCode 10
2.2.4. MorePages 10
2.2.5. FeederMode 10
2.2.6. SheetWidth 10
2.2.7. SheetHeight 11
2.2.8. InputJustification 11
2.2.9. JobID 11
2.2.10. EntireDocument 11
2.2.11. Timeout 11

2.3. Eventing and Moderation 12

2.4. Actions 13

2.4.1. *(void)* Load(JobIDIn, StateOut) 13
2.4.2. *(void)* Eject(JobIDIn, bEntireDocumentIn, StateOut) 14
2.4.3. *(void)* Reset(JobIDIn, StateOut) 14
2.4.4. *(void)* GetState(StateOut, MorePagesOut, FailureCodeOut) 15
2.4.5. *(void)* SetFeederMode(JobIDIn, FeederModeIn) 15
2.4.6. *(void)* GetFeederMode(FeederModeOut) 15
2.4.7. Common Error Codes 16

2.5. Theory of Operation 16

2.5.1. Enhanced Feeder Operation 17

3. XML Service Template for *Feeder:1.0* 18

4. Testing 22

4.1. Syntax Tests 22

LIST OF TABLES

Table 1: State Variables 9
Table 1.1 *allowedValueList for State* 10
Table 1.2 *allowedValueList for FailureCode* 10
Table 1.3 *allowedValueList for FeederMode* 10
Table 1.4 *allowedValueRange for SheetWidth* 10
Table 1.5 *allowedValueRange for SheetHeight* 11
Table 2: Event Moderation 12
Table 3: Action List 13
Table 4: Arguments for Load 13
Table 5: Errors for Load 13
Table 6: Arguments for Eject 14
Table 7: Errors for Eject 14
Table 8: Arguments for Reset 14
Table 9: Errors for Reset 14
Table 10: Arguments for GetState 15
Table 11: Arguments for SetFeederMode 15
Table 12: Errors for SetFeederMode 15
Table 13: Arguments for GetFeederMode 15
Table 14: Common Error Codes 16