

ISO/IEC 29145-2:2014-03 (E)

Information Technology - Wireless Beacon-enabled Energy Efficient Mesh network (WiBEEM) for wireless home network services - Part 2: MAC Layer

| Contents | Page |
|--|------|
| FOREWORD | 5 |
| INTRODUCTION | 6 |
| 1 Scope | 7 |
| 2 Normative reference | 7 |
| 3 Terms, definitions and abbreviations | 7 |
| 3.1 Terms and definitions | 7 |
| 3.2 Abbreviations | 8 |
| 3.3 Conventions | 9 |
| 4 Conformance | 10 |
| 5 Overview of the WiBEEM technology | 10 |
| 6 MAC layer specifications | 10 |
| 6.1 General | 10 |
| 6.2 MAC layer service specifications | 10 |
| 6.2.1 Service overview | 10 |
| 6.2.2 MAC data service | 11 |
| 6.2.3 MAC management service | 17 |
| 6.2.4 Association primitives | 17 |
| 6.2.5 Disassociation primitives | 22 |
| 6.2.6 Beacon notification primitive | 24 |
| 6.2.7 Primitives for reading PIB attributes | 27 |
| 6.2.8 RAP management primitives | 28 |
| 6.2.9 Primitives for orphan notification | 31 |
| 6.2.10 Primitives for resetting the MAC layer | 34 |
| 6.2.11 Primitives for specifying the receiver enable time | 35 |
| 6.2.12 Primitives for channel scanning | 37 |
| 6.2.13 Communication status primitive | 39 |
| 6.2.14 Primitives for writing MAC PIB attributes | 41 |
| 6.2.15 Primitives for updating the superframe configuration | 42 |
| 6.2.16 Primitives for synchronising with a WRC | 45 |
| 6.2.17 Primitives for requesting data from a WRC | 47 |
| 6.3 MAC frame formats | 49 |
| 6.3.1 General | 49 |
| 6.3.2 General MAC frame format | 50 |
| 6.3.3 Beacon frame format | 52 |
| 6.3.4 MAC command frame format | 52 |
| Bibliography | 62 |
| Figure 1 – MAC layer structure | 11 |
| Figure 2 – Message sequence chart describing the MAC data service | 16 |
| Figure 3 – Message sequence chart for association | 22 |
| Figure 4 – Message sequence chart for disassociation | 24 |
| Figure 5 – Message sequence chart for RAP allocation initiated by a device | 31 |
| Figure 6 – Message sequence chart for RAP deallocation initiated by a device and the WMC | 31 |

| | |
|---|----|
| Figure 7 – Beacon lost (orphan notification) message sequence chart | 33 |
| Figure 8 – Message sequence chart for updating the superframe configuration..... | 45 |
| Figure 9 – Message sequence chart for synchronising to a WRC in a beacon-enabled WPAN..... | 47 |
| Figure 10 – Message sequence chart for requesting data from the WRC..... | 49 |
| Figure 11 – General MAC frame format..... | 50 |
| Figure 12 – Beacon frame format..... | 52 |
| | |
| Table 1 – MLDE-DATA.request parameters..... | 12 |
| Table 2 – MLDE-DATA.confirm parameters..... | 13 |
| Table 3 – MLDE-DATA.indication parameters | 14 |
| Table 4 – MLDE-ERASE.request parameters | 15 |
| Table 5 – MLDE-ERASE.confirm parameters | 16 |
| Table 6 – Summary of the primitives accessed through the MLME-SAP | 17 |
| Table 7 – MLME-ASSOCIATE.request parameters..... | 18 |
| Table 8 – MLME-ASSOCIATE.indication parameters | 19 |
| Table 9 – MLME-ASSOCIATE.response parameters | 20 |
| Table 10 – MLME-ASSOCIATE.confirm parameters | 21 |
| Table 11 – MLME-DISASSOCIATE.request parameters | 22 |
| Table 12 – MLME-DISASSOCIATE.indication parameters | 23 |
| Table 13 – MLME-DISASSOCIATE.confirm parameters | 24 |
| Table 14 – MLME-BEACON-NOTIFY.indication parameters | 25 |
| Table 15 – Elements of mesh descriptor | 26 |
| Table 16 – MLME-READ-MIB.request parameters..... | 27 |
| Table 17 – MLME-READ-MIB.confirm parameters..... | 28 |
| Table 18 – MLME- RAP-MANAGEMENT.request parameters..... | 29 |
| Table 19 – MLME-RAP-MANAGEMENT.confirm parameters | 29 |
| Table 20 – MLME-RAP-MANAGEMENT.indication parameters..... | 30 |
| Table 21 – MLME-BEACON-LOST.indication parameters..... | 32 |
| Table 22 – MLME-BEACON-LOST.indication parameters..... | 33 |
| Table 23 – MLME-RESET.request parameters | 34 |
| Table 24 – MLME-RESET.confirm parameters | 35 |
| Table 25 – MLME-RX-ON.request parameters | 35 |
| Table 26 – MLME-RX-ON.confirm parameters | 36 |
| Table 27 – MLME-SCAN.request parameters | 37 |
| Table 28 – MLME-SCAN.confirm parameters | 39 |
| Table 29 – MLME-COMM-RESULT.indication parameters..... | 40 |
| Table 30 – MLME-WRITE-MIB.request parameters | 41 |
| Table 31 – MLME-WRITE-MIB.confirm parameters | 42 |
| Table 32 – MLME-START.request parameters | 43 |
| Table 33 – MLME-START.confirm parameters | 44 |
| Table 34 – MLME-SYNC.request parameters | 45 |
| Table 35 – MLME-SYNC-LOSS.indication parameters | 46 |

| | |
|--|----|
| Table 36 – MLME-INDIRECT-COMM.request parameters | 48 |
| Table 37 – MLME-INDIRECT-COMM.confirm parameters | 48 |
| Table 38 – MAC command frame | 53 |
| Table 39 – Association request command | 53 |
| Table 41 – Association response command | 54 |
| Table 42 – Association status field..... | 55 |
| Table 43 – Disassociation notification command format | 55 |
| Table 44 – Disassociation reason code | 56 |
| Table 45 – Data request command format..... | 57 |
| Table 46 – Mesh ID conflict notification command format..... | 57 |
| Table 47 – Orphan notification command format | 58 |
| Table 48 – Beacon request command format | 58 |
| Table 49 – Co-ordinator realignment command format | 59 |
| Table 50 – CFP request command format | 60 |
| Table 51 – CFP characteristics field format..... | 60 |
| Table 52 – Rate reconfiguration request format | 60 |
| Table 53 – Data rate | 61 |
| Table 54 – Rate reconfiguration request command format | 61 |