Information technology - Wireless Beacon-enabled Energy Efficient Mesh network (WiBEEM) for w ireless home network services - Part 3: NWK Layer

Contents

Page

FOREWORD 4
INTRODUCTION 5
1 Scope 6
2 Normative references 6
3 Terms, definitions and abbreviations 6
3.1 Terms and definitions 6
3.2 Abbreviations 7
3.3 Conventions 8
4 Conformance 8
5 Overview of the WiBEEM technology 8
6 NWK layer specifications 8
6.1 General 8
6.2 NWK layer service specifications 8
6.2.1 Overview 8
6.2.2 NWK data service 9
6.2.3 NWK management service 12
6.2.4 Network formation 14
6.2.5 Allowing devices to join 16
6.2.6 Begin as a router 18
6.2.7 Joining a network 19
6.2.8 Joining a device directly to a network 22
6.2.9 Leaving a network 24
6.2.10 Resetting a device 26
6.2.11 Receiver synchronisation 27
6.2.12 Information base maintenance 30
Bibliography 34

Figure 1 – NWK layer structure 9
Figure 2 – Message sequence chart for resetting the network layer 27
Figure 3 – Message sequence chart for synchronising in a non-beaconing network 30

Table 1 – NLDE-DATA.request parameters 10
Table 2 – NLDE-DATA.confirm parameters 11
Table 3 – NLDE-DATA.indication parameters 12
Table 4 – Summary of primitives used by NWK layer 12
Table 5 – NLME-NETWORK-DISCOVERY.request parameters 13
Table 6 – NLME-WiBEEM-DISCOVERY.confirm paramters 14
Table 7 – Network descriptor information fields 14
Table 8 – NLME-WRC-OPERATING.request parameters 15
Table 9 – NLME-NETWORK-FORMATION.confirm parameters 16
Table 10 – NLME-ALLOW-JOINING.request 17
Table 11 – NLME-ALLOW-JOINING.confirm parameters 17

Table 12 – NLME-SET-SUPERFRAME.request parameters 18
Table 13 – NLME-SET-SUPERFRAME.confirm parameters 19
Table 14 – NLME-JOIN.request parameters 20
Table 15 – NLME-JOIN.indication parameters 21
Table 16 – NLME-JOIN.confirm parameters 22
Table 17 – NLME-DETERMINED-JOIN.request parameters 22
Table 18 – Capability information parameter format 23
Table 19 – NLME-DETERMINED-JOIN.confirm parameters 23
Table 20 – NLME-LEAVE.request parameters 24
Table 21 – NLME-LEAVE.indication parameters 25
Table 22 – NLME-LEAVE.confirm parameters 25
Table 23 – NLME-RESET.confirm parameters 27
Table 24 – NLME-SYNC.request parameters 28
Table 25 – NLME-SYNC.confirm parameters 29
Table 26 – NLME-READ-NIB.request parameters 30
Table 27 – NLME-READ-NIB.confirm parameters 31
Table 28 – NLME-WRITE-NIB.request parameters 32
Table 29 – NLME-WRITE-NIB.confirm parameters 33