

# ISO/IEC 24775-3:2014-10 (E)

## Information technology - Storage management - Part 3: Common Profiles

---

Contents	Page
FOREWORD.....	35
Introduction .....	37
1 Scope .....	39
2 Normative references .....	39
3 Terms, definitions and abbreviations .....	41
3.1 Terms and definitions .....	41
3.2 Abbreviations .....	41
4 Profile introduction.....	42
4.1 Profile overview.....	42
4.1.1 General.....	42
4.1.2 Terminology.....	43
4.2 Format for Profile Specifications .....	43
5 Typographical Conventions .....	46
5.1 Maturity Model.....	46
5.2 Experimental Maturity Level.....	46
5.3 Implemented Maturity Level.....	46
5.4 Stable Maturity Level.....	47
5.5 Finalized Maturity Level .....	47
5.6 Deprecated Material.....	47
6 Recipe overview .....	49
6.1 Recipe concepts.....	49
6.2 Recipe Pseudo Code conventions .....	49
6.2.1 Overview .....	49
6.2.2 General Syntax.....	49
6.2.3 CIM related variable and methods .....	50
6.2.4 Data structure .....	51
6.2.5 Operations.....	51
6.2.6 Control operations .....	52
6.2.7 Functions.....	52
6.2.8 Exception handling .....	53
6.2.9 Built-in functions .....	53
6.2.10 Extrinsic method calls.....	54
7 Generic Target Ports Profile .....	55
7.1 Synopsis.....	55
7.2 Description .....	55
7.3 Implementation.....	55
7.3.1 General.....	55
7.3.2 Modeling SCSI/SB Logical Units .....	57
7.4 Methods of the Profile .....	57
7.4.1 Extrinsic methods .....	57
7.4.2 Intrinsic methods .....	58
7.5 Use Cases.....	58
7.6 CIM Elements.....	58
7.6.1 General.....	58
7.6.2 CIM_DeviceSAPImplementation .....	58
7.6.3 CIM_HostedAccessPoint.....	59
7.6.4 CIM_LogicalPort.....	59
7.6.5 CIM_ProtocolEndpoint .....	59
7.6.6 CIM_SystemDevice (Port).....	60
8 Parallel SCSI (SPI) Target Ports Profile .....	61

8.1	Synopsis.....	61
8.2	Description .....	61
8.3	Implementation.....	61
8.4	Health and Fault Management.....	62
8.5	Methods – Extrinsic Methods of this Subprofile .....	62
8.6	CIM elements .....	62
8.6.1	General.....	62
8.6.2	CIM_DeviceSAPImplementation .....	62
8.6.3	CIM_HostedAccessPoint.....	63
8.6.4	CIM_SCSIProtocolEndpoint .....	63
8.6.5	CIM_SPIPort .....	64
8.6.6	CIM_SystemDevice (Port).....	64
9	FC Target Ports Profile.....	66
9.1	Synopsis.....	66
9.2	Description .....	66
9.3	Implementation.....	66
9.3.1	General.....	66
9.3.2	SMI-S 1.0 backwards compatibility .....	66
9.4	Durable Names and Correlatable IDs of the Subprofile .....	67
9.5	Health and Fault Management.....	67
9.6	Supported Profiles and Packages.....	67
9.7	Extrinsic Methods of this Subprofile .....	67
9.8	Client Considerations and Recipes .....	67
9.9	CIM Elements.....	68
9.9.1	General.....	68
9.9.2	CIM_DeviceSAPImplementation .....	68
9.9.3	CIM_FCPort .....	69
9.9.4	CIM_HostedAccessPoint.....	70
9.9.5	CIM_ProtocolControllerForPort .....	70
9.9.6	CIM_SCSIProtocolEndpoint .....	70
9.9.7	CIM_SystemDevice (Port).....	71
10	iSCSI Target Ports Subprofile .....	72
10.1	Synopsis.....	72
10.2	Description .....	72
10.3	Implementation.....	72
10.3.1	General.....	72
10.3.2	Mapping and Masking considerations .....	74
10.3.3	Settings .....	75
10.3.4	Durable Names and Correlatable IDs of the Subprofile .....	75
10.4	Health and Fault Management.....	75
10.5	Supported Subprofiles and Packages.....	76
10.6	Methods of this Subprofile.....	76
10.6.1	General.....	76
10.6.2	CreateiSCSINode.....	76
10.6.3	DeleteiSCSINode .....	77
10.6.4	CreateiSCSIProtocolEndpoint .....	77
10.6.5	DeleteiSCSIProtocolEndpoint .....	79
10.6.6	BindiSCSIProtocolEndpoint.....	79
10.7	Client Considerations and Recipes .....	80
10.7.1	Discover the iSCSI Target Port capabilities .....	80
10.7.2	Identify the iSCSI Nodes in a target system .....	81
10.7.3	Identify the iSCSI Ports on an given iSCSI node .....	81
10.7.4	Identify the iSCSI sessions existing on an iSCSI node .....	82
10.7.5	Create an iSCSI Target Node on an iSCSI Network Entity .....	83

10.7.6	Create an iSCSI Target Port on an iSCSI target node .....	84
10.7.7	Add a Network Portal to a Target Port .....	85
10.7.8	Determine the health of Nodes in a target system .....	87
10.7.9	Determine the health of a Session on a target system.....	87
10.7.10	Configure the default settings for Sessions created in a target computer system ..	88
10.7.11	Configure default settings for Connections on Network Portals used by an iSCSIProtocolEndpoint.....	89
10.7.12	Get the statistics for a Session on a target system .....	89
10.7.13	Configure Enable/disable header and data digest .....	89
10.8	CIM Elements.....	90
10.8.1	General.....	90
10.8.2	CIM_BindsTo (TCPProtocolEndpoint to IPProtocolEndpoint).....	92
10.8.3	CIM_BindsTo (iSCSIProtocolEndpoint to TCPProtocolEndpoint).....	92
10.8.4	CIM_ConcreteDependency .....	93
10.8.5	CIM_DeviceSAPImplementation (EthernetPort to IPProtocolEndpoint).....	93
10.8.6	CIM_DeviceSAPImplementation (EthernetPort to iSCSIProtocolEndpoint).....	93
10.8.7	CIM_ElementCapabilities (iSCSIConfigurationCapabilities to System).....	94
10.8.8	CIM_ElementCapabilities (iSCSIConfigurationCapabilities to iSCSIConfigurationService).....	94
10.8.9	CIM_ElementSettingData (iSCSIConnectionSettings to TCPProtocolEndpoint).....	94
10.8.10	CIM_ElementSettingData (iSCSIConnectionSettings to iSCSIProtocolEndpoint) ..	95
10.8.11	CIM_ElementSettingData (iSCSIConnectionSettings to SCSIProtocolController) .....	95
10.8.12	CIM_ElementSettingData (iSCSIConnectionSettings to System) .....	95
10.8.13	CIM_ElementSettingData (iSCSIConnectionSettings to iSCSIProtocolEndpoint).....	96
10.8.14	CIM_ElementStatisticalData (iSCSILoginStatistics to SCSIProtocolController) .....	96
10.8.15	CIM_ElementStatisticalData (iSCSIConnectionFailures to SCSIProtocolController) ...	96
10.8.16	CIM_ElementStatisticalData (iSCSIConnectionStatistics to iSCSIConnection).....	97
10.8.17	CIM_EndpointOfNetworkPipe (iSCSIConnection to TCPProtocolEndpoint).....	97
10.8.18	CIM_EndpointOfNetworkPipe (iSCSIConnection to iSCSIProtocolEndpoint) .....	98
10.8.19	CIM_EthernetPort .....	98
10.8.20	CIM_HostedAccessPoint (System to IPProtocolEndpoint) .....	98
10.8.21	CIM_HostedAccessPoint (System to TCPProtocolEndpoint) .....	99
10.8.22	CIM_HostedAccessPoint (System to iSCSIProtocolEndpoint) .....	99
10.8.23	CIM_HostedCollection .....	99
10.8.24	CIM_HostedService .....	100
10.8.25	CIM_IPProtocolEndpoint.....	100
10.8.26	CIM_MemberOfCollection.....	100
10.8.27	CIM_NetworkPipeComposition .....	101
10.8.28	CIM_SAPAvailableForElement .....	101
10.8.29	CIM_SCSIProtocolController .....	101
10.8.30	CIM_SystemDevice (System to EthernetPort).....	102
10.8.31	CIM_SystemDevice (System to SCSIProtocolController).....	102
10.8.32	CIM_SystemSpecificCollection .....	102
10.8.33	CIM_TCPProtocolEndpoint.....	103
10.8.34	CIM_iSCSICapabilities.....	103
10.8.35	CIM_iSCSIConfigurationCapabilities .....	104
10.8.36	CIM_iSCSIConfigurationService .....	104
10.8.37	CIM_iSCSIConnection .....	104
10.8.38	CIM_iSCSIConnectionSettings .....	105
10.8.39	CIM_iSCSILoginStatistics .....	106
10.8.40	CIM_iSCSIProtocolEndpoint .....	106
10.8.41	CIM_iSCSIConnection.....	107
10.8.42	CIM_iSCSIConnectionFailures.....	108
10.8.43	CIM_iSCSIConnectionSettings.....	108
10.8.44	CIM_iSCSIConnectionStatistics .....	109

11	Serial Attached SCSI (SAS) Target Port Subprofile .....	110
11.1	Synopsis.....	110
11.2	Description .....	110
11.2.1	General.....	110
11.2.2	Health and Fault Management .....	111
11.3	Methods .....	111
11.3.1	Extrinsic Methods of this Subprofile .....	111
11.3.2	Intrinsic Methods of this Subprofile .....	111
11.4	Client considerations and Recipes.....	111
11.5	CIM Elements.....	112
11.5.1	General.....	112
11.5.2	CIM_ConcreteComponent.....	112
11.5.3	CIM_DeviceSAPImplementation .....	112
11.5.4	CIM_HostedAccessPoint.....	113
11.5.5	CIM_SASPort.....	113
11.5.6	CIM_SCSIProtocolEndpoint .....	114
11.5.7	CIM_SystemDevice (Port).....	114
11.5.8	CIM_SystemDevice (SAS PHY).....	115
11.5.9	SNIA_SASPHY .....	115
12	Serial ATA (SATA) Target Ports Profile.....	116
12.1	Synopsis.....	116
12.2	Description .....	116
12.2.1	General.....	116
12.2.2	Health and Fault Management .....	117
12.3	Methods of this Subprofile.....	117
12.4	Client considerations and Recipes.....	117
12.5	CIM elements .....	118
12.5.1	General.....	118
12.5.2	CIM_ATAPort .....	118
12.5.3	CIM_ATAProtocolEndpoint .....	119
12.5.4	CIM_DeviceSAPImplementation .....	119
12.5.5	CIM_HostedAccessPoint.....	119
12.5.6	CIM_SystemDevice (Port).....	120
13	SB Target Ports Profile.....	121
13.1	Synopsis.....	121
13.2	Description .....	121
13.3	Implementation.....	121
13.4	Health and Fault Management Consideration.....	122
13.5	Cascading Considerations .....	122
13.6	Methods of the Profile .....	123
13.6.1	Extrinsic Methods of the Profile .....	123
13.6.2	Intrinsic Methods of the Profile .....	123
13.7	Client Considerations and Recipes .....	123
13.8	CIM Elements.....	123
13.8.1	General.....	123
13.8.2	CIM_DeviceSAPImplementation .....	124
13.8.3	CIM_FCPort .....	124
13.8.4	CIM_HostedAccessPoint.....	125
13.8.5	CIM_SystemDevice (Port).....	125
13.8.6	SNIA_SBPProtocolEndpoint.....	125
14	Direct Attach (DA) Ports Profile .....	128
14.1	Description .....	128
14.2	Health and Fault Management.....	128
14.3	Supported Profiles and Packages.....	128

14.4	Extrinsic Methods.....	128
14.5	Client Considerations and Recipes.....	129
14.6	Registered Name and Version.....	129
14.7	CIM Elements.....	129
14.7.1	General.....	129
14.7.2	CIM_DAPort.....	129
14.7.3	CIM_DeviceSAPImplementation.....	130
14.7.4	CIM_HostedAccessPoint.....	130
14.7.5	CIM_SCSIProtocolEndpoint.....	130
14.7.6	CIM_SystemDevice (Port).....	131
15	Generic Initiator Ports Profile.....	132
15.1	Synopsis.....	132
15.2	Description.....	132
15.3	Implementation.....	132
15.3.1	General.....	132
15.3.2	Remote Device Models.....	133
15.3.3	Health and Fault Management Considerations.....	136
15.3.4	Cascading Considerations.....	136
15.4	Methods.....	136
15.4.1	Extrinsic Methods of this Profile.....	136
15.4.2	Intrinsic Methods of this Profile.....	136
15.5	Use Cases.....	136
15.6	CIM Elements.....	137
15.6.1	General.....	137
15.6.2	CIM_ConnectivityCollection.....	137
15.6.3	CIM_DeviceSAPImplementation.....	138
15.6.4	CIM_ElementStatisticalData (Port Statistics).....	138
15.6.5	CIM_HostedAccessPoint (Initiator).....	138
15.6.6	CIM_HostedAccessPoint (Target).....	139
15.6.7	CIM_HostedCollection (Connectivity Collection).....	139
15.6.8	CIM_LogicalPort.....	139
15.6.9	CIM_MemberOfCollection (Connectivity Collection).....	140
15.6.10	CIM_ProtocolEndpoint (Initiator).....	140
15.6.11	CIM_ProtocolEndpoint (Target).....	141
15.6.12	CIM_SystemDevice (Initiator Ports).....	141
15.6.13	SNIA_LogicalPortStatistics.....	142
16	Parallel SCSI (SPI) Initiator Ports Profile.....	143
16.1	Synopsis.....	143
16.2	Description.....	143
16.3	Implementation.....	143
16.3.1	General.....	143
16.3.2	Health and Fault Management Considerations.....	143
16.3.3	Cascading Considerations.....	144
16.4	Methods.....	144
16.4.1	Extrinsic Methods of this Profile.....	144
16.4.2	Intrinsic Methods of this Profile.....	144
16.5	Detailed Use Cases and Recipes.....	144
16.6	CIM Elements.....	144
16.6.1	General.....	144
16.6.2	CIM_ConnectivityCollection.....	145
16.6.3	CIM_DeviceSAPImplementation.....	145
16.6.4	CIM_ElementStatisticalData (Port Statistics).....	146
16.6.5	CIM_HostedAccessPoint (Initiator).....	146
16.6.6	CIM_HostedAccessPoint (Target).....	146

16.6.7	CIM_HostedCollection (Connectivity Collection)	147
16.6.8	CIM_MemberOfCollection (Connectivity Collection)	147
16.6.9	CIM_SCSIInitiatorTargetLogicalUnitPath	148
16.6.10	CIM_SCSIProtocolEndpoint (Initiator)	148
16.6.11	CIM_SCSIProtocolEndpoint (Target)	149
16.6.12	CIM_SPIPort	149
16.6.13	CIM_SystemDevice (Initiator Ports)	150
16.6.14	SNIA_LogicalPortStatistics	150
17	iSCSI Initiator Port Profile	152
17.1	Synopsis	152
17.2	Description	152
17.3	Implementation	152
17.3.1	General	152
17.3.2	Health and Fault Management Considerations	153
17.3.3	Cascading Considerations	153
17.4	Methods	153
17.4.1	Extrinsic Methods of this Profile	153
17.4.2	Intrinsic Methods of this Profile	153
17.5	Detailed Use Cases and Recipes	154
17.6	CIM Elements	154
17.6.1	General	154
17.6.2	CIM_BindsTo (Host Hardware RAID Controller)	155
17.6.3	CIM_DeviceSAPImplementation (IPProtocolEndpoint to EthernetPort)	155
17.6.4	CIM_DeviceSAPImplementation (iSSIPProtocolEndpoint to EthernetPort)	155
17.6.5	CIM_EthernetPort (Host Hardware RAID Controller)	156
17.6.6	CIM_HostedAccessPoint (System to IPProtocolEndpoint)	156
17.6.7	CIM_HostedAccessPoint (System to TCPProtocolEndpoint)	156
17.6.8	CIM_HostedAccessPoint (System to iSCSIProtocolEndpoint)	157
17.6.9	CIM_IPProtocolEndpoint (Host Hardware RAID Controller)	157
17.6.10	CIM_LogicalDevice (Host Hardware RAID Controller)	158
17.6.11	CIM_SystemDevice (System to EthernetPort)	158
17.6.12	CIM_SystemDevice (System to LogicalDevice)	158
17.6.13	CIM_TCPProtocolEndpoint (Host Hardware RAID Controller)	159
17.6.14	CIM_iSCSIProtocolEndpoint (Host Hardware RAID Controller)	159
18	FC Initiator Ports Profile	161
18.1	Synopsis	161
18.2	Description	161
18.3	Implementation	161
18.3.1	General	161
18.3.2	Port Statistics	162
18.3.3	Logical Port Group (FC Node)	162
18.3.4	Health and Fault Management Considerations	163
18.3.5	Cascading Considerations	163
18.4	Methods	163
18.4.1	Extrinsic Methods of this Profile	163
18.4.2	Intrinsic Methods of this Profile	163
18.5	Use Cases – Get the statistics for each FC port	163
18.6	CIM Elements	164
18.6.1	General	164
18.6.2	CIM_ConnectivityCollection	165
18.6.3	CIM_DeviceSAPImplementation	165
18.6.4	CIM_ElementStatisticalData (Port Statistics)	166
18.6.5	CIM_FCPort	166
18.6.6	CIM_FCPortStatistics	168

18.6.7	CIM_HostedAccessPoint (Initiator)	168
18.6.8	CIM_HostedAccessPoint (Target)	169
18.6.9	CIM_HostedCollection (Connectivity Collection)	169
18.6.10	CIM_MemberOfCollection (Connectivity Collection)	170
18.6.11	CIM_ProtocolControllerForPort	170
18.6.12	CIM_SCSIInitiatorTargetLogicalUnitPath	170
18.6.13	CIM_SCSIProtocolController	171
18.6.14	CIM_SCSIProtocolEndpoint (Initiator)	171
18.6.15	CIM_SCSIProtocolEndpoint (Target)	172
18.6.16	CIM_SystemDevice (Initiator Ports)	172
19	SAS Initiator Ports Profile	174
19.1	Synopsis	174
19.2	Description	174
19.2.1	General	174
19.2.2	Health and Fault Management Considerations	175
19.3	Methods of the profile	175
19.4	Client Considerations and Recipes	175
19.5	CIM Elements	175
19.5.1	General	175
19.5.2	CIM_ATAProtocolEndpoint (Initiator)	176
19.5.3	CIM_BindsTo	176
19.5.4	CIM_ConcreteComponent	177
19.5.5	CIM_ConnectivityCollection	177
19.5.6	CIM_DeviceSAPImplementation	177
19.5.7	CIM_ElementStatisticalData (PHY Statistics)	178
19.5.8	CIM_ElementStatisticalData (Port Statistics)	178
19.5.9	CIM_HostedAccessPoint (Initiator)	178
19.5.10	CIM_HostedAccessPoint (Target)	179
19.5.11	CIM_HostedCollection (Connectivity Collection)	179
19.5.12	CIM_MemberOfCollection (Connectivity Collection)	179
19.5.13	CIM_SASPort	180
19.5.14	CIM_SCSIInitiatorTargetLogicalUnitPath	180
19.5.15	CIM_SCSIProtocolEndpoint (Initiator)	181
19.5.16	CIM_SCSIProtocolEndpoint (Target)	181
19.5.17	CIM_SystemDevice (Initiator PHY)	182
19.5.18	CIM_SystemDevice (Initiator Ports)	182
19.5.19	SNIA_LogicalPortStatistics	183
19.5.20	SNIA_SASPHY	183
19.5.21	SNIA_SASPhyStatistics	184
20	ATA Initiator Ports Profile	185
20.1	Synopsis	185
20.2	Description	185
20.3	Implementation	185
20.3.1	General	185
20.3.2	Health and Fault Management Consideration	186
20.3.3	Cascading Considerations	186
20.4	Methods of the Profile	186
20.4.1	Extrinsic Methods of the Profile	186
20.4.2	Intrinsic Methods of this Profile	186
20.5	Client Considerations and Recipes	186
20.6	CIM Elements	187
20.6.1	General	187
20.6.2	CIM_ATAInitiatorTargetLogicalUnitPath	187
20.6.3	CIM_ATAPort	188

20.6.4	CIM_ATAProtocolEndpoint (Initiator)	188
20.6.5	CIM_ATAProtocolEndpoint (Target)	189
20.6.6	CIM_ConnectivityCollection	190
20.6.7	CIM_DeviceSAPImplementation	190
20.6.8	CIM_ElementStatisticalData (Port Statistics)	190
20.6.9	CIM_HostedAccessPoint (Initiator)	191
20.6.10	CIM_HostedAccessPoint (Target)	191
20.6.11	CIM_HostedCollection (Connectivity Collection)	191
20.6.12	CIM_MemberOfCollection (Connectivity Collection)	192
20.6.13	CIM_SystemDevice (Initiator Ports)	192
20.6.14	SNIA_LogicalPortStatistics	193
21	FC-SB-x Initiator Ports Profile	194
21.1	Synopsis	194
21.2	Description	194
21.3	Implementation	194
21.3.1	General	194
21.3.2	Health and Fault Management Considerations	195
21.3.3	Cascading Considerations	195
21.4	Methods	195
21.4.1	Extrinsic Methods of the Profile	195
21.4.2	Intrinsic Methods of this Profile	195
21.5	Client Considerations and Recipes	195
21.6	CIM Elements	196
21.6.1	General	196
21.6.2	CIM_ConnectivityCollection	196
21.6.3	CIM_DeviceSAPImplementation	197
21.6.4	CIM_ElementStatisticalData (Port Statistics)	197
21.6.5	CIM_FCPort	198
21.6.6	CIM_HostedAccessPoint (Initiator)	199
21.6.7	CIM_HostedAccessPoint (Target)	199
21.6.8	CIM_HostedCollection (Connectivity Collection)	199
21.6.9	CIM_MemberOfCollection (Connectivity Collection)	200
21.6.10	CIM_SystemDevice (Initiator Ports)	200
21.6.11	SNIA_LogicalPortStatistics	200
21.6.12	SNIA_SBInitiatorTargetLogicalUnitPath	201
21.6.13	SNIA_SBProtocolEndpoint (Initiator)	201
21.6.14	SNIA_SBProtocolEndpoint (Target)	202
22	Backend Ports Subprofile	203
23	FCoE Initiator Ports Profile	204
23.1	Synopsis	204
23.2	Description	204
23.3	Implementation	204
23.3.1	General	204
23.3.2	Relationship to Storage HBA Profile	205
23.3.3	Optional target model	205
23.3.4	Port Statistics	205
23.3.5	Logical Port Group (FC Node)	205
23.3.6	Health and Fault Management Considerations	206
23.3.7	Cascading Considerations	206
23.4	Methods	206
23.4.1	Extrinsic Methods of this Profile	206
23.4.2	Intrinsic Methods of this Profile	206
23.5	Detailed Use Cases and Recipes	207
23.6	CIM Elements	207

23.6.1	General.....	207
23.6.2	CIM_ConnectivityCollection .....	208
23.6.3	CIM_DeviceSAPImplementation .....	208
23.6.4	CIM_ElementStatisticalData (Port Statistics) .....	209
23.6.5	CIM_EthernetPort.....	209
23.6.6	CIM_FCPort .....	209
23.6.7	CIM_FCPortStatistics .....	210
23.6.8	CIM_HostedAccessPoint (Initiator) .....	211
23.6.9	CIM_HostedAccessPoint (Target).....	212
23.6.10	CIM_HostedCollection (Connectivity Collection).....	212
23.6.11	CIM_HostedCollection (FC Node).....	212
23.6.12	CIM_HostedDependency (NetworkPort to FCPort) .....	213
23.6.13	CIM_LogicalPortGroup.....	213
23.6.14	CIM_MemberOfCollection (Connectivity Collection).....	213
23.6.15	CIM_MemberOfCollection (FC Node).....	214
23.6.16	CIM_ProtocolEndpoint (Initiator) .....	214
23.6.17	CIM_ProtocolEndpoint (Target) .....	215
23.6.18	CIM_SCSIInitiatorTargetLogicalUnitPath.....	215
23.6.19	CIM_SCSIProtocolEndpoint (Initiator).....	216
23.6.20	CIM_SCSIProtocolEndpoint (Target).....	216
23.6.21	CIM_SystemDevice (Ethernet Port).....	217
23.6.22	CIM_SystemDevice (Initiator Ports).....	217
24	Access Points Subprofile.....	218
24.1	Description .....	218
24.2	Health and Fault Management Considerations.....	219
24.3	Cascading Considerations .....	219
24.4	Supported Subprofiles and Packages.....	219
24.5	Methods of this Profile.....	219
24.6	Client Considerations and Recipes.....	220
24.7	Registered Name and Version .....	220
24.8	CIM Elements.....	220
24.8.1	General.....	220
24.8.2	CIM_HostedAccessPoint.....	220
24.8.3	CIM_RemoteServiceAccessPoint .....	220
24.8.4	CIM_SAPAvailableForElement .....	221
25	Cascading Subprofile .....	222
25.1	Introduction to cascading subprofile.....	222
25.2	Description .....	222
25.2.1	Overview .....	222
25.2.2	Instance Diagrams .....	223
25.3	Health and Fault Management Considerations.....	229
25.3.1	Reporting Health of Leaf Systems, Resources and Object Managers .....	229
25.3.2	Cascading Indications of Health.....	230
25.4	Cascading Considerations .....	230
25.5	Supported Subprofiles and Packages.....	230
25.6	Methods of this Subprofile.....	230
25.6.1	General.....	230
25.6.2	Allocate.....	230
25.6.3	Deallocate .....	231
25.7	Client Considerations and Recipes.....	232
25.7.1	Recipe MPCP01: Determining Resources used by cascading Profiles.....	232
25.7.2	Recipe MPCP02: Monitoring the existence of Cascading Profiles.....	232
25.7.3	OPTIONAL: Recipe MPCP03: Allocation of Leaf Resources .....	232
25.7.4	OPTIONAL: Recipe MPCP04: Deallocation of Leaf Resources.....	232

25.7.5	Recipe MPCP05: Monitoring the existence of “Stitching” between Profiles .....	232
25.7.6	Supported SNIA_CascadingCapabilities Patterns .....	232
25.8	Registered Name and Version .....	232
25.9	CIM Elements.....	233
25.9.1	General.....	233
25.9.2	CIM_ComputerSystem (Leaf System).....	235
25.9.3	CIM_Dependency (Object Managers).....	235
25.9.4	CIM_Dependency (Profile to Object Manager) .....	236
25.9.5	CIM_Dependency (Systems) .....	236
25.9.6	CIM_ElementCapabilities .....	236
25.9.7	CIM_ElementConformsToProfile (Leaf) .....	237
25.9.8	CIM_HostedCollection (Allocated Resources) .....	237
25.9.9	CIM_HostedCollection (Remote Resources) .....	238
25.9.10	CIM_HostedService (Allocation Service) .....	238
25.9.11	CIM_HostedService (Object Manager) .....	239
25.9.12	CIM_LogicalDisk .....	239
25.9.13	CIM_LogicalIdentity (General) .....	240
25.9.14	CIM_LogicalIdentity (LogicalDisk).....	241
25.9.15	CIM_LogicalIdentity (StorageVolume) .....	241
25.9.16	CIM_MemberOfCollection (Allocated Resources) .....	241
25.9.17	CIM_MemberOfCollection (Remote Resources).....	242
25.9.18	CIM_Namespace (Leaf).....	242
25.9.19	CIM_NamespaceInManager (Leaf).....	243
25.9.20	CIM_ObjectManager (Leaf).....	243
25.9.21	CIM_RegisteredProfile (Leaf).....	243
25.9.22	CIM_RemoteServiceAccessPoint (Leaf).....	244
25.9.23	CIM_SAPAvailableForElement .....	244
25.9.24	CIM_StorageVolume.....	245
25.9.25	CIM_SystemDevice (Leaf Devices) .....	246
25.9.26	SNIA_AllocatedResources .....	246
25.9.27	SNIA_AllocationService .....	247
25.9.28	SNIA_CascadingCapabilities .....	248
25.9.29	SNIA_RemoteResources .....	248
26	Health Package .....	250
26.1	Description .....	250
26.1.1	General.....	250
26.1.2	Error Reporting Mechanism .....	250
26.1.3	Event Reporting Mechanism .....	251
26.1.4	Standard Events.....	251
26.1.5	Reporting Health .....	252
26.1.6	Computer System Operational Status .....	252
26.1.7	Event Reporting.....	253
26.1.8	Fault Region .....	253
26.1.9	RelatedElementCausingError.....	253
26.1.10	HealthState .....	254
26.2	Health and Fault Management Considerations.....	254
26.3	Cascading Considerations .....	254
26.4	Supported Subprofiles and Packages.....	254
26.5	Client Considerations and Recipes .....	254
26.6	Registered Name and Version .....	254
26.7	CIM Elements.....	254
26.7.1	General.....	254
26.7.2	CIM_ComputerSystem .....	255
26.7.3	CIM_LogicalDevice .....	255

26.7.4	CIM_RelatedElementCausingError .....	256
27	Job Control Subprofile .....	257
27.1	Description .....	257
27.1.1	General.....	257
27.1.2	Instance Diagram .....	257
27.1.3	MethodResult .....	258
27.1.4	OperationalStatus for Jobs.....	259
27.1.5	JobState for Jobs .....	259
27.1.6	Determining How Long a Job Remains after Execution .....	260
27.2	Health and Fault Management.....	260
27.3	Cascading Considerations .....	260
27.4	Support Subprofiles and Packages.....	260
27.5	Methods of the Profile .....	261
27.5.1	Job Modification .....	261
27.5.2	Getting Error Conditions from Jobs .....	261
27.5.3	Suspending, Killing or Terminating a Job.....	261
27.6	Client Considerations and Recipes .....	262
27.7	Registered Name and Version .....	263
27.8	CIM Elements.....	263
27.8.1	General.....	263
27.8.2	CIM_AffectedJobElement.....	264
27.8.3	CIM_AssociatedJobMethodResult .....	264
27.8.4	CIM_ConcreteJob .....	264
27.8.5	CIM_MethodResult.....	266
27.8.6	CIM_OwningJobElement.....	267
28	Location Subprofile.....	268
28.1	Description .....	268
28.1.1	General.....	268
28.1.2	Instance Diagram .....	268
28.2	Health and Fault Management Considerations.....	268
28.3	Cascading Considerations .....	268
28.4	Supported Subprofiles and Packages.....	268
28.5	Methods of the Profile .....	268
28.6	Client Considerations and Recipes .....	268
28.7	Registered Name and Version .....	268
28.8	CIM Elements.....	269
28.8.1	General.....	269
28.8.2	CIM_Location .....	269
28.8.3	CIM_PhysicalElementLocation.....	269
29	Extra Capacity Set Subprofile.....	270
30	Cluster Subprofile .....	271
31	Multiple Computer System Subprofile .....	272
31.1	Description .....	272
31.1.1	General.....	272
31.1.2	Top Level System.....	272
31.1.3	Non-Top-Level Systems .....	273
31.1.4	Types of RedundancySets .....	273
31.1.5	Multiple Tiers of Systems .....	273
31.1.6	Associations between ComputerSystems and other Logical Elements.....	274
31.1.7	Associations between ComputerSystems and PhysicalPackages and Products..	275
31.1.8	Storage Systems without Multiple Systems .....	276
31.1.9	Durable Names and Correlatable IDs of the Subprofile .....	276
31.2	Health and Fault Management Considerations.....	276
31.3	Cascading Considerations .....	276

31.4	Supported Subprofiles and Packages.....	276
31.5	Methods of the Profile .....	276
31.6	Client Considerations and Recipes .....	276
	31.6.1 General.....	276
	31.6.2 Find Top-level Computer Systems .....	276
	31.6.3 Find the Top-level Computer System for any LogicalDevice.....	276
31.7	Registered Name and Version .....	279
31.8	CIM Elements.....	279
	31.8.1 General.....	279
	31.8.2 CIM_ComponentCS .....	279
	31.8.3 CIM_ComputerSystem (Non-Top-Level System).....	280
	31.8.4 CIM_ConcretelIdentity.....	280
	31.8.5 CIM_IsSpare .....	280
	31.8.6 CIM_MemberOfCollection .....	281
	31.8.7 CIM_RedundancySet .....	281
32	Physical Package Package .....	282
32.1	Description .....	282
	32.1.1 General.....	282
	32.1.2 Well Defined Subcomponents .....	282
	32.1.3 Multiple Product Identities .....	283
32.2	Health and Fault Management Considerations.....	284
32.3	Cascading Considerations .....	284
32.4	Supported Subprofiles and Packages.....	284
32.5	Methods of this Profile.....	284
32.6	Client Considerations and Recipes .....	284
	32.6.1 Find Asset Information .....	284
	32.6.2 Finding Product information .....	284
	32.6.3 Finding Asset information.....	285
32.7	Registered Name and Version .....	285
32.8	CIM Elements.....	285
	32.8.1 General.....	285
	32.8.2 CIM_Container .....	285
	32.8.3 CIM_LogicalIdentity.....	286
	32.8.4 CIM_PhysicalElementLocation.....	286
	32.8.5 CIM_PhysicalPackage (Component) .....	287
	32.8.6 CIM_PhysicalPackage (System) .....	287
	32.8.7 CIM_Product (Component) .....	288
	32.8.8 CIM_Product (System) .....	288
	32.8.9 CIM_ProductParentChild.....	289
	32.8.10CIM_ProductPhysicalComponent (Component) .....	289
	32.8.11CIM_ProductPhysicalComponent (System).....	289
	32.8.12CIM_SystemPackaging (Component).....	290
	32.8.13CIM_SystemPackaging (System) .....	290
33	Power Supply Profile .....	291
33.1	Synopsis.....	291
33.2	Description .....	291
33.3	Implementation.....	291
	33.3.1 General.....	291
	33.3.2 Health and Fault Management Consideration.....	291
	33.3.3 Cascading Considerations .....	291
33.4	Methods .....	291
33.5	Use Cases.....	291
33.6	CIM Elements.....	292
	33.6.1 General.....	292

33.6.2	CIM_ElementCapabilities .....	292
33.6.3	CIM_IsSpare .....	293
33.6.4	CIM_MemberOfCollection .....	294
33.6.5	CIM_OwningCollectionElement.....	294
33.6.6	CIM_PowerSupply.....	294
33.6.7	CIM_RedundancySet .....	295
33.6.8	CIM_SuppliesPower .....	296
33.6.9	CIM_SystemDevice.....	296
34	Fan Profile .....	297
34.1	Synopsis.....	297
34.2	Description .....	297
34.3	Implementation.....	297
34.3.1	Health and Fault Management Consideration.....	297
34.3.2	Cascading Considerations .....	297
34.4	Methods .....	297
34.5	Use Cases.....	297
34.6	CIM Elements.....	298
34.6.1	General.....	298
34.6.2	CIM_AssociatedCooling .....	298
34.6.3	CIM_AssociatedSensor .....	299
34.6.4	CIM_ElementCapabilities .....	299
34.6.5	CIM_EnabledLogicalElementCapabilities .....	299
34.6.6	CIM_Fan.....	300
34.6.7	CIM_IsSpare .....	301
34.6.8	CIM_MemberOfCollection .....	301
34.6.9	CIM_NumericSensor .....	301
34.6.10	CIM_OwningCollectionElement .....	302
34.6.11	CIM_RedundancySet .....	302
34.6.12	CIM_Sensor .....	303
34.6.13	CIM_SystemDevice.....	303
35	Sensors Profile .....	304
35.1	Synopsis.....	304
35.2	Description .....	304
35.3	Implementation.....	304
35.3.1	General.....	304
35.3.2	Health and Fault Management Consideration.....	304
35.3.3	Cascading Considerations .....	304
35.4	Methods .....	304
35.5	Use Cases.....	304
35.6	CIM Elements.....	304
35.6.1	General.....	304
35.6.2	CIM_AssociatedSensor .....	305
35.6.3	CIM_ElementCapabilities .....	305
35.6.4	CIM_EnabledLogicalElementCapabilities .....	306
35.6.5	CIM_NumericSensor .....	306
35.6.6	CIM_Sensor .....	307
35.6.7	CIM_SystemDevice.....	308
36	Base Server Profile.....	310
36.1	Synopsis.....	310
36.2	Description .....	310
36.3	Implementation.....	310
36.3.1	General.....	310
36.3.2	HBA Instrumentation .....	311
36.3.3	Host Hardware RAID Instrumentation .....	311

36.3.4	Storage Enclosure Instrumentation .....	311
36.3.5	Health and Fault Management Consideration .....	311
36.3.6	Cascading Considerations .....	311
36.4	Methods .....	311
36.5	Use Cases.....	311
36.6	CIM Elements.....	311
36.6.1	General.....	311
36.6.2	CIM_ComputerSystem .....	312
36.6.3	CIM_ComputerSystemPackage .....	312
36.6.4	CIM_ElementCapabilities .....	313
36.6.5	CIM_EnabledLogicalElementCapabilities .....	313
36.6.6	CIM_HostedService .....	313
36.6.7	CIM_PhysicalPackage .....	314
36.6.8	CIM_ServiceAffectsElement.....	315
36.6.9	CIM_TimeService.....	315
37	Media Access Device Profile .....	316
37.1	Synopsis.....	316
37.2	Description .....	316
37.2.1	General.....	316
37.2.2	Location Indicator .....	316
37.2.3	Media Access Device Online/Offline .....	316
37.3	Implementation.....	317
37.3.1	Health and Fault Management Consideration .....	317
37.3.2	Cascading Considerations .....	317
37.3.3	Hot swap insertion or Removal of Drives .....	318
37.4	Methods .....	318
37.4.1	Request State Change .....	318
37.5	Use Cases.....	318
37.6	CIM Elements.....	318
37.6.1	General.....	318
37.6.2	CIM_EnabledLogicalElementCapabilities .....	319
37.6.3	CIM_HostedAccessPoint.....	319
37.6.4	CIM_MediaAccessDevice .....	319
37.6.5	CIM_PhysicalPackage .....	320
37.6.6	CIM_ProtocolEndpoint .....	320
37.6.7	CIM_Realizes .....	321
37.6.8	CIM_SAPAvailableForElement .....	321
37.6.9	CIM_SystemDevice.....	321
38	Storage Enclosure Profile.....	323
38.1	Synopsis.....	323
38.2	Description .....	323
38.2.1	General.....	323
38.2.2	Guidelines related to Referencing Profiles .....	323
38.2.3	Examples of Storage Enclosure Configurations .....	325
38.3	Implementation.....	326
38.3.1	Health and Fault Management Consideration .....	326
38.3.2	Cascading Considerations .....	326
38.3.3	Enclosure Elements .....	326
38.3.4	Storage Elements .....	326
38.3.5	Physical Assets .....	327
38.4	Methods .....	328
38.4.1	Extrinsic Methods of the Profile .....	328
38.4.2	Intrinsic Methods of this Profile .....	329
38.5	Use Cases.....	329

38.6	CIM Elements.....	329
38.6.1	General.....	329
38.6.2	CIM_ConfigurationReportingService .....	329
38.6.3	CIM_HostedService .....	330
39	Software Subprofile .....	331
39.1	Description .....	331
39.2	Health and Fault Management Considerations.....	331
39.3	Cascading Considerations .....	331
39.4	Supported Subprofiles, and Packages.....	331
39.5	Methods of the Profile .....	331
39.6	Client Considerations and Recipes .....	332
39.7	Registered Name and Version .....	332
39.8	CIM Elements.....	332
39.8.1	General.....	332
39.8.2	CIM_InstalledSoftwareIdentity.....	332
39.8.3	CIM_SoftwareIdentity .....	332
40	Software Inventory Profile .....	334
40.1	Synopsis.....	334
40.2	Description .....	334
40.2.1	General.....	334
40.2.2	Relationship to the SMI-S Software Profile .....	334
40.3	Implementation.....	335
40.3.1	General.....	335
40.3.2	Software Installation and Update .....	335
40.3.3	Health and Fault Management Consideration.....	335
40.3.4	Cascading Considerations .....	335
40.4	Methods .....	335
40.5	Use Cases.....	335
40.6	CIM Elements.....	335
40.6.1	General.....	335
40.6.2	CIM_ElementSoftwareIdentity.....	336
40.6.3	CIM_HostedAccessPoint.....	336
40.6.4	CIM_HostedCollection.....	337
40.6.5	CIM_InstalledSoftwareIdentity.....	337
40.6.6	CIM_MemberOfCollection .....	337
40.6.7	CIM_OrderedComponent .....	337
40.6.8	CIM_OrderedDependency .....	338
40.6.9	CIM_SAPAvailableForElement .....	338
40.6.10	CIM_SoftwareIdentity.....	338
40.6.11	CIM_SoftwareIdentityResource .....	339
40.6.12	CIM_SystemSpecificCollection .....	339
41	Server Profile.....	341
41.1	Description .....	341
41.1.1	Model Overview.....	341
41.1.2	Use of model fields to Populate the SLP template .....	341
41.1.3	Support for Indications .....	343
41.1.4	Security Background .....	343
41.2	Health and Fault Management.....	343
41.3	Cascading Considerations .....	343
41.4	Supported Subprofiles and Packages.....	343
41.5	Methods of the Profile .....	343
41.6	Client Considerations and Recipes – Segregate a SAN Device Type .....	343
41.7	Registered Name and Version .....	345
41.8	CIM Elements.....	345

41.8.1	General	345
41.8.2	CIM_CIMXMLCommunicationMechanism	346
41.8.3	CIM_CommMechanismForManager	346
41.8.4	CIM_HostedAccessPoint	347
41.8.5	CIM_HostedService	347
41.8.6	CIM_Namespace	347
41.8.7	CIM_NamespaceInManager	348
41.8.8	CIM_ObjectManager	348
41.8.9	CIM_ObjectManagerCommunicationMechanism	349
41.8.10	CIM_System	350
42	Profile Registration Profile	351
42.1	Synopsis	351
42.2	Description	351
42.3	Implementation	351
42.3.1	General	351
42.3.2	ElementConformsToProfile Association	352
42.3.3	Associations between Autonomous and Component Profile	353
42.3.4	The SMI-S Registered Profile	353
42.3.5	Health and Fault Management Consideration	355
42.3.6	Cascading Considerations	355
42.4	Methods	355
42.5	Use Cases	355
42.5.1	Using the CIM Server Model to Determine SNIA Profiles Supported	355
42.5.2	Recipe Assumptions	356
42.5.3	Find Servers Supporting a Given Profile	356
42.5.4	Enumerate Profiles Supported by a Given CIM Server	358
42.5.5	Identify the ManagedElement Defined by a Profile	360
42.5.6	Determine the SNIA Version of a Profile	360
42.5.7	Find all Profiles on a Server	361
42.6	CIM Elements	362
42.6.1	General	362
42.6.2	CIM_ElementConformsToProfile (Associates Domain object (e.g. System) to RegisteredProfile)	363
42.6.3	CIM_ElementConformsToProfile (Associates RegisteredProfiles for SMI-S and domain profiles)	363
42.6.4	CIM_ElementSoftwareIdentity (Profile and SW identity)	364
42.6.5	CIM_ElementSoftwareIdentity (Subprofile and SW identity)	364
42.6.6	CIM_Product	364
42.6.7	CIM_ProductSoftwareComponent	364
42.6.8	CIM_ReferencedProfile	365
42.6.9	CIM_RegisteredProfile (Domain Registered Profile)	365
42.6.10	CIM_RegisteredProfile (The SMI-S Registered Profile)	366
42.6.11	CIM_RegisteredSubProfile	367
42.6.12	CIM_SoftwareIdentity	367
42.6.13	CIM_SubProfileRequiresProfile	368
43	Indication Profile	369
43.1	Description	369
43.1.1	General	369
43.1.2	IndicationFilter Names	371
43.1.3	Basic Indication Classes and Association	371
43.1.4	Life Cycle Indications	373
43.1.5	AlertIndications	374
43.1.6	Indication Delivery	375
43.1.7	Instrumentation Requirements	375

43.2	Health and Fault Management Considerations.....	379
43.2.1	Elements Reporting Health .....	379
43.2.2	Health State Transformations and Dependencies.....	379
43.2.3	Standard Errors Produced.....	379
43.2.4	Cause and effect associations .....	379
43.2.5	Indication Correlation .....	379
43.3	Cascading Considerations .....	379
43.4	Supported Profiles, Subprofiles and Packages.....	379
43.5	Methods of the Profile .....	379
43.5.1	Extrinsic Methods of the Profile.....	379
43.5.2	Intrinsic Methods of the Profile .....	379
43.6	Client Considerations and Recipes .....	383
43.6.1	Use of Profile Specific Recipes .....	383
43.6.2	General Client Considerations .....	383
43.6.3	Discovery of Implementation variations.....	383
43.6.4	Client Defined Filters .....	384
43.6.5	Creation of IndicationFilter and ListenerDestination Instances .....	384
43.6.6	Creation of IndicationSubscription Instances .....	384
43.6.7	Determine if the indication subscription requested already exists.....	384
43.6.8	Listenable Instance Notification.....	385
43.6.9	Life Cycle Event Subscription Description.....	385
43.6.10	Subscription for alert indications .....	386
43.6.11	Listenable Interface Modification Notification.....	386
43.6.12	Subscribe for Lifecycle Events where OperationalStatus Changes.....	386
43.7	Registered Name and Version .....	387
43.8	CIM Elements.....	387
43.8.1	General.....	387
43.8.2	CIM_AlertIndication .....	387
43.8.3	CIM_IndicationFilter (client defined).....	389
43.8.4	CIM_IndicationFilter (pre-defined).....	390
43.8.5	CIM_IndicationSubscription.....	391
43.8.6	CIM_InstCreation .....	392
43.8.7	CIM_InstDeletion .....	392
43.8.8	CIM_InstModification.....	393
43.8.9	CIM_ListenerDestinationCIMXML (Indication Handler).....	394
44	Experimental Indication Profile .....	395
44.1	Description .....	395
44.1.1	General.....	395
44.1.2	Basic Indication Classes and Association .....	396
44.1.3	AlertingManagedElement encoding in AlertIndication Instances .....	396
44.1.4	Instrumentation Requirements .....	396
44.1.5	Semi-Fixed Client Specific Indication Filters .....	399
44.1.6	Filter Collections.....	400
44.1.7	Indication Configuration Services .....	403
44.2	Fault Management Considerations .....	405
44.2.1	Indication Correlation .....	405
44.3	Cascading Considerations .....	406
44.4	Supported Profiles, Subprofiles and Packages.....	406
44.5	Methods of the Profile .....	407
44.5.1	Extrinsic Methods of the Profile.....	407
44.5.2	Intrinsic Methods of the Profile .....	410
44.6	Client Considerations and Recipes .....	413
44.6.1	General.....	413
44.6.2	Testing a Listener Destination.....	413

44.6.3	Discovering predefined IndicationFilters of an implementation .....	414
44.6.4	Creating a subscription to a predefined IndicationFilter .....	415
44.6.5	Creating a client defined indication and subscription .....	415
44.6.6	Creating a semi-fixed indication filter .....	416
44.6.7	Creating a FilterCollection .....	416
44.7	Registered Name and Version .....	417
44.8	CIM Elements.....	417
44.8.1	General.....	417
44.8.2	CIM_AlertIndication .....	418
44.8.3	CIM_ElementCapabilities (Indication Config Service to Capabilities) .....	420
44.8.4	CIM_FilterCollection (Client Defined) .....	420
44.8.5	CIM_FilterCollectionSubscription (Filter Collection Subscription) .....	420
44.8.6	CIM_HostedCollection (Hosted Filter Collection) .....	421
44.8.7	CIM_HostedService (Indication Config Service to System) .....	421
44.8.8	CIM_IndicationFilter (client defined).....	422
44.8.9	CIM_IndicationFilter (pre-defined).....	423
44.8.10	CIM_IndicationSubscription .....	424
44.8.11	CIM_InstCreation .....	424
44.8.12	CIM_InstDeletion.....	425
44.8.13	CIM_InstModification.....	426
44.8.14	CIM_ListenerDestinationCIMXML (Indication Handler) .....	427
44.8.15	CIM_ListenerDestinationWSManagement (WS-Man Indication Handler).....	427
44.8.16	CIM_MemberOfCollection (Filter Collection to Filters).....	428
44.8.17	SNIA_IndicationConfigurationCapabilities .....	428
44.8.18	SNIA_IndicationConfigurationService .....	429
45	Object Manager Adapter Subprofile .....	430
45.1	Description .....	430
45.1.1	General.....	430
45.1.2	Instance Diagram .....	430
45.2	Health and Fault Management.....	430
45.3	Cascading Considerations .....	430
45.4	Supported Subprofiles and Packages.....	430
45.5	Methods of the Profile .....	430
45.6	Client Considerations and Recipes .....	431
45.7	Registered Name and Version .....	431
45.8	CIM Elements.....	431
45.8.1	General.....	431
45.8.2	CIM_CommMechanismForObjectManagerAdapter .....	431
45.8.3	CIM_ObjectManagerAdapter.....	431
46	Proxy Server System Management Subprofile.....	433
46.1	Description .....	433
46.1.1	General.....	433
46.1.2	Relationship to Server Profile.....	433
46.1.3	Model.....	433
46.1.4	Creation Considerations.....	434
46.2	Health and Fault Management Consideration.....	435
46.3	Cascading Considerations .....	435
46.4	Supported Profiles, Subprofiles, and Packages.....	435
46.5	Methods of the Profile .....	435
46.5.1	General.....	435
46.5.2	AddSystem .....	435
46.5.3	DiscoverSystems.....	436
46.5.4	RemoveSystem .....	437
46.6	Client Considerations and Recipes .....	437

46.6.1	General.....	437
46.6.2	Use Case 1: Add Device .....	438
46.6.3	Use Case 2: Remove Device .....	438
46.7	Registered Name and Version .....	438
46.8	CIM Elements.....	438
46.8.1	General.....	438
46.8.2	CIM_HostedService .....	439
46.8.3	SNIA_SystemRegistrationCapabilities .....	439
46.8.4	SNIA_SystemRegistrationService .....	440
47	Device Credentials Subprofile .....	441
47.1	Description .....	441
47.1.1	General.....	441
47.1.2	Instance Diagram .....	441
47.2	Health and Fault Management Considerations.....	441
47.3	Cascading Considerations .....	441
47.4	Supported Subprofiles and Packages.....	441
47.5	Extrinsic Methods of this Profile .....	441
47.6	Client Considerations and Recipes .....	441
47.7	Registered Name and Version .....	441
47.8	CIM Elements.....	442
47.8.1	General.....	442
47.8.2	CIM_HostedService .....	442
47.8.3	CIM_SharedSecret.....	442
47.8.4	CIM_SharedSecretIsShared .....	442
47.8.5	CIM_SharedSecretService .....	443
48	Miscellaneous Security Profiles.....	444
49	Operational Power Profile.....	445
49.1	Synopsis.....	445
49.2	Description .....	445
49.3	Implementation.....	445
49.3.1	Model Overview.....	445
49.3.2	Element Types .....	446
49.3.3	Power Metric Attributes .....	449
49.3.4	Bulk Retrieval .....	450
49.3.5	Default Manifest Collection.....	450
49.3.6	Client Defined Manifest Collection .....	450
49.3.7	Capabilities Support for Operational Power Profile .....	451
49.3.8	Health and Fault Management Consideration .....	452
49.3.9	Cascading Considerations .....	452
49.4	Methods of the Profile .....	452
49.4.1	Extrinsic Methods of the Profile .....	452
49.4.2	Intrinsic Methods of this Profile .....	457
49.5	Use Cases – Client Considerations and Recipes .....	457
49.6	CIM Elements.....	457
49.6.1	General.....	457
49.6.2	CIM_ComputerSystem (Optional Element) .....	459
49.6.3	CIM_DiskDrive (Optional Element) .....	459
49.6.4	CIM_ElementCapabilities .....	459
49.6.5	CIM_ElementStatisticalData (Optional Element Stats) .....	459
49.6.6	CIM_ElementStatisticalData (Top Level System Stats) .....	459
49.6.7	CIM_Fan (Optional Element).....	460
49.6.8	CIM_HostedCollection (Client Defined).....	460
49.6.9	CIM_HostedCollection (Default).....	460
49.6.10	CIM_HostedCollection (System to StatisticsCollection).....	461

49.6.11	CIM_HostedService .....	461
49.6.12	CIM_LogicalModule (Optional Element) .....	461
49.6.13	CIM_MemberOfCollection (Member of client defined collection) .....	462
49.6.14	CIM_MemberOfCollection (Member of power statistics collection) .....	462
49.6.15	CIM_MemberOfCollection (Member of pre-defined collection) .....	462
49.6.16	CIM_PowerSource (Optional Element) .....	463
49.6.17	CIM_PowerSupply (Optional Element) .....	463
49.6.18	CIM_Processor (Optional Element) .....	463
49.6.19	CIM_StatisticsCollection .....	463
49.6.20	SNIA_OperationalPowerManifest (Client Defined) .....	463
49.6.21	SNIA_OperationalPowerManifest (Provider Support) .....	464
49.6.22	SNIA_OperationalPowerManifestCollection (Client Defined) .....	465
49.6.23	SNIA_OperationalPowerManifestCollection (Provider Defined) .....	466
49.6.24	SNIA_OperationalPowerStatisticalData (Optional Element Stats) .....	466
49.6.25	SNIA_OperationalPowerStatisticalData (Top Level System Stats) .....	467
49.6.26	SNIA_OperationalPowerStatisticsCapabilities .....	467
49.6.27	SNIA_OperationalPowerStatisticsService .....	468
50	Cross Profile Considerations .....	470
50.1	Overview .....	470
50.2	HBA model .....	470
50.3	Switch Model .....	471
50.3.1	General .....	471
50.3.2	Recipes .....	471
50.4	Array Model .....	475
50.5	Storage Virtualization Model .....	477
50.6	Fabric Topology (HBA, Switch, Array) .....	478
50.6.1	General .....	478
50.6.2	Logical Device Composition .....	479
Annex A	(informative) SMI-S Information Model .....	525
Bibliography	.....	527

Figure 1 - Experimental Maturity Level Tag .....	46
Figure 2 - Implemented Maturity Level Tag .....	47
Figure 3 - Stable Maturity Level Tag .....	47
Figure 4 - Deprecated Tag .....	48
Figure 5 - Generic Target Port Classes .....	55
Figure 6 - LogicalPort Class Hierarchy .....	56
Figure 7 - Generic Target with LUN Masking.....	57
Figure 8 - SPI Target Port Instance Diagram.....	61
Figure 9 - FC Target Port Instance Diagram.....	67
Figure 10 - iSCSI Target Ports Subprofile Instance Diagram .....	74
Figure 11 - Serial Attached SCSI (SAS) Target Port Instance Diagram .....	110
Figure 12 - SATA Target Port Instance Diagram .....	117
Figure 13 - SB Target Port Instance Diagram.....	122
Figure 14 - DA Port Instance Diagram.....	128
Figure 15 - Generic Initiator Port Model.....	132
Figure 16 - Optional Connectivity Collection Model .....	133
Figure 17 - Optional Full-Path Model .....	133
Figure 18 - HBA and Disk Model .....	134
Figure 19 - HBA and Tape or Optical Devices.....	135
Figure 20 - Port Statistics.....	135
Figure 21 - Port Statistics Hierarchy .....	136
Figure 22 - SPI Initiator Port Instance Diagram .....	143
Figure 23 - iSCSI Initiator Port Instance Diagram.....	153
Figure 24 - Fibre Channel Initiator Instance Diagram .....	162
Figure 25 - FC Node Model .....	162
Figure 26 - SAS Initiator Port Model .....	174
Figure 27 - ATA Initiator Port Class Diagram.....	185
Figure 28 - Fibre Channel Initiator Instance Diagram .....	194
Figure 29 - FCoE Initiator Instance Diagram .....	204
Figure 30 - Optional Target Element Model.....	205
Figure 31 - Logical Port Group Model.....	206
Figure 32 - System-wide Remote Access Point.....	218
Figure 33 - Access Point Instance Diagram.....	219
Figure 34 - Instance Diagram for Logical Topology .....	223
Figure 35 - Resource Allocation/Deallocation Instance Diagram.....	225
Figure 36 - Cascading Server Topology .....	226
Figure 37 - Instance Diagram for Cascading with Resource Ownership .....	227
Figure 38 - Instance Diagram for Cascading with Credential Management Subprofile .....	228
Figure 39 - Modeling of Cascading Capabilities .....	229
Figure 40 - Job Control Subprofile Model .....	257
Figure 41 - Storage Configuration.....	262
Figure 42 - Location Instance .....	268
Figure 43 - Two Redundant Systems Instance Diagram .....	272
Figure 44 - Multiple Redundancy Tier Instance Diagram.....	273
Figure 45 - System Level Numbers .....	274
Figure 46 - Physical Package Package Mandatory Classes .....	282
Figure 47 - Modeling for well defined subcomponents .....	283
Figure 48 - Physical Package Package with Optional Classes.....	284
Figure 49 - Media Access Device Class Diagram.....	317

Figure 50 - Enclosure with Two Arrays .....	325
Figure 51 - Model for Disk in Enclosure .....	328
Figure 52 - Software Instance Diagram .....	331
Figure 53 - Server Model .....	341
Figure 54 - Profile Registration Model .....	352
Figure 55 - Associations between RegisteredProfile instances .....	353
Figure 56 - Model for SMI-S Registered Profile .....	354
Figure 57 - Model for Provider Versions .....	354
Figure 58 - Indication Profile and Namespaces .....	369
Figure 59 - Indication Profile Instance Diagram .....	372
Figure 60 - Indication Profile Instance Diagram .....	396
Figure 61 - Anatomy of IndicationIdentifier .....	397
Figure 62 - Predefined Filter Collections .....	401
Figure 63 - Client Defined Filter Collections .....	402
Figure 64 - Indication Configuration Service Classes .....	404
Figure 65 - ObjectManagerAdapter Subprofile Model .....	430
Figure 66 - Proxy Server System Management Model .....	434
Figure 67 - DeviceCredentials Subprofile Model .....	441
Figure 68 - Operational Power Profile Summary .....	446
Figure 69 - Model for Element Types .....	447
Figure 70 - Classes related to Top-level System Power Statistics .....	448
Figure 71 - System Diagram .....	470
Figure 72 - Host Bus Adapter Model .....	470
Figure 73 - Switch Model .....	471
Figure 74 - Array Instance .....	476
Figure 75 - Virtualization Instance .....	477
Figure 76 - Fabric Topology .....	478

Table 1 - Profile Components .....	44
Table 2 - Modeling of Common Storage Devices in CIM .....	57
Table 3 - CIM Elements for Generic Target Ports .....	58
Table 4 - SMI Referenced Properties/Methods for CIM_DeviceSAPImplementation .....	58
Table 5 - SMI Referenced Properties/Methods for CIM_HostedAccessPoint .....	59
Table 6 - SMI Referenced Properties/Methods for CIM_LogicalPort .....	59
Table 7 - SMI Referenced Properties/Methods for CIM_ProtocolEndpoint .....	60
Table 8 - SMI Referenced Properties/Methods for CIM_SystemDevice (Port) .....	60
Table 9 - Related Profiles for SPI Target Ports .....	61
Table 10 - SPIPort OperationalStatus .....	62
Table 11 - CIM Elements for SPI Target Ports .....	62
Table 12 - SMI Referenced Properties/Methods for CIM_DeviceSAPImplementation .....	63
Table 13 - SMI Referenced Properties/Methods for CIM_HostedAccessPoint .....	63
Table 14 - SMI Referenced Properties/Methods for CIM_SCSIProtocolEndpoint .....	64
Table 15 - SMI Referenced Properties/Methods for CIM_SPIPort .....	64
Table 16 - SMI Referenced Properties/Methods for CIM_SystemDevice (Port) .....	65
Table 17 - Related Profiles for FC Target Ports .....	66
Table 18 - FCPort OperationalStatus .....	67
Table 19 - CIM Elements for FC Target Ports .....	68
Table 20 - SMI Referenced Properties/Methods for CIM_DeviceSAPImplementation .....	69
Table 21 - SMI Referenced Properties/Methods for CIM_FCPort .....	69
Table 22 - SMI Referenced Properties/Methods for CIM_HostedAccessPoint .....	70
Table 23 - SMI Referenced Properties/Methods for CIM_ProtocolControllerForPort .....	70
Table 24 - SMI Referenced Properties/Methods for CIM_SCSIProtocolEndpoint .....	71
Table 25 - SMI Referenced Properties/Methods for CIM_SystemDevice (Port) .....	71
Table 26 - iSCSI Terminology and SMI-S Class Names .....	72
Table 27 - EthernetPort OperationalStatus .....	75
Table 28 - CIM Elements for iSCSI Target Ports .....	90
Table 29 - SMI Referenced Properties/Methods for CIM_BindsTo (TCPProtocolEndpoint to IPProtocolEndpoint) .....	92
Table 30 - SMI Referenced Properties/Methods for CIM_BindsTo (iSCSIProtocolEndpoint to TCPProtocolEndpoint) .....	93
Table 31 - SMI Referenced Properties/Methods for CIM_ConcreteDependency .....	93
Table 32 - SMI Referenced Properties/Methods for CIM_DeviceSAPImplementation (EthernetPort to IPProtocolEndpoint) .....	93
Table 33 - SMI Referenced Properties/Methods for CIM_DeviceSAPImplementation (EthernetPort to iSCSIProtocolEndpoint) .....	94
Table 34 - SMI Referenced Properties/Methods for CIM_ElementCapabilities (iSCSIConfigurationCapabilities to System) .....	94
Table 35 - SMI Referenced Properties/Methods for CIM_ElementCapabilities (iSCSIConfigurationCapabilities to iSCSIConfigurationService) .....	94
Table 36 - SMI Referenced Properties/Methods for CIM_ElementSettingData (iSCSIConnectionSettings to TCPProtocolEndpoint) .....	95
Table 37 - SMI Referenced Properties/Methods for CIM_ElementSettingData (iSCSIConnectionSettings to iSCSIProtocolEndpoint) .....	95
Table 38 - SMI Referenced Properties/Methods for CIM_ElementSettingData (iSCSIConnectionSettings to iSCSIProtocolController) .....	95
Table 39 - SMI Referenced Properties/Methods for CIM_ElementSettingData (iSCSIConnectionSettings to System) .....	96
Table 40 - SMI Referenced Properties/Methods for CIM_ElementSettingData (iSCSIConnectionSettings to iSCSIProtocolEndpoint) .....	96
Table 41 - SMI Referenced Properties/Methods for CIM_ElementStatisticalData (iSCSIConnectionSettings to iSCSIProtocolController) .....	96
Table 42 - SMI Referenced Properties/Methods for CIM_ElementStatisticalData (iSCSIConnectionSettings to iSCSIProtocolController) .....	97

Table 43 - SMI Referenced Properties/Methods for CIM_ElementStatisticalData (iSCSIStatistics to iSCSIEndpoint) .....	97
Table 44 - SMI Referenced Properties/Methods for CIM_EndpointOfNetworkPipe (iSCSIConnection to TCPPEndpoint).....	97
Table 45 - SMI Referenced Properties/Methods for CIM_EndpointOfNetworkPipe (iSCSIEndpoint to iSCSIProtocolEndpoint).....	98
Table 46 - SMI Referenced Properties/Methods for CIM_EthernetPort.....	98
Table 47 - SMI Referenced Properties/Methods for CIM_HostedAccessPoint (System to IPPEndpoint).....	99
Table 48 - SMI Referenced Properties/Methods for CIM_HostedAccessPoint (System to TCPPEndpoint).....	99
Table 49 - SMI Referenced Properties/Methods for CIM_HostedAccessPoint (System to iSCSIProtocolEndpoint).....	99
Table 50 - SMI Referenced Properties/Methods for CIM_HostedCollection.....	100
Table 51 - SMI Referenced Properties/Methods for CIM_HostedService.....	100
Table 52 - SMI Referenced Properties/Methods for CIM_IPProtocolEndpoint .....	100
Table 53 - SMI Referenced Properties/Methods for CIM_MemberOfCollection .....	101
Table 54 - SMI Referenced Properties/Methods for CIM_NetworkPipeComposition.....	101
Table 55 - SMI Referenced Properties/Methods for CIM_SAPAvailableForElement.....	101
Table 56 - SMI Referenced Properties/Methods for CIM_SCSIProtocolController.....	102
Table 57 - SMI Referenced Properties/Methods for CIM_SystemDevice (System to EthernetPort) .....	102
Table 58 - SMI Referenced Properties/Methods for CIM_SystemDevice (System to SCSIProtocolController) .....	102
Table 59 - SMI Referenced Properties/Methods for CIM_SystemSpecificCollection.....	103
Table 60 - SMI Referenced Properties/Methods for CIM_TCPPEndpoint .....	103
Table 61 - SMI Referenced Properties/Methods for CIM_iSCSICapabilities .....	103
Table 62 - SMI Referenced Properties/Methods for CIM_iSCSIConfigurationCapabilities.....	104
Table 63 - SMI Referenced Properties/Methods for CIM_iSCSIConfigurationService .....	104
Table 64 - SMI Referenced Properties/Methods for CIM_iSCSIConnection.....	105
Table 65 - SMI Referenced Properties/Methods for CIM_iSCSIConnectionSettings.....	105
Table 66 - SMI Referenced Properties/Methods for CIM_iSCSILoginStatistics.....	106
Table 67 - SMI Referenced Properties/Methods for CIM_iSCSIProtocolEndpoint .....	107
Table 68 - SMI Referenced Properties/Methods for CIM_iSCSIEndpoint .....	107
Table 69 - SMI Referenced Properties/Methods for CIM_iSCSIEndpointFailures .....	108
Table 70 - SMI Referenced Properties/Methods for CIM_iSCSIEndpointSettings.....	108
Table 71 - SMI Referenced Properties/Methods for CIM_iSCSIEndpointStatistics.....	109
Table 72 - Related Profiles for SAS Target Ports .....	110
Table 73 - SASPort OperationalStatus .....	111
Table 74 - CIM Elements for SAS Target Ports .....	112
Table 75 - SMI Referenced Properties/Methods for CIM_ConcreteComponent.....	112
Table 76 - SMI Referenced Properties/Methods for CIM_DeviceSAPImplementation .....	113
Table 77 - SMI Referenced Properties/Methods for CIM_HostedAccessPoint.....	113
Table 78 - SMI Referenced Properties/Methods for CIM_SASPort.....	114
Table 79 - SMI Referenced Properties/Methods for CIM_SCSIProtocolEndpoint .....	114
Table 80 - SMI Referenced Properties/Methods for CIM_SystemDevice (Port).....	115
Table 81 - SMI Referenced Properties/Methods for CIM_SystemDevice (SAS PHY).....	115
Table 82 - SMI Referenced Properties/Methods for SNIA_SASPHY.....	115
Table 83 - Related Profiles for SATA Target Ports .....	116
Table 84 - ATAPort OperationalStatus.....	117
Table 85 - CIM Elements for SATA Target Ports .....	118
Table 86 - SMI Referenced Properties/Methods for CIM_ATAPort .....	118
Table 87 - SMI Referenced Properties/Methods for CIM_ATAPortEndpoint.....	119
Table 88 - SMI Referenced Properties/Methods for CIM_DeviceSAPImplementation .....	119

Table 89 - SMI Referenced Properties/Methods for CIM_HostedAccessPoint.....	120
Table 90 - SMI Referenced Properties/Methods for CIM_SystemDevice (Port).....	120
Table 91 - Related Profiles for SB Target Ports.....	121
Table 92 - FCPort OperationalStatus.....	122
Table 93 - CIM Elements for SB Target Ports.....	123
Table 94 - SMI Referenced Properties/Methods for CIM_DeviceSAPImplementation .....	124
Table 95 - SMI Referenced Properties/Methods for CIM_FCPort.....	124
Table 96 - SMI Referenced Properties/Methods for CIM_HostedAccessPoint.....	125
Table 97 - SMI Referenced Properties/Methods for CIM_SystemDevice (Port).....	125
Table 98 - SMI Referenced Properties/Methods for SNIA_SBProtocolEndpoint.....	126
Table 99 - CIM Elements for DA Target Ports .....	129
Table 100 - SMI Referenced Properties/Methods for CIM_DAPort .....	129
Table 101 - SMI Referenced Properties/Methods for CIM_DeviceSAPImplementation .....	130
Table 102 - SMI Referenced Properties/Methods for CIM_HostedAccessPoint.....	130
Table 103 - SMI Referenced Properties/Methods for CIM_SCSIProtocolEndpoint .....	131
Table 104 - SMI Referenced Properties/Methods for CIM_SystemDevice (Port).....	131
Table 105 - CIM Elements for Generic Initiator Ports .....	137
Table 106 - SMI Referenced Properties/Methods for CIM_ConnectivityCollection.....	137
Table 107 - SMI Referenced Properties/Methods for CIM_DeviceSAPImplementation .....	138
Table 108 - SMI Referenced Properties/Methods for CIM_ElementStatisticalData (Port Statistics) .....	138
Table 109 - SMI Referenced Properties/Methods for CIM_HostedAccessPoint (Initiator).....	138
Table 110 - SMI Referenced Properties/Methods for CIM_HostedAccessPoint (Target).....	139
Table 111 - SMI Referenced Properties/Methods for CIM_HostedCollection (Connectivity Collection) .....	139
Table 112 - SMI Referenced Properties/Methods for CIM_LogicalPort .....	140
Table 113 - SMI Referenced Properties/Methods for CIM_MemberOfCollection (Connectivity Collection) .....	140
Table 114 - SMI Referenced Properties/Methods for CIM_ProtocolEndpoint (Initiator) .....	140
Table 115 - SMI Referenced Properties/Methods for CIM_ProtocolEndpoint (Target).....	141
Table 116 - SMI Referenced Properties/Methods for CIM_SystemDevice (Initiator Ports) .....	142
Table 117 - SMI Referenced Properties/Methods for SNIA_LogicalPortStatistics.....	142
Table 118 - SPIPort OperationalStatus.....	143
Table 119 - CIM Elements for SPI Initiator Ports .....	144
Table 120 - SMI Referenced Properties/Methods for CIM_ConnectivityCollection.....	145
Table 121 - SMI Referenced Properties/Methods for CIM_DeviceSAPImplementation .....	146
Table 122 - SMI Referenced Properties/Methods for CIM_ElementStatisticalData (Port Statistics) .....	146
Table 123 - SMI Referenced Properties/Methods for CIM_HostedAccessPoint (Initiator).....	146
Table 124 - SMI Referenced Properties/Methods for CIM_HostedAccessPoint (Target).....	147
Table 125 - SMI Referenced Properties/Methods for CIM_HostedCollection (Connectivity Collection).....	147
Table 126 - SMI Referenced Properties/Methods for CIM_MemberOfCollection (Connectivity Collection).....	148
Table 127 - SMI Referenced Properties/Methods for CIM_SCSIInitiatorTargetLogicalUnitPath .....	148
Table 128 - SMI Referenced Properties/Methods for CIM_SCSIProtocolEndpoint (Initiator).....	148
Table 129 - SMI Referenced Properties/Methods for CIM_SCSIProtocolEndpoint (Target) .....	149
Table 130 - SMI Referenced Properties/Methods for CIM_SPIPort.....	150
Table 131 - SMI Referenced Properties/Methods for CIM_SystemDevice (Initiator Ports) .....	150
Table 132 - SMI Referenced Properties/Methods for SNIA_LogicalPortStatistics.....	151
Table 133 - Related Profiles for iSCSI Initiator Ports .....	152
Table 134 - EthernetPort OperationalStatus .....	153
Table 135 - CIM Elements for iSCSI Initiator Ports.....	154
Table 136 - SMI Referenced Properties/Methods for CIM_BindsTo (Host Hardware RAID Controller) .....	155
Table 137 - SMI Referenced Properties/Methods for CIM_DeviceSAPImplementation (IPProtocolEndpoint to EthernetPort).....	155

Table 138 - SMI Referenced Properties/Methods for CIM_DeviceSAPImplementation (iSSIProtocolEndpoint to EthernetPort) .....	156
Table 139 - SMI Referenced Properties/Methods for CIM_EthernetPort (Host Hardware RAID Controller) .....	156
Table 140 - SMI Referenced Properties/Methods for CIM_HostedAccessPoint (System to IPProtocolEndpoint) .....	156
Table 141 - SMI Referenced Properties/Methods for CIM_HostedAccessPoint (System to TCPProtocolEndpoint) .....	157
Table 142 - SMI Referenced Properties/Methods for CIM_HostedAccessPoint (System to iSCSIProtocolEndpoint) .....	157
Table 143 - SMI Referenced Properties/Methods for CIM_IPProtocolEndpoint (Host Hardware RAID Controller) .....	157
Table 144 - SMI Referenced Properties/Methods for CIM_LogicalDevice (Host Hardware RAID Controller) .....	158
Table 145 - SMI Referenced Properties/Methods for CIM_SystemDevice (System to EthernetPort) .....	158
Table 146 - SMI Referenced Properties/Methods for CIM_SystemDevice (System to LogicalDevice) .....	159
Table 147 - SMI Referenced Properties/Methods for CIM_TCPProtocolEndpoint (Host Hardware RAID Controller) .....	159
Table 148 - SMI Referenced Properties/Methods for CIM_iSCSIProtocolEndpoint (Host Hardware RAID Controller) .....	160
Table 149 - Related Profiles for FC Initiator Ports .....	161
Table 150 - FCPort OperationalStatus .....	163
Table 151 - CIM Elements for FC Initiator Ports .....	164
Table 152 - SMI Referenced Properties/Methods for CIM_ConnectivityCollection .....	165
Table 153 - SMI Referenced Properties/Methods for CIM_DeviceSAPImplementation .....	166
Table 154 - SMI Referenced Properties/Methods for CIM_ElementStatisticalData (Port Statistics) .....	166
Table 155 - SMI Referenced Properties/Methods for CIM_FCPort .....	167
Table 156 - SMI Referenced Properties/Methods for CIM_FCPortStatistics .....	168
Table 157 - SMI Referenced Properties/Methods for CIM_HostedAccessPoint (Initiator) .....	169
Table 158 - SMI Referenced Properties/Methods for CIM_HostedAccessPoint (Target) .....	169
Table 159 - SMI Referenced Properties/Methods for CIM_HostedCollection (Connectivity Collection) .....	169
Table 160 - SMI Referenced Properties/Methods for CIM_MemberOfCollection (Connectivity Collection) .....	170
Table 161 - SMI Referenced Properties/Methods for CIM_ProtocolControllerForPort .....	170
Table 162 - SMI Referenced Properties/Methods for CIM_SCSIInitiatorTargetLogicalUnitPath .....	171
Table 163 - SMI Referenced Properties/Methods for CIM_SCSIProtocolController .....	171
Table 164 - SMI Referenced Properties/Methods for CIM_SCSIProtocolEndpoint (Initiator) .....	172
Table 165 - SMI Referenced Properties/Methods for CIM_SCSIProtocolEndpoint (Target) .....	172
Table 166 - SMI Referenced Properties/Methods for CIM_SystemDevice (Initiator Ports) .....	173
Table 167 - SASPort OperationalStatus .....	175
Table 168 - CIM Elements for SAS Initiator Ports .....	175
Table 169 - SMI Referenced Properties/Methods for CIM_ATAProtocolEndpoint (Initiator) .....	176
Table 170 - SMI Referenced Properties/Methods for CIM_BindsTo .....	177
Table 171 - SMI Referenced Properties/Methods for CIM_ConcreteComponent .....	177
Table 172 - SMI Referenced Properties/Methods for CIM_ConnectivityCollection .....	177
Table 173 - SMI Referenced Properties/Methods for CIM_DeviceSAPImplementation .....	178
Table 174 - SMI Referenced Properties/Methods for CIM_ElementStatisticalData (PHY Statistics) .....	178
Table 175 - SMI Referenced Properties/Methods for CIM_ElementStatisticalData (Port Statistics) .....	178
Table 176 - SMI Referenced Properties/Methods for CIM_HostedAccessPoint (Initiator) .....	179
Table 177 - SMI Referenced Properties/Methods for CIM_HostedAccessPoint (Target) .....	179
Table 178 - SMI Referenced Properties/Methods for CIM_HostedCollection (Connectivity Collection) .....	179
Table 179 - SMI Referenced Properties/Methods for CIM_MemberOfCollection	

Table 180 - SMI Referenced Properties/Methods for CIM_SASPort .....	180
Table 181 - SMI Referenced Properties/Methods for CIM_SCSIInitiatorTargetLogicalUnitPath .....	181
Table 182 - SMI Referenced Properties/Methods for CIM_SCSIProtocolEndpoint (Initiator) .....	181
Table 183 - SMI Referenced Properties/Methods for CIM_SCSIProtocolEndpoint (Target) .....	182
Table 184 - SMI Referenced Properties/Methods for CIM_SystemDevice (Initiator PHY) .....	182
Table 185 - SMI Referenced Properties/Methods for CIM_SystemDevice (Initiator Ports) .....	183
Table 186 - SMI Referenced Properties/Methods for SNIA_LogicalPortStatistics .....	183
Table 187 - SMI Referenced Properties/Methods for SNIA_SASPHY .....	183
Table 188 - SMI Referenced Properties/Methods for SNIA_SASPhyStatistics .....	184
Table 189 - ATAPort OperationalStatus .....	186
Table 190 - CIM Elements for ATA Initiator Ports .....	187
Table 191 - SMI Referenced Properties/Methods for CIM_ATAInitiatorTargetLogicalUnitPath .....	188
Table 192 - SMI Referenced Properties/Methods for CIM_ATAPort .....	188
Table 193 - SMI Referenced Properties/Methods for CIM_ATAProtocolEndpoint (Initiator) .....	189
Table 194 - SMI Referenced Properties/Methods for CIM_ATAProtocolEndpoint (Target) .....	189
Table 195 - SMI Referenced Properties/Methods for CIM_ConnectivityCollection .....	190
Table 196 - SMI Referenced Properties/Methods for CIM_DeviceSAPImplementation .....	190
Table 197 - SMI Referenced Properties/Methods for CIM_ElementStatisticalData (Port Statistics) .....	191
Table 198 - SMI Referenced Properties/Methods for CIM_HostedAccessPoint (Initiator) .....	191
Table 199 - SMI Referenced Properties/Methods for CIM_HostedAccessPoint (Target) .....	191
Table 200 - SMI Referenced Properties/Methods for CIM_HostedCollection (Connectivity Collection) .....	192
Table 201 - SMI Referenced Properties/Methods for CIM_MemberOfCollection (Connectivity Collection) .....	192
Table 202 - SMI Referenced Properties/Methods for CIM_SystemDevice (Initiator Ports) .....	192
Table 203 - SMI Referenced Properties/Methods for SNIA_LogicalPortStatistics .....	193
Table 204 - Related Profiles for SB Initiator Ports .....	194
Table 205 - FCPort OperationalStatus .....	195
Table 206 - CIM Elements for SB Initiator Ports .....	196
Table 207 - SMI Referenced Properties/Methods for CIM_ConnectivityCollection .....	197
Table 208 - SMI Referenced Properties/Methods for CIM_DeviceSAPImplementation .....	197
Table 209 - SMI Referenced Properties/Methods for CIM_ElementStatisticalData (Port Statistics) .....	197
Table 210 - SMI Referenced Properties/Methods for CIM_FCPort .....	198
Table 211 - SMI Referenced Properties/Methods for CIM_HostedAccessPoint (Initiator) .....	199
Table 212 - SMI Referenced Properties/Methods for CIM_HostedAccessPoint (Target) .....	199
Table 213 - SMI Referenced Properties/Methods for CIM_HostedCollection (Connectivity Collection) .....	199
Table 214 - SMI Referenced Properties/Methods for CIM_MemberOfCollection (Connectivity Collection) .....	200
Table 215 - SMI Referenced Properties/Methods for CIM_SystemDevice (Initiator Ports) .....	200
Table 216 - SMI Referenced Properties/Methods for SNIA_LogicalPortStatistics .....	201
Table 217 - SMI Referenced Properties/Methods for SNIA_SBInitiatorTargetLogicalUnitPath .....	201
Table 218 - SMI Referenced Properties/Methods for SNIA_SBProtocolEndpoint (Initiator) .....	202
Table 219 - SMI Referenced Properties/Methods for SNIA_SBProtocolEndpoint (Target) .....	202
Table 220 - FCPort OperationalStatus .....	206
Table 221 - CIM Elements for FCoE Initiator Ports .....	207
Table 222 - SMI Referenced Properties/Methods for CIM_ConnectivityCollection .....	208
Table 223 - SMI Referenced Properties/Methods for CIM_DeviceSAPImplementation .....	208
Table 224 - SMI Referenced Properties/Methods for CIM_ElementStatisticalData (Port Statistics) .....	209
Table 225 - SMI Referenced Properties/Methods for CIM_EthernetPort .....	209
Table 226 - SMI Referenced Properties/Methods for CIM_FCPort .....	210
Table 227 - SMI Referenced Properties/Methods for CIM_FCPortStatistics .....	211
Table 228 - SMI Referenced Properties/Methods for CIM_HostedAccessPoint (Initiator) .....	212

Table 229 - SMI Referenced Properties/Methods for CIM_HostedAccessPoint (Target) .....	212
Table 230 - SMI Referenced Properties/Methods for CIM_HostedCollection (Connectivity Collection) .....	212
Table 231 - SMI Referenced Properties/Methods for CIM_HostedCollection (FC Node) .....	213
Table 232 - SMI Referenced Properties/Methods for CIM_HostedDependency (NetworkPort to FCPort) .....	213
Table 233 - SMI Referenced Properties/Methods for CIM_LogicalPortGroup .....	213
Table 234 - SMI Referenced Properties/Methods for CIM_MemberOfCollection (Connectivity Collection) .....	214
Table 235 - SMI Referenced Properties/Methods for CIM_MemberOfCollection (FC Node) .....	214
Table 236 - SMI Referenced Properties/Methods for CIM_ProtocolEndpoint (Initiator) .....	214
Table 237 - SMI Referenced Properties/Methods for CIM_ProtocolEndpoint (Target) .....	215
Table 238 - SMI Referenced Properties/Methods for CIM_SCSIInitiatorTargetLogicalUnitPath .....	215
Table 239 - SMI Referenced Properties/Methods for CIM_SCSIProtocolEndpoint (Initiator) .....	216
Table 240 - SMI Referenced Properties/Methods for CIM_SCSIProtocolEndpoint (Target) .....	216
Table 241 - SMI Referenced Properties/Methods for CIM_SystemDevice (Ethernet Port) .....	217
Table 242 - SMI Referenced Properties/Methods for CIM_SystemDevice (Initiator Ports) .....	217
Table 243 - RemoteAccessPoint InfoFormat and AccessInfo Properties .....	219
Table 244 - CIM Elements for Access Points .....	220
Table 245 - SMI Referenced Properties/Methods for CIM_HostedAccessPoint .....	220
Table 246 - SMI Referenced Properties/Methods for CIM_RemoteServiceAccessPoint .....	221
Table 247 - SMI Referenced Properties/Methods for CIM_SAPAvailableForElement .....	221
Table 248 - Supported Profiles for Cascading .....	230
Table 249 - Extrinsic Methods Supported by Cascading Subprofile .....	230
Table 250 - Cascading Capabilities Patterns .....	232
Table 251 - CIM Elements for Cascading .....	233
Table 252 - SMI Referenced Properties/Methods for CIM_ComputerSystem (Leaf System) .....	235
Table 253 - SMI Referenced Properties/Methods for CIM_Dependency (Object Managers) .....	236
Table 254 - SMI Referenced Properties/Methods for CIM_Dependency (Profile to Object Manager) .....	236
Table 255 - SMI Referenced Properties/Methods for CIM_Dependency (Systems) .....	236
Table 256 - SMI Referenced Properties/Methods for CIM_ElementCapabilities .....	237
Table 257 - SMI Referenced Properties/Methods for CIM_ElementConformsToProfile (Leaf) .....	237
Table 258 - SMI Referenced Properties/Methods for CIM_HostedCollection (Allocated Resources) .....	238
Table 259 - SMI Referenced Properties/Methods for CIM_HostedCollection (Remote Resources) .....	238
Table 260 - SMI Referenced Properties/Methods for CIM_HostedService (Allocation Service) .....	238
Table 261 - SMI Referenced Properties/Methods for CIM_HostedService (Object Manager) .....	239
Table 262 - SMI Referenced Properties/Methods for CIM_LogicalDisk .....	239
Table 263 - SMI Referenced Properties/Methods for CIM_LogicalIdentity (General) .....	240
Table 264 - SMI Referenced Properties/Methods for CIM_LogicalIdentity (LogicalDisk) .....	241
Table 265 - SMI Referenced Properties/Methods for CIM_LogicalIdentity (StorageVolume) .....	241
Table 266 - SMI Referenced Properties/Methods for CIM_MemberOfCollection (Allocated Resources) .....	242
Table 267 - SMI Referenced Properties/Methods for CIM_MemberOfCollection (Remote Resources) .....	242
Table 268 - SMI Referenced Properties/Methods for CIM_Namespace (Leaf) .....	242
Table 269 - SMI Referenced Properties/Methods for CIM_NamespaceInManager (Leaf) .....	243
Table 270 - SMI Referenced Properties/Methods for CIM_ObjectManager (Leaf) .....	243
Table 271 - SMI Referenced Properties/Methods for CIM_RegisteredProfile (Leaf) .....	244
Table 272 - SMI Referenced Properties/Methods for CIM_RemoteServiceAccessPoint (Leaf) .....	244
Table 273 - SMI Referenced Properties/Methods for CIM_SAPAvailableForElement .....	245
Table 274 - SMI Referenced Properties/Methods for CIM_StorageVolume .....	245
Table 275 - SMI Referenced Properties/Methods for CIM_SystemDevice (Leaf Devices) .....	246

Table 276 - SMI Referenced Properties/Methods for SNIA_AllocatedResources .....	247
Table 277 - SMI Referenced Properties/Methods for SNIA_AllocationService.....	247
Table 278 - SMI Referenced Properties/Methods for SNIA_CascadingCapabilities.....	248
Table 279 - SMI Referenced Properties/Methods for SNIA_RemoteResources .....	249
Table 280 - OperationalStatus Details .....	252
Table 281 - CIM Elements for Health.....	254
Table 282 - SMI Referenced Properties/Methods for CIM_ComputerSystem .....	255
Table 283 - SMI Referenced Properties/Methods for CIM_LogicalDevice.....	255
Table 284 - SMI Referenced Properties/Methods for CIM_RelatedElementCausingError .....	256
Table 285 - OperationalStatus to Job State Mapping .....	259
Table 286 - Standard Message for Job Control Subprofile.....	260
Table 287 - CIM Elements for Job Control.....	263
Table 288 - SMI Referenced Properties/Methods for CIM_AffectedJobElement.....	264
Table 289 - SMI Referenced Properties/Methods for CIM_AssociatedJobMethodResult .....	264
Table 290 - SMI Referenced Properties/Methods for CIM_ConcreteJob.....	265
Table 291 - SMI Referenced Properties/Methods for CIM_MethodResult.....	267
Table 292 - SMI Referenced Properties/Methods for CIM_OwningJobElement.....	267
Table 293 - CIM Elements for Location.....	269
Table 294 - SMI Referenced Properties/Methods for CIM_Location .....	269
Table 295 - SMI Referenced Properties/Methods for CIM_PhysicalElementLocation.....	269
Table 296 - Redundancy Type.....	273
Table 297 - Supported Profiles for Multiple Computer System .....	276
Table 298 - CIM Elements for Multiple Computer System .....	279
Table 299 - SMI Referenced Properties/Methods for CIM_ComponentCS .....	280
Table 300 - SMI Referenced Properties/Methods for CIM_ComputerSystem (Non-Top-Level System).....	280
Table 301 - SMI Referenced Properties/Methods for CIM_ConcreteIdentity.....	280
Table 302 - SMI Referenced Properties/Methods for CIM_IsSpare.....	281
Table 303 - SMI Referenced Properties/Methods for CIM_MemberOfCollection .....	281
Table 304 - SMI Referenced Properties/Methods for CIM_RedundancySet .....	281
Table 305 - CIM Elements for Physical Package.....	285
Table 306 - SMI Referenced Properties/Methods for CIM_Container .....	286
Table 307 - SMI Referenced Properties/Methods for CIM_LogicalIdentity .....	286
Table 308 - SMI Referenced Properties/Methods for CIM_PhysicalElementLocation.....	286
Table 309 - SMI Referenced Properties/Methods for CIM_PhysicalPackage (Component).....	287
Table 310 - SMI Referenced Properties/Methods for CIM_PhysicalPackage (System) .....	287
Table 311 - SMI Referenced Properties/Methods for CIM_Product (Component).....	288
Table 312 - SMI Referenced Properties/Methods for CIM_Product (System) .....	288
Table 313 - SMI Referenced Properties/Methods for CIM_ProductParentChild .....	289
Table 314 - SMI Referenced Properties/Methods for CIM_ProductPhysicalComponent (Component).....	289
Table 315 - SMI Referenced Properties/Methods for CIM_ProductPhysicalComponent (System) .....	290
Table 316 - SMI Referenced Properties/Methods for CIM_SystemPackaging (Component) .....	290
Table 317 - SMI Referenced Properties/Methods for CIM_SystemPackaging (System).....	290
Table 318 - Related Profiles for Power Supply .....	291
Table 319 - CIM Elements for Power Supply .....	292
Table 320 - SMI Referenced Properties/Methods for CIM_ElementCapabilities .....	293
Table 321 - SMI Referenced Properties/Methods for CIM_EnabledLogicalElementCapabilities.....	293
Table 322 - SMI Referenced Properties/Methods for CIM_IsSpare.....	293
Table 323 - SMI Referenced Properties/Methods for CIM_MemberOfCollection .....	294
Table 324 - SMI Referenced Properties/Methods for CIM_OwningCollectionElement.....	294
Table 325 - SMI Referenced Properties/Methods for CIM_PowerSupply.....	295
Table 326 - SMI Referenced Properties/Methods for CIM_RedundancySet .....	295

Table 327 - SMI Referenced Properties/Methods for CIM_SuppliesPower .....	296
Table 328 - SMI Referenced Properties/Methods for CIM_SystemDevice .....	296
Table 329 - Related Profiles for Fan .....	297
Table 330 - CIM Elements for Fan .....	298
Table 331 - SMI Referenced Properties/Methods for CIM_AssociatedCooling .....	299
Table 332 - SMI Referenced Properties/Methods for CIM_AssociatedSensor .....	299
Table 333 - SMI Referenced Properties/Methods for CIM_ElementCapabilities .....	299
Table 334 - SMI Referenced Properties/Methods for CIM_EnabledLogicalElementCapabilities.....	300
Table 335 - SMI Referenced Properties/Methods for CIM_Fan.....	300
Table 336 - SMI Referenced Properties/Methods for CIM_IsSpare.....	301
Table 337 - SMI Referenced Properties/Methods for CIM_MemberOfCollection .....	301
Table 338 - SMI Referenced Properties/Methods for CIM_NumericSensor .....	301
Table 339 - SMI Referenced Properties/Methods for CIM_OwningCollectionElement.....	302
Table 340 - SMI Referenced Properties/Methods for CIM_RedundancySet .....	302
Table 341 - SMI Referenced Properties/Methods for CIM_Sensor.....	303
Table 342 - SMI Referenced Properties/Methods for CIM_SystemDevice .....	303
Table 343 - CIM Elements for Sensors .....	304
Table 344 - SMI Referenced Properties/Methods for CIM_AssociatedSensor .....	305
Table 345 - SMI Referenced Properties/Methods for CIM_ElementCapabilities .....	306
Table 346 - SMI Referenced Properties/Methods for CIM_EnabledLogicalElementCapabilities.....	306
Table 347 - SMI Referenced Properties/Methods for CIM_NumericSensor .....	306
Table 348 - SMI Referenced Properties/Methods for CIM_Sensor.....	308
Table 349 - SMI Referenced Properties/Methods for CIM_SystemDevice .....	309
Table 350 - Related Profiles for Base Server.....	310
Table 351 - CIM Elements for Base Server .....	311
Table 352 - SMI Referenced Properties/Methods for CIM_ComputerSystem .....	312
Table 353 - SMI Referenced Properties/Methods for CIM_ComputerSystemPackage .....	313
Table 354 - SMI Referenced Properties/Methods for CIM_ElementCapabilities .....	313
Table 355 - SMI Referenced Properties/Methods for CIM_EnabledLogicalElementCapabilities.....	313
Table 356 - SMI Referenced Properties/Methods for CIM_HostedService.....	314
Table 357 - SMI Referenced Properties/Methods for CIM_PhysicalPackage.....	314
Table 358 - SMI Referenced Properties/Methods for CIM_ServiceAffectsElement.....	315
Table 359 - SMI Referenced Properties/Methods for CIM_TimeService .....	315
Table 360 - Related Profiles for Media Access Device .....	316
Table 361 - OperationalStatus For MediaAccessDevice .....	317
Table 362 - CIM Elements for Media Access Device.....	318
Table 363 - SMI Referenced Properties/Methods for CIM_EnabledLogicalElementCapabilities.....	319
Table 364 - SMI Referenced Properties/Methods for CIM_HostedAccessPoint.....	319
Table 365 - SMI Referenced Properties/Methods for CIM_MediaAccessDevice.....	319
Table 366 - SMI Referenced Properties/Methods for CIM_PhysicalPackage.....	320
Table 367 - SMI Referenced Properties/Methods for CIM_ProtocolEndpoint.....	321
Table 368 - SMI Referenced Properties/Methods for CIM_Realizes .....	321
Table 369 - SMI Referenced Properties/Methods for CIM_SAPAvailableForElement.....	321
Table 370 - SMI Referenced Properties/Methods for CIM_SystemDevice .....	322
Table 371 - Related Profiles for Storage Enclosure.....	323
Table 372 - CIM Elements for Storage Enclosure.....	329
Table 373 - SMI Referenced Properties/Methods for CIM_ConfigurationReportingService .....	329
Table 374 - SMI Referenced Properties/Methods for CIM_HostedService.....	330
Table 375 - CIM Elements for Software .....	332
Table 376 - SMI Referenced Properties/Methods for CIM_InstalledSoftwareIdentity .....	332
Table 377 - SMI Referenced Properties/Methods for CIM_SoftwareIdentity .....	333
Table 378 - Related Profiles for Software Inventory .....	334
Table 379 - CIM Elements for Software Inventory .....	335

Table 380 - SMI Referenced Properties/Methods for CIM_ElementSoftwareIdentity .....	336
Table 381 - SMI Referenced Properties/Methods for CIM_HostedAccessPoint.....	336
Table 382 - SMI Referenced Properties/Methods for CIM_HostedCollection .....	337
Table 383 - SMI Referenced Properties/Methods for CIM_InstalledSoftwareIdentity.....	337
Table 384 - SMI Referenced Properties/Methods for CIM_MemberOfCollection .....	337
Table 385 - SMI Referenced Properties/Methods for CIM_OrderedComponent .....	338
Table 386 - SMI Referenced Properties/Methods for CIM_OrderedDependency.....	338
Table 387 - SMI Referenced Properties/Methods for CIM_SAPAvailableForElement.....	338
Table 388 - SMI Referenced Properties/Methods for CIM_SoftwareIdentity .....	339
Table 389 - SMI Referenced Properties/Methods for CIM_SoftwareIdentityResource .....	339
Table 390 - SMI Referenced Properties/Methods for CIM_SystemSpecificCollection.....	340
Table 391 - Supported Profiles for Server.....	343
Table 392 - CIM Elements for Server.....	345
Table 393 - SMI Referenced Properties/Methods for CIM_CIMXMLCommunicationMechanism.....	346
Table 394 - SMI Referenced Properties/Methods for CIM_CommMechanismForManager .....	347
Table 395 - SMI Referenced Properties/Methods for CIM_HostedAccessPoint.....	347
Table 396 - SMI Referenced Properties/Methods for CIM_HostedService.....	347
Table 397 - SMI Referenced Properties/Methods for CIM_Namespace.....	348
Table 398 - SMI Referenced Properties/Methods for CIM_NamespaceInManager.....	348
Table 399 - SMI Referenced Properties/Methods for CIM_ObjectManager .....	349
Table 400 - SMI Referenced Properties/Methods for CIM_ObjectManagerCommunicationMechanism .....	349
Table 401 - SMI Referenced Properties/Methods for CIM_System .....	350
Table 402 - CIM Elements for Profile Registration .....	362
Table 403 - SMI Referenced Properties/Methods for CIM_ElementConformsToProfile (Associates Domain object (e.g. System) to RegisteredProfile) .....	363
Table 404 - SMI Referenced Properties/Methods for CIM_ElementConformsToProfile (Associates RegisteredProfiles for SMI-S and domain profiles) .....	363
Table 405 - SMI Referenced Properties/Methods for CIM_ElementSoftwareIdentity (Profile and SW identity) .....	364
Table 406 - SMI Referenced Properties/Methods for CIM_ElementSoftwareIdentity (Subprofile and SW identity) .....	364
Table 407 - SMI Referenced Properties/Methods for CIM_Product.....	364
Table 408 - SMI Referenced Properties/Methods for CIM_ProductSoftwareComponent.....	365
Table 409 - SMI Referenced Properties/Methods for CIM_ReferencedProfile .....	365
Table 410 - SMI Referenced Properties/Methods for CIM_RegisteredProfile (Domain Registered Profile).....	366
Table 411 - SMI Referenced Properties/Methods for CIM_RegisteredProfile (The SMI-S Registered Profile).....	366
Table 412 - SMI Referenced Properties/Methods for CIM_RegisteredSubProfile .....	367
Table 413 - SMI Referenced Properties/Methods for CIM_SoftwareIdentity .....	368
Table 414 - SMI Referenced Properties/Methods for CIM_SubProfileRequiresProfile .....	368
Table 415 - Indication Profile Methods that cause Instance Creation, Deletion or Modification .....	380
Table 416 - CIM Elements for Indication.....	387
Table 417 - SMI Referenced Properties/Methods for CIM_AlertIndication .....	388
Table 418 - SMI Referenced Properties/Methods for CIM_IndicationFilter (client defined) .....	389
Table 419 - SMI Referenced Properties/Methods for CIM_IndicationFilter (pre-defined) .....	390
Table 420 - SMI Referenced Properties/Methods for CIM_IndicationSubscription.....	391
Table 421 - SMI Referenced Properties/Methods for CIM_InstCreation.....	392
Table 422 - SMI Referenced Properties/Methods for CIM_InstDeletion .....	393
Table 423 - SMI Referenced Properties/Methods for CIM_InstModification .....	393
Table 424 - SMI Referenced Properties/Methods for CIM_ListenerDestinationCIMXML (Indication Handler).....	394
Table 425 - Test that a Listener Destination is Functioning Properly .....	414
Table 426 - Discovery of Predefined IndicationFilters.....	414

Table 427 - Create a subscription to a predefined indication filter .....	415
Table 428 - Create an IndicationFilter and subscribe to it.....	415
Table 429 - Creation of a semi-fixed Indication filters .....	416
Table 430 - Creation of a client defined FilterCollection .....	416
Table 431 - CIM Elements for Experimental Indication .....	417
Table 432 - SMI Referenced Properties/Methods for CIM_AlertIndication .....	419
Table 433 - SMI Referenced Properties/Methods for CIM_ElementCapabilities (Indication Config Service to Capabilities) .....	420
Table 434 - SMI Referenced Properties/Methods for CIM_FilterCollection (Client Defined) .....	420
Table 435 - SMI Referenced Properties/Methods for CIM_FilterCollectionSubscription (Filter Collection Subscription) .....	421
Table 436 - SMI Referenced Properties/Methods for CIM_HostedCollection (Hosted Filter Collection) .....	421
Table 437 - SMI Referenced Properties/Methods for CIM_HostedService (Indication Config Service to System).....	422
Table 438 - SMI Referenced Properties/Methods for CIM_IndicationFilter (client defined) .....	422
Table 439 - SMI Referenced Properties/Methods for CIM_IndicationFilter (pre-defined) .....	423
Table 440 - SMI Referenced Properties/Methods for CIM_IndicationSubscription .....	424
Table 441 - SMI Referenced Properties/Methods for CIM_InstCreation .....	425
Table 442 - SMI Referenced Properties/Methods for CIM_InstDeletion .....	425
Table 443 - SMI Referenced Properties/Methods for CIM_InstModification .....	426
Table 444 - SMI Referenced Properties/Methods for CIM_ListenerDestinationCIMXML (Indication Handler).....	427
Table 445 - SMI Referenced Properties/Methods for CIM_ListenerDestinationWSManagement (WS-Man Indi- cation Handler).....	428
Table 446 - SMI Referenced Properties/Methods for CIM_MemberOfCollection (Filter Collection to Filters) .....	428
Table 447 - SMI Referenced Properties/Methods for SNIA_IndicationConfigurationCapabilities .....	429
Table 448 - SMI Referenced Properties/Methods for SNIA_IndicationConfigurationService .....	429
Table 449 - CIM Elements for Object Manager Adapter .....	431
Table 450 - SMI Referenced Properties/Methods for CIM_CommMechanismForObjectManagerAdapter .....	431
Table 451 - SMI Referenced Properties/Methods for CIM_ObjectManagerAdapter .....	432
Table 452 - Capabilities .....	434
Table 453 - AddSystem Method Parameters .....	435
Table 454 - AddSystem Return Codes .....	436
Table 455 - DiscoverSystem Parameters .....	436
Table 456 - DiscoverSystem Return Codes .....	437
Table 457 - RemoveSystem Parameters .....	437
Table 458 - CIM Elements for Proxy Server System Management .....	438
Table 459 - SMI Referenced Properties/Methods for CIM_HostedService.....	439
Table 460 - SMI Referenced Properties/Methods for SNIA_SystemRegistrationCapabilities .....	439
Table 461 - SMI Referenced Properties/Methods for SNIA_SystemRegistrationService .....	440
Table 462 - CIM Elements for Device Credentials .....	442
Table 463 - SMI Referenced Properties/Methods for CIM_HostedService.....	442
Table 464 - SMI Referenced Properties/Methods for CIM_SharedSecret .....	442
Table 465 - SMI Referenced Properties/Methods for CIM_SharedSecretIsShared.....	443
Table 466 - SMI Referenced Properties/Methods for CIM_SharedSecretService .....	443
Table 467 - Related Profiles for Operational Power.....	445
Table 468 - Creation, Deletion and Modification Methods .....	452
Table 469 - CIM Elements for Operational Power .....	457
Table 470 - SMI Referenced Properties/Methods for CIM_ElementCapabilities .....	459
Table 471 - SMI Referenced Properties/Methods for CIM_ElementStatisticalData (Optional Element Stats).....	459
Table 472 - SMI Referenced Properties/Methods for CIM_ElementStatisticalData	

(Top Level System Stats).....	460
Table 473 - SMI Referenced Properties/Methods for CIM_HostedCollection (Client Defined).....	460
Table 474 - SMI Referenced Properties/Methods for CIM_HostedCollection (Default).....	461
Table 475 - SMI Referenced Properties/Methods for CIM_HostedCollection (System to StatisticsCollection) .....	461
Table 476 - SMI Referenced Properties/Methods for CIM_HostedService.....	461
Table 477 - SMI Referenced Properties/Methods for CIM_MemberOfCollection (Member of client defined collection) .....	462
Table 478 - SMI Referenced Properties/Methods for CIM_MemberOfCollection (Member of power statistics collection).....	462
Table 479 - SMI Referenced Properties/Methods for CIM_MemberOfCollection (Member of pre-defined collection) .....	463
Table 480 - SMI Referenced Properties/Methods for CIM_StatisticsCollection .....	463
Table 481 - SMI Referenced Properties/Methods for SNIA_OperationalPowerManifest (Client Defined).....	464
Table 482 - SMI Referenced Properties/Methods for SNIA_OperationalPowerManifest (Provider Support).....	465
Table 483 - SMI Referenced Properties/Methods for SNIA_OperationalPowerManifestCollection (Client De- fined).....	465
Table 484 - SMI Referenced Properties/Methods for SNIA_OperationalPowerManifestCollection (Provider De- fined).....	466
Table 485 - SMI Referenced Properties/Methods for SNIA_OperationalPowerStatisticalData (Optional Ele- ment Stats).....	466
Table 486 - SMI Referenced Properties/Methods for SNIA_OperationalPowerStatisticalData (Top Level System Stats).....	467
Table 487 - SMI Referenced Properties/Methods for SNIA_OperationalPowerStatisticsCapabilities .....	468
Table 488 - SMI Referenced Properties/Methods for SNIA_OperationalPowerStatisticsService .....	468