ISO/IEC 29341-30-12:2017-06 (E)

Information technology - UPnP Device Architecture - Part 30-12: IoT management and control device control protocol - IoT management and control transport generic service

Contents

Page

1 Scope 1
2 Normative References 1
3 Terms, Definitions and Abbreviations 2
4 Notations and conventions 2
4.1 Notation 2
4.2 Data Types 3
4.3 Vendor-defined Extensions 3
5 Service Modelling Definitions 3
5.1 Service Type 3
5.2 SensorTransportGeneric Service Architecture 3
5.3 Key Concepts 3
5.3.1 Sensor Connectivity 3
5.3.2 Sensor HTTP/HTTPS Transport Protocol 4
5.4 State Variables 5
5.4.1 State Variable Overview 5
5.4.2 *A_ARG_TYPE_SensorID* 5
5.4.3 *A_ARG_TYPE_SensorURN* 5
5.4.4 *A_ARG_TYPE_SensorClientID* 5
5.4.5 *A_ARG_TYPE_DataRecords* 5
5.4.6 *A_ARG_TYPE_DataRecordCount* 7
5.4.7 *A_ARG_TYPE_TransportURL* 7
5.4.8 *A_ARG_TYPE_SensorDataTypeEnable* 7
5.4.9 *A_ARG_TYPE_SensorRecordInfo* 7
5.4.10 *A_ARG_TYPE_TransportConnectionID* 8
5.4.11 *A_ARG_TYPE_TransportConnections* 8
5.5 Actions 9
5.5.1 *ConnectSensor()* 9
5.5.2 *DisconnectSensor()* 12
5.5.3 *ReadSensor()* 13
5.5.4 *WriteSensor()* 14
5.5.5 *GetSensorTransportConnections()* 15
5.5.6 Error Code Summary 16
6 XML Service Description 17

Table 1 — State Variables 5
Table 2 — Actions 9
Table 3 — Arguments for *ConnectSensor()* 9
Table 4 — Error Codes for *ConnectSensor()* 11
Table 5 — Arguments for *DisconnectSensor()* 12
Table 6 — Error Codes for *DisconnectSensor()* 12
Table 7 — Arguments for *ReadSensor()* 13
Table 8 — Error Codes for *ReadSensor()* 14
Table 9 — Arguments for *WriteSensor()* 14
Table 10 — Error Codes for *WriteSensor()* 15
Table 11 — Arguments for *GetSensorTransportConnections()* 16
Table 12 — Error Codes for *GetSensorTransportConnections()* 16
Table 13 — Error Code Summary 16