ISO/IEC 29341-24-10:2017-09 (E)

Information technology - UPnP Device Architecture - Part 24-10: Internet gateway device control protocol - Level 2 - Wide area network internet protocol - Connection service

Contents

Page

1 Scope 1

2 Normative references 1

3 Terms, definitions, symbols and abbreviated terms 2

4 Notations and conventions 4
4.1 Notation 4
4.2 Data types 4
4.2.1 Primary data types 4
4.2.2 Secondary data types 5
4.3 Vendor-defined extensions 6

5 Service model 6
5.1 Service type 6
5.2 Changes from WANIPConnection:1 6
5.2.1 Backward compatibility 6
5.2.2 Generic requirements and other changes 6
5.2.3 New state variables 6
5.2.4 New actions 6
5.2.5 Changes in existing actions and procedures 7
5.3 Service Architecture 7
5.3.1 Introduction 7
5.3.2 Main feature sets 8
5.4 State variables 9
5.4.1 State variable overview 9
5.4.2 ConnectionType 11
5.4.3 PossibleConnectionTypes 11
5.4.4 ConnectionStatus 11
5.4.5 Uptime 12
5.4.6 LastConnectionError 12
5.4.7 AutoDisconnectTime 12
5.4.8 IdleDisconnectTime 13
5.4.9 WarnDisconnectDelay 13
5.4.10 RSIPAvailable 13
5.4.11 NATEnabled 13
5.4.12 ExternalIPAddress 13
5.4.13 PortMappingNumberOfEntries 13
5.4.14 PortMappingEnabled 14
5.4.15 PortMappingLeaseDuration 14
5.4.16 RemoteHost 14
5.4.17 ExternalPort 14
5.4.18 InternalPort 15
5.4.19 PortMappingProtocol 15
5.4.20 InternalClient 15
5.4.21 PortMappingDescription 15
5.4.22 SystemUpdateID 15
5.4.23 A_ARG_TYPE_Manage 16
5.4.24 A_ARG_TYPE_PortListing 16

5.5 Eventing and Moderation 17
5.5.1 Eventing of PossibleConnectionTypes 18
5.5.2 Eventing of ConnectionStatus 18
5.5.3 Eventing of ExternalIPAddress 18
5.5.4 Eventing of PortMappingNumberOfEntries 18
5.5.5 Eventing of SystemUpdateID 18
5.5.6 Relationships among State Variables 18
5.6 Actions 19
5.6.1 SetConnectionType() 20
5.6.2 GetConnectionTypeInfo() 21
5.6.3 RequestConnection() 22
5.6.4 RequestTermination() 23
5.6.5 ForceTermination() 24
5.6.6 SetAutoDisconnectTime() 25
5.6.7 SetIdleDisconnectTime() 26
5.6.8 SetWarnDisconnectDelay() 27
5.6.9 GetStatusInfo() 27
5.6.10 GetAutoDisconnectTime() 28
5.6.11 GetIdleDisconnectTime() 29
5.6.12 GetWarnDisconnectDelay() 30
5.6.13 GetNATRSIPStatus() 31
5.6.14 GetGenericPortMappingEntry() 31
5.6.15 GetSpecificPortMappingEntry() 33
5.6.16 AddPortMapping() 34
5.6.17 AddAnyPortMapping() 38
5.6.18 DeletePortMapping() 40
5.6.19 DeletePortMappingRange() 42
5.6.20 GetExternalIPAddress() 43
5.6.21 GetListOfPortMappings() 44
5.6.22 Relationships Between Actions 45
5.6.23 Error Code Summary 45
5.7 Service Behavioral Model 47
5.7.1 Connection Initiation 47
5.7.2 Connection Termination 48

6 XML Service Description 49

Annex A (informative) Theory of Operation 61

Annex B (informative) Bibliography 65

Figure 1 -- UPnP IGD component relationships for NAT processing 10

Figure 2 -- Example of relationship between AddPortMapping() action and port triggering 35

Figure 3 -- Summary of AddPortMapping() results 37

Figure 4 -- Summary of AddAnyPortMapping() results 40

Figure 5 -- State diagram for IP connection 47

Figure A.1 -- NAT is an IP address translator 63

Figure A.2 -- NAT issue with bundled session applications 64

Table 1 -- CSV examples 5

Table 2 -- State Variables 9

Table 3 -- allowedValueList for the ConnectionType state variable 11

Table 4 -- allowedValueList for the ConnectionStatus state variable 11

Table 5 -- allowedValueList for the LastConnectionError state variable 12
Table 6 -- allowedValueRange for the PortMappingLeaseDuration state variable 14
Table 7 -- allowedValueRange for the InternalPort state variable 15
Table 8 -- allowedValueList for the PortMappingProtocol state variable 15
Table 9 -- Eventing and Moderation 17
Table 10 -- Actions 19
Table 11 -- Common parameters 19
Table 12 -- Arguments for SetConnectionType() 20
Table 13 -- Error Codes for SetConnectionType() 21
Table 14 -- Arguments for GetConnectionTypeInfo() 21
Table 15 -- Error Codes for GetConnectionTypeInfo() 22
Table 16 -- Error Codes for RequestConnection() 23
Table 17 -- Error Codes for RequestTermination() 24
Table 18 -- Error Codes for ForceTermination() 25
Table 19 -- Arguments for SetAutoDisconnectTime() 25
Table 20 -- Error Codes for SetAutoDisconnectTime() 26
Table 21 -- Arguments for SetIdleDisconnectTime() 26
Table 22 -- Error Codes for SetIdleDisconnectTime() 27
Table 23 -- Arguments for SetWarnDisconnectDelay() 27
Table 24 -- Error Codes for SetWarnDisconnectDelay() 27
Table 25 -- Arguments for GetStatusInfo() 28
Table 26 -- Error Codes for GetStatusInfo() 28
Table 27 -- Arguments for GetAutoDisconnectTime() 28
Table 28 -- Error Codes for GetAutoDisconnectTime() 29
Table 29 -- Arguments for GetIdleDisconnectTime() 29
Table 30 -- Error Codes for GetIdleDisconnectTime() 30
Table 31 -- Arguments for GetWarnDisconnectDelay() 30
Table 32 -- Error Codes for GetWarnDisconnectDelay() 30
Table 33 -- Arguments for GetNATRSIPStatus() 31
Table 34 -- Error Codes for GetNATRSIPStatus() 31
Table 35 -- Arguments for GetGenericPortMappingEntry() 32

Table 36 -- Error Codes for GetGenericPortMappingEntry() 33

Table 37 -- Arguments for GetSpecificPortMappingEntry() 33

Table 38 -- Error Codes for GetSpecificPortMappingEntry() 34

Table 39 -- Arguments for AddPortMapping() 35

Table 40 -- Error Codes for AddPortMapping() 37

Table 41 -- Arguments for AddAnyPortMapping() 38

Table 42 -- Error Codes for AddAnyPortMapping() 40

Table 43 -- Arguments for DeletePortMapping() 41

Table 44 -- Error Codes for DeletePortMapping() 41

Table 45 -- Arguments for DeletePortMappingRange() 42

Table 46 -- Error Codes for DeletePortMappingRange() 43

Table 47 -- Arguments for GetExternalIPAddress() 43

Table 48 -- Error Codes for GetExternalIPAddress() 44

Table 49 -- Arguments for GetListOfPortMappings() 44

Table 50 -- Error Codes for GetListOfPortMappings() 45

Table 51 -- Error Code Summary 46

Table A.1 -- Connection Procedures 61