ISO/IEC 14543-3-4:2007-01 (E)

Information technology – Home electronic system (HES) architecture – Part 3-4: System management – Management procedures for network based control of HES Class 1

CONTENTS

FOREWORD 7
INTRODUCTION 9
1 Scope 10
2 Normative references 10
3 Terms, definitions and abbreviations 11
3.1 Terms and definitions 11
3.2 Abbreviations 13
4 Conformance 13
5 Network management procedures 13
5.1 General 13
5.2 NM_IndividualAddress_Read 14
5.2.1 Description 14
5.2.2 Management service used 14
5.2.3 Sequence 14
5.2.4 Exception handling 14
5.3 NM_IndividualAddress_Write 14
5.3.1 Description 14
5.3.2 Management services used 15
5.3.3 Sequence 15
5.3.4 Exception handling 16
5.4 NM_SerialNumberDefaultIA_Scan 16
5.4.1 Description 16
5.4.2 Management service used 16
5.4.3 Sequence 17
5.4.4 Exception handling 17
5.5 NM_IndividualAddress_SerialNumber_Read 17
5.5.1 Description 17
5.5.2 Management service used 17
5.5.3 Sequence 17
5.5.4 Exception handling 18
5.6 NM_IndividualAddress_SerialNumber_Write 18
5.6.1 Description 18
5.6.2 Management services used 18
5.6.3 Sequence 18
5.6.4 Exception handling 18
5.7 NM_DomainAddress_Read 19
5.7.1 Description 19
5.7.2 Management service used 19
5.7.3 Sequence 19
5.7.4 Exception handling 19
5.8 NM_DomainAddress_Write 19
5.8.1 Description 19
5.8.2 Management services used 20
5.8.3 Sequence 20

5.8.4 Exception handling 21
5.9 NM_DomainAddress_Scan 21
5.9.1 Description 21
5.9.2 Management service used 21
5.9.3 Sequence 22
5.9.4 Exception handling 22
5.10 NM_Router_Scan 22
5.10.1 Description 22
5.10.2 Management service used 22
5.10.3 Sequence 23
5.11 NM_SubnetworkDevices_Scan 23
5.11.1 Description 23
5.11.2 Management service used 23
5.11.3 Sequence 23
5.12 NM_SubnetworkAddress_Read 24
5.12.1 Description 24
5.12.2 Management service used 24
5.12.3 Sequence 24
5.12.4 Exception handling 24
5.13 NM_IndividualAddress_Reset 24
5.13.1 Description 24
5.13.2 Management services used 24
5.13.3 Sequence 25
5.14 NM_IndividualAddress_Scan 25
5.14.1 Description 25
5.14.2 Management services used 25
5.14.3 Sequence 26
5.14.4 Possible reactions 26
5.15 NM_IndividualAddress_Check 26
5.15.1 Description 26
5.15.2 Management services used 26
5.15.3 Sequence 27
5.16 NM_IndividualAddress_Check_LocalSubnetwork 27
5.16.1 Description 27
5.16.2 Management service used 27
5.16.3 Sequence 28
5.17 NM_GroupAddress_Check 28
5.17.1 Description 28
5.17.2 Management service used 28
5.17.3 Sequence 28
5.17.4 Exception handling 29
5.18 NM_FunctionalBlock_Scan 29
5.18.1 Description 29
5.18.2 Management service used 29
5.18.3 Sequence 29
5.18.4 Exception handling 29
Device management procedures 30
6.1 General 30
6.2 General exception handling 30

6.3 DM_Connect 30
6.3.1 General Description 30
6.3.2 Procedure: DMP_Connect_RCo 30
6.3.3 Procedure: DMP_Connect_RCl 31
6.4 DM_Disconnect 32
6.4.1 General description 32
6.4.2 Procedure: DMP_Disconnect_RCo 32
6.4.3 Procedure: DMP_Disconnect_RCl 32
6.5 DM_Authorize 33
6.5.1 General description 33
6.5.2 Procedure: DMP_Authorize_RCo 33
6.6 DM_SetKey 33
6.6.1 General description 33
6.6.2 Procedure: DM_SetKey_RCo 34
6.7 DM_Restart 34
6.7.1 General description 34
6.7.2 Procedure: DM_Restart_RCo 34
6.8 DM_Delay 35
6.8.1 Description 35
6.8.2 Procedure: DMP_Delay 35
6.9 DM_IndividualAddressRead 35
6.10 DM_IndividualAddressWrite 35
6.11 DM_DomainAddressRead 36
6.12 DM_DomainAddressWrite 36
6.13 DM_ProgMode_Switch 36
6.13.1 Description 36
6.13.2 Procedure: DMP_ProgModeSwitch_RCo 36
6.14 DM_GroupObject_Link_Read 37
6.14.1 Description 37
6.14.2 Management service used 37
6.14.3 Sequence 37
6.14.4 Exception handling 37
6.15 DM_GroupObject_Link_Write 37
6.15.1 Description 37
6.15.2 Management services used 38
6.15.3 Sequence 38
6.15.4 Exception handling 38
6.16 DM_MemWrite 38
6.16.1 General description 38
6.16.2 Procedure: DMP_MemWrite_RCo 39
6.16.3 Procedure: DMP_MemWrite_RCoV 40
6.17 DM_MemVerify 41
6.17.1 General description 41
6.17.2 Procedure: DMP_MemVerify_RCo 42
6.18 DM_MemRead 42
6.18.1 General description 42
6.18.2 Procedure: DMP_MemRead_RCo 43
6.19 DM_UserMemWrite 43
6.19.1 General description 43

6.19.2 Procedure: DMP_UserMemWrite_RCo 44
6.19.3 Procedure: DMP_UserMemWrite_RCoV 45
6.20 DM_UserMemVerify 46
6.20.1 General description 46
6.20.2 Procedure: DMP_UserMemVerify_RCo 46
6.21 DM_UserMemRead 47
6.21.1 General description 47
6.21.2 Procedure: DMP_UserMemRead_RCo 47
6.22 DM_InterfaceObjectWrite 48
6.22.1 General description 48
6.22.2 Procedure: DMP_InterfaceObjectWrite_R 48
6.23 DM_InterfaceObjectVerify 49
6.23.1 General description 49
6.23.2 Procedure: DMP_InterfaceObjectVerify_R 50
6.24 DM_InterfaceObjectRead 51
6.24.1 General description 51
6.24.2 Procedure: DMP_InterfaceObjectRead_R 51
6.25 DM_InterfaceObjectScan 52
6.25.1 General description 52
6.25.2 Procedure: DMP_InterfaceObjectScan_R 53
6.26 DM_LoadStateMachineWrite 54
6.26.1 General description 54
6.26.2 Procedure: DMP_LoadStateMachineWrite_RCo_Mem 56
6.26.3 Procedure: DMP_LoadStateMachineWrite_RCo_IO 59
6.27 DM_LoadStateMachineVerify 62
6.27.1 General description 62
6.27.2 Procedure: DM_LoadStateMachineVerify_RCo_Mem 63
6.27.3 Procedure: DMP_LoadStateMachineVerify_R_IO 64
6.28 DM_LoadStateMachineRead 64
6.28.1 General description 64
6.28.2 Procedure: DMP_LoadStateMachineRead_RCo_Mem 65
6.28.3 Procedure: DMP_LoadStateMachineRead_R_IO 66
6.29 DM_RunStateMachineWrite 67
6.29.1 General description 67
6.29.2 Procedure: DMP_RunStateMachineWrite_RCo_Mem 67
6.29.3 Procedure: DMP_RunStateMachineWrite_R_IO 68
6.30 DM_RunStateMachineVerify 69
6.30.1 General description 69
6.30.2 Procedure: DMP_RunStateMachineVerify_RCo_Mem 70
6.30.3 Procedure: DMP_RunStateMachineVerify_R_IO 70
6.31 DM_RunStateMachineRead 71
6.31.1 General description 71
6.31.2 Procedure: DMP_RunStateMachineRead_RCo_Mem 72
6.31.3 Procedure: DMP_RunStateMachineRead_R_IO 72
6.32 DM_LCSlaveMemWrite 73
6.32.1 General description 73
6.32.2 Procedure: DMP_LCSlaveMemWrite_RCo 74
6.33 DM_LCSlaveMemVerify 75
6.33.1 General description 75

6.33.2 Procedure: DMP_LCSlaveMemVerify_RCo 75
6.34 DM_LCSlaveMemRead 76
6.34.1 General description 76
6.34.2 Procedure: DMP_LCSlaveMemRead_RCo 76
6.35 DM_LCExtMemWrite 77
6.35.1 General description 77
6.35.2 Procedure: DMP_LCExtMemWrite_RCo 78
6.36 DM_LCExtMemVerify 79
6.36.1 General description 79
6.36.2 Procedure: DMP_LCExtMemVerify_RCo 80
6.37 DM_LCExtMemRead 80
6.37.1 General description 80
6.37.2 Procedure: DMP_LCExtMemRead_RCo 81
6.38 DM_LCExtMemOpen 81
6.38.1 General description 81
6.38.2 Procedure: DMP_LCExtMemOpen_RCo 82
6.39 DM_LCRouteTableStateWrite 82
6.39.1 General description 82
6.39.2 Procedure: DMP_LCRouteTableStateWrite_RCo 82
6.40 DM_LCRouteTableStateVerify 83
6.40.1 General description 83
6.40.2 Procedure: DMP_LCRouteTableStateVerify_RCo 83
6.41 DM_LCRouteTableStateRead 84
6.41.1 General description 84
6.41.2 Procedure: DMP_LCRouteTableStateRead_RCo 84
Bibliography 86

Table 1 – Resulting states after each event 55
Table 2 – Overview state machine types and tables 55
Table 3 – Overview addresses for the load management controls 56
Table 4 – Addresses of the load state controls 63
Table 5 – Addresses of the load state controls 65
Table 6 – Run state events and resulting run states 67
Table 7 – Addresses of the run state controls 68