

ISO 14404-2:2024-09 (E)

Calculation method of carbon dioxide emission intensity from iron and steel production - Part 2: Steel plant with electric arc furnace (EAF)

Contents		Page
Foreword		iv
Introduction		v
1	Scope	1
2	Normative references	1
3	Terms and definitions	1
3.1	Emissions	1
3.2	Gas fuel	2
3.3	Liquid fuel	2
3.4	Solid fuel	3
3.5	Auxiliary material	3
3.6	Energy carriers	4
3.7	Ferrous containing materials	4
3.8	Alloys	5
3.9	Other imported/exported materials	5
3.10	Others	5
4	Symbols	6
5	Principles	7
5.1	General	7
5.2	Relevance	7
5.3	Completeness	7
5.4	Consistency	7
5.5	Accuracy	7
5.6	Transparency	7
6	Boundary	8
6.1	General	8
6.2	Category 1	8
6.3	Category 2	9
6.4	Category 3	9
6.5	Category 4	9
7	Calculation	9
7.1	General	9
7.2	Calculation procedure	9
7.2.1	Data collection of crude steel production	9
7.2.2	Data collection direct and/or upstream CO2 emission sources	10
7.2.3	Data collection of credit CO2 emission sources	11
7.2.4	Calculation	12
Annex A (informative) Calculation of energy consumption and intensity		15
Annex B (informative) Example of template for using different emission factors or emission sources from Table 4		17
Annex C (informative) Example of CO2 emission and intensity calculations for steel plant -- Data of a steel plant		19
Annex D (informative) Decarbonization strategies and its impact on CO2 calculation method		22
Bibliography		23