# ISO 21978:2023-12 (E)

## Air to water heat pumps - Testing and rating at part load conditions and calculation of seasonal coefficient of performance for space heating

## Contents

Page


**Foreword** ..... **v**

**Introduction** ..... **vi**

**1 Scope** ..... **1**

**2 Normative references** ..... **1**

**3 Terms and definitions** ..... **1**

**4 Symbols** ..... **8**

**5 Installation requirements** ..... **9**
5.1 Test apparatus and uncertainties of measurement ..... 9
5.2 Test room for the airside ..... 10
5.3 Installation and connection of the heat pump ..... 10
5.4 Installation of heat pumps consisting of several parts ..... 11
5.5 Environment conditions for indoor unit installation and electrical power supply requirements ..... 11

**6 Setting and part load test conditions** ..... **11**
6.1 General ..... 11
6.2 Setting for capacity ratio ..... 11
6.3 Setting the external static pressure difference for ducted units ..... 11
6.4 Setting of units with integral pumps ..... 12
6.5 Part load test conditions ..... 12

**7 Space heating test** ..... **15**
7.1 Heating capacity test ..... 15
7.2 Heating capacity correction ..... 16
7.2.1 General ..... 16
7.2.2 Capacity correction due to indoor liquid pump ..... 16
7.2.3 Effective power input ..... 17
7.3 Test procedure ..... 19
7.3.1 General ..... 19
7.3.2 Permissible deviations ..... 19
7.3.3 Preconditioning period ..... 20
7.3.4 Equilibrium period ..... 21
7.3.5 Data collection period ..... 21
7.4 Heating capacity calculation ..... 21
7.4.1 Steady state capacity test ..... 21
7.4.2 Transient capacity test ..... 21
7.5 Effective power input calculation ..... 21
7.5.1 Steady state test ..... 21
7.5.2 Transient capacity test ..... 21
7.6 Determination of degradation coefficient $C_d$ ..... 21
7.7 Test methods for electric power input during thermostat-off mode, standby mode, crankcase heater mode and off mode ..... 22
7.7.1 Uncertainties of measurement ..... 22
7.7.2 Measurement of electric power input during thermostat-off mode ..... 22
7.7.3 Measurement of electric power input during standby mode ..... 23
7.7.4 Measurement of electric power input during crankcase heater mode ..... 23
7.7.5 Measurement of electric power input during off mode ..... 23

**8 Calculation methods for seasonal coefficient of performance ($S_{COP}$) ..... 23**
8.1 General formula for calculation of $S_{COP}$ ..... 23
8.2 Calculation of the reference annual heating demand, $Q_H$ ..... 24
8.3 Calculation of the annual energy consumption, $Q_{HE}$ ..... 24
8.4 Calculation of $S_{COP,on}$ and $S_{COP,net}$ ..... 24
8.5 Calculation procedure for determination of $C_{Pb}$ values at part load conditions A to G ..... 26
8.5.1 General ..... 26
8.5.2 Calculation procedure for fixed capacity units ..... 26
8.5.3 Calculation procedure for staged and variable capacity units ..... 26

**9 Test results and test report ..... 27**
9.1 Data ..... 27
9.2 Test report ..... 28

**10 Marking provisions ..... 29**
10.1 General ..... 29
10.2 Nameplate requirements ..... 29
10.3 Nameplate information ..... 29

**Annex A** (normative) **Heating capacity test procedures given in 7.3 ..... 30**

**Annex B** (normative) **Determination of the liquid pump efficiency ..... 36**

**Annex C** (informative) **Examples of set of bin hours and hours for active mode, thermostat-off mode, standby mode, off mode and crankcase heater mode ..... 40**

**Annex D** (informative) **$S_{COP,on}$ and $S_{COP,net}$ calculation for fixed capacity for 35 °C temperature application — Example ..... 42**

**Annex E** (informative) **$S_{COP,on}$ and $S_{COP,net}$ calculation for variable capacity unit for 35 °C temperature application — Example ..... 46**

**Bibliography ..... 50**