

# DIN EN 14175-6:2006-08 (E)

## Fume cupboards - Part 6: Variable air volume fume cupboards

---

<b>Contents</b>		<b>Page</b>
Foreword .....		3
Introduction .....		4
<b>1</b>	<b>Scope .....</b>	<b>5</b>
<b>2</b>	<b>Normative references .....</b>	<b>5</b>
<b>3</b>	<b>Terms and definitions .....</b>	<b>5</b>
<b>4</b>	<b>Requirements .....</b>	<b>5</b>
4.1	General .....	5
4.2	System status port .....	6
4.3	Air flow indicator .....	6
<b>5</b>	<b>Type test methods .....</b>	<b>6</b>
5.1	General .....	6
5.2	Test conditions .....	6
5.2.1	VAV fume cupboards (see 5.4) .....	6
5.2.2	VAV systems (see 5.3) .....	6
5.3	Test of VAV systems .....	6
5.3.1	General .....	6
5.3.2	Tests for air flow rate characteristics .....	7
5.3.3	Tests for dynamic control behaviour .....	9
5.3.4	Test of set points .....	11
5.4	Test of VAV fume cupboards .....	12
5.4.1	Test installation .....	12
5.4.2	Test of the integrated VAV system .....	12
5.4.3	Test of the VAV fume cupboard .....	12
<b>6</b>	<b>On-site test methods .....</b>	<b>12</b>
6.1	General .....	12
6.2	Extract volume flow rate at set points .....	12
6.3	Test of set points .....	12
6.4	Test of response time .....	13
6.5	Containment .....	13
6.6	Air exchange at minimum volume flow rate .....	13
<b>7</b>	<b>Product manual .....</b>	<b>13</b>
<b>8</b>	<b>Marking and labelling .....</b>	<b>13</b>
<b>9</b>	<b>Test reports .....</b>	<b>13</b>
9.1	Type test report for VAV systems .....	13
9.2	Type test report for VAV fume cupboards .....	14
9.3	On-site test report for VAV fume cupboards .....	14
Bibliography .....		16