ISO 4126-10:2024-03 (E)

Safety devices for protection against excessive pressure - Part 10: Sizing of safety valves and bursting discs for gas/liquid two-phase flow

Contents

Page

Foreword ..... **v**

Introduction ..... **vi**

1 Scope **1**

2 Normative references **1**

3 Terms and definitions **1**
3.1 General 1
3.2 Pressure 2
3.3 Flow rate 4
3.4 Flow area 5
3.5 Fluid state 5
3.6 Temperature 5

4 Symbols and abbreviated terms and figures **6**
4.1 Symbols 6
4.2 Abbreviated terms 8
4.3 Figures 9

5 Application range of the method **11**
5.1 General 11
5.2 Limitations of the method for calculating the two-phase mass flux in safety devices 11
5.2.1 Flashing flow 11
5.2.2 Condensing flow 12
5.2.3 Flashing flow for multi-component liquids 12
5.2.4 Dissolved gases 12
5.2.5 Compressibility coefficient ω 13
5.3 Limitations of the method for calculating the mass flow rate required to be discharged 13
5.3.1 Rate of temperature and pressure increase 13
5.3.2 Immiscible liquids 13

6 Sizing steps **13**
6.1 General outline of sizing steps 13
6.2 Step 1 — Identification of the sizing case 14
6.3 Step 2 — Flow regime at the inlet of the vent line system 15
6.3.1 General 15
6.3.2 Phenomenon of level swell 15
6.3.3 Influence of liquid viscosity and foaming behaviour on the flow regime 15
6.3.4 Prediction of the flow regime (gas/vapour or two-phase flow) 17
6.4 Step 3 — Calculation of the mass flow rate required to be discharged 20
6.4.1 General 20
6.4.2 Pressure increase caused by an excess in-flow 20
6.4.3 Pressure increase due to external heating 22
6.4.4 Pressure increase due to thermal runaway reactions 25
6.5 Step 4 — Calculation of the dischargeable mass flux through and pressure change in the vent line system 29
6.5.1 General 29
6.5.2 Two-phase flow discharge coefficient, $K_{\mathrm{dr,2ph}}$ 32
6.5.3 Dimensionless mass flow rate, C 33
6.5.4 Compressibility coefficient, ω (numerical method) 34
6.5.5 Calculation of the downstream stagnation condition 35
6.5.6 Slip correction for non-flashing two-phase flow 35
6.5.7 Slip correction for two-phase flow in straight pipes 36

6.6 Step 5 — Ensure proper operation of safety valve vent line systems under plant conditions ... 36
6.7 Simultaneous calculation of the dischargeable mass flux and pressure change in the vent line system ... 36
6.8 Summary of calculation procedure ... 37

Annex A (informative) **Identification of sizing scenarios** ... **44**

Annex B (informative) **Example calculation of the mass flow rate to be discharged** ... **46**

Annex C (informative) **Example of calculation of the dischargeable mass flux and pressure change through connected vent line systems** ... **50**

Annex D (informative) **Environmental factor** ... **67**

Bibliography ... **68**