

# ISO 28981:2009-11 (E)

## Mopeds - Methods for setting the running resistance on a chassis dynamometer

---

<b>Contents</b>		<b>Page</b>
Foreword .....		iv
Introduction .....		v
1	Scope .....	1
2	Normative references .....	1
3	Terms and definitions .....	1
4	Symbols .....	2
5	Test moped, chassis dynamometer and instruments .....	3
6	Required accuracy of measurements .....	4
7	Road test .....	4
7.1	Requirement for road .....	4
7.2	Ambient conditions for the road test .....	4
7.3	Reference speed .....	5
7.4	Specified speed .....	5
7.5	Coastdown starting speed .....	5
7.6	Coastdown time measurement beginning speed and ending speed .....	5
7.7	Preparation of test moped .....	5
7.8	Rider and riding position .....	6
7.9	Measurement of coastdown time .....	6
8	Data processing .....	8
8.1	Calculation of running resistance force .....	8
8.2	Running resistance curve fitting .....	8
8.3	Target running resistance force for chassis dynamometer setting .....	8
9	Chassis dynamometer setting derived from on-road coastdown measurements .....	8
9.1	Requirements for the equipment .....	8
9.2	Inertia mass setting .....	9
9.3	Warming up of chassis dynamometer .....	9
9.4	Adjustment of tyre pressures .....	9
9.5	Moped warming up .....	9
9.6	Procedures for setting chassis dynamometer .....	9
9.7	Verification of chassis dynamometer .....	12
10	Chassis dynamometer setting using the running resistance table .....	12
10.1	Applicability .....	12
10.2	Requirements for the equipment .....	12
10.3	Setting the running resistance force on the chassis dynamometer .....	14
10.4	The specified speed for the chassis dynamometer .....	14
10.5	Verification of chassis dynamometer .....	14
Annex A (normative)	Moped description .....	16
Annex B (normative)	Chassis dynamometer and instruments description .....	18
Annex C (informative)	Record of coastdown time and chassis dynamometer setting .....	20
Bibliography .....		23