

# ISO 21215:2010-11 (E)

## Intelligent transport systems - Communications access for land mobiles (CALM) - M5

---

<b>Contents</b>		<b>Page</b>
Foreword .....		iv
Introduction .....		v
<b>1</b>	<b>Scope .....</b>	<b>1</b>
<b>2</b>	<b>Normative references .....</b>	<b>1</b>
<b>3</b>	<b>Terms and definitions .....</b>	<b>2</b>
<b>4</b>	<b>Symbols and abbreviated terms .....</b>	<b>2</b>
<b>5</b>	<b>Requirements .....</b>	<b>3</b>
<b>6</b>	<b>Architecture .....</b>	<b>4</b>
<b>7</b>	<b>Communication interface protocol stack .....</b>	<b>5</b>
7.1	Physical layer .....	5
7.2	Medium access control layer .....	7
7.2.1	General .....	7
7.2.2	Elements .....	7
7.2.3	MAC procedures .....	11
7.3	Logical link control sub-layer .....	12
7.4	Communication adaptation layer .....	12
7.4.1	General .....	12
7.4.2	Elements .....	12
7.4.3	CAL procedures .....	15
<b>8</b>	<b>Communication interface management .....</b>	<b>17</b>
8.1	Communication module management entity .....	17
8.2	Communication interface management adaptation entity .....	17
8.2.1	Mapping of 802.11 parameters .....	17
8.2.2	Mapping of 802.11 commands .....	17
8.2.3	Management frames .....	18
8.2.4	Cross-CI prioritization procedure .....	18
8.2.5	CI registration .....	19
8.2.6	VCI deletion .....	19
8.2.7	Regulatory information management .....	20
8.2.8	MI-parameters .....	20
<b>9</b>	<b>Conformance .....</b>	<b>22</b>
<b>10</b>	<b>Test methods .....</b>	<b>22</b>
<b>11</b>	<b>Marking, labelling and packaging .....</b>	<b>22</b>
<b>Annex A (normative)</b>	<b>Parameters .....</b>	<b>23</b>
<b>Annex B (normative)</b>	<b>MI-COMMAND .....</b>	<b>31</b>
<b>Annex C (normative)</b>	<b>MI-REQUEST .....</b>	<b>32</b>

<b>Annex D (normative) Management frame MAC commands .....</b>	<b>33</b>
<b>Annex E (normative) ASN.1 definitions .....</b>	<b>34</b>
<b>Annex F (informative) Operation in Europe .....</b>	<b>37</b>
<b>Bibliography .....</b>	<b>39</b>