

# ISO 17458-5:2013-02 (E)

## Road vehicles - FlexRay communications system - Part 5: Electrical physical layer conformance test specification

---

Contents	Page
<b>Foreword .....</b>	<b>v</b>
<b>Introduction .....</b>	<b>vi</b>
<b>1 Scope .....</b>	<b>1</b>
<b>2 Normative references .....</b>	<b>1</b>
<b>3 Terms, definitions, symbols and abbreviated terms .....</b>	<b>1</b>
<b>3.1 Terms and definitions .....</b>	<b>1</b>
<b>3.2 Abbreviated terms .....</b>	<b>2</b>
<b>4 Document reference according to OSI model .....</b>	<b>3</b>
<b>5 Conventions .....</b>	<b>4</b>
<b>5.1 General .....</b>	<b>4</b>
<b>5.2 Notational conventions .....</b>	<b>4</b>
<b>6 Test environment .....</b>	<b>4</b>
<b>6.1 Test case architecture .....</b>	<b>4</b>
<b>6.2 Test method .....</b>	<b>5</b>
<b>6.3 Test environment .....</b>	<b>9</b>
<b>6.4 Test topology .....</b>	<b>9</b>
<b>6.5 Test equipment .....</b>	<b>27</b>
<b>7 Stress Conditions .....</b>	<b>34</b>
<b>7.1 Ground shift .....</b>	<b>34</b>
<b>7.2 Low battery voltage inside operational range .....</b>	<b>35</b>
<b>7.3 Undervoltage .....</b>	<b>36</b>
<b>7.4 Dynamic low battery voltage .....</b>	<b>37</b>
<b>7.5 Dynamic low supply voltage .....</b>	<b>38</b>
<b>7.6 Failures .....</b>	<b>41</b>
<b>7.7 Babbling idiot .....</b>	<b>47</b>
<b>7.8 Dynamic ground shift .....</b>	<b>47</b>
<b>7.9 EMC .....</b>	<b>48</b>
<b>7.10 ESD .....</b>	<b>48</b>
<b>7.11 Temperature tests .....</b>	<b>48</b>
<b>7.12 Common mode offset .....</b>	<b>48</b>
<b>8 Parameter List .....</b>	<b>49</b>
<b>8.1 General .....</b>	<b>49</b>
<b>8.2 Static test cases .....</b>	<b>50</b>
<b>8.3 Communication .....</b>	<b>50</b>
<b>8.4 Host Interface .....</b>	<b>54</b>
<b>8.5 Mode .....</b>	<b>55</b>
<b>8.6 Power supply .....</b>	<b>59</b>
<b>8.7 Environment .....</b>	<b>61</b>
<b>8.8 Dynamic low battery voltage .....</b>	<b>62</b>
<b>8.9 Dynamic low supply voltage .....</b>	<b>62</b>
<b>8.10 Failure .....</b>	<b>62</b>
<b>8.11 Functional class .....</b>	<b>65</b>

<b>8.12</b>	<b>Simulation .....</b>	<b>65</b>
<b>9</b>	<b>Test Cases for Bus Drivers .....</b>	<b>65</b>
9.1	Configuration .....	66
9.2	Static test cases .....	89
9.3	Test cases .....	97
<b>10</b>	<b>Test cases for Active Stars .....</b>	<b>563</b>
10.1	General .....	563
10.2	Configuration .....	563
10.3	Static test cases .....	577
10.4	Test cases .....	584
<b>11</b>	<b>Test cases for Active Stars with communication controller interface .....</b>	<b>717</b>
11.1	Configuration .....	717
11.2	Static test cases .....	724
11.3	Test cases .....	728
<b>12</b>	<b>Test Cases for Active Stars with host interface .....</b>	<b>795</b>
12.1	Configuration .....	795
12.2	Static test cases .....	800
12.3	Test cases .....	803
<b>Annex A (normative) FlexRay parameters .....</b>		<b>922</b>
<b>Bibliography .....</b>		<b>930</b>