

# ISO 14230-2:2016-08 (E)

## Road vehicles - Diagnostic communication over K-Line (DoK-Line) - Part 2: Data link layer

---

<b>Contents</b>		<b>Page</b>
<b>Foreword</b> .....		<b>v</b>
<b>Introduction</b> .....		<b>vi</b>
<b>1 Scope</b> .....		<b>1</b>
<b>2 Normative references</b> .....		<b>1</b>
<b>3 Terms, definitions, symbols and abbreviated terms</b> .....		<b>1</b>
3.1 Terms and definitions.....		1
3.2 Symbols and abbreviated terms.....		2
<b>4 Conventions</b> .....		<b>3</b>
<b>5 Document overview</b> .....		<b>4</b>
<b>6 Physical bus topology</b> .....		<b>5</b>
<b>7 Data link layer overview</b> .....		<b>7</b>
7.1 General.....		7
7.2 Format description of data link layer services.....		7
7.3 Services provided by the data link layer to higher layers.....		7
7.4 Specification of DoK-Line data link layer service primitives.....		8
7.4.1 DL_Data.request.....		8
7.4.2 DL_Data.confirm.....		8
7.4.3 DL_Data_FB.indication.....		9
7.4.4 DL_Data.indication.....		9
7.4.5 DoK-Line_Init.request.....		9
7.4.6 DoK-Line_Initialize.confirm.....		9
7.4.7 DoK-Line_ChangeParameter.request.....		10
7.4.8 DoK-Line_ChangeParameter.confirm.....		10
7.5 Service data unit specification.....		10
7.5.1 SA, Source Address.....		10
7.5.2 TA, Target Address.....		10
7.5.3 TAtype, target address type.....		11
7.5.4 <Length>.....		11
7.5.5 <MessageData>.....		11
7.5.6 <Result_DoK-Line>.....		11
7.5.7 <InitializationModeIdentifier>.....		12
7.5.8 <InitializationResultData>.....		12
7.5.9 <Result_Initialization>.....		12
7.5.10 <Parameter_Value>.....		13
7.5.11 <Result_ChangeParameter>.....		13
<b>8 Protocol initialization</b> .....		<b>14</b>
8.1 General.....		14
8.2 Timing parameters for 5-BAUD_INIT.....		14
8.3 Protocol determination.....		14
8.3.1 5-BAUD_INIT according to ISO 9141.....		14
8.3.2 5-BAUD_INIT according to this document.....		16
8.3.3 FAST_INIT according to this document.....		17
8.3.4 FAST_INIT according to ISO 14230-4.....		19
8.3.5 Client protocol determination by server (ECU) key bytes.....		20
8.3.6 Initial data exchange after successful completion of initialization.....		22
8.4 Protocol specific key bytes.....		22
8.4.1 Format of key bytes.....		22
8.4.2 Key bytes for emissions-related OBD protocols of ISO 9141-2.....		23
8.4.3 Key bytes for emissions-related OBD protocol ISO 14230-4.....		23
8.4.4 Key bytes for enhanced diagnostics with support of ISO 14230-4.....		24
8.4.5 Calculation of decimal value of key bytes.....		25

<b>9</b>	<b>Message definition</b> .....	<b>25</b>
9.1	Message structure.....	25
9.2	Message header.....	26
9.2.1	Format byte (FMT).....	26
9.2.2	Target address byte (TA).....	26
9.2.3	Source address byte (SA).....	27
9.2.4	Length byte (LEN).....	27
9.2.5	Message header configurations.....	27
9.3	Protocol data unit (PDU).....	28
9.4	Checksum byte (CS).....	28
<b>10</b>	<b>Protocol timing requirements</b> .....	<b>29</b>
10.1	General timing measurement requirements.....	29
10.2	Protocol timing parameter definition.....	29
10.2.1	Inter-byte and inter-message timing parameters.....	29
10.2.2	Inter-byte timing parameter set.....	29
10.3	Inter-byte message timing.....	30
10.4	Data link layer timing at T-Data interface.....	32
<b>11</b>	<b>Communication services</b> .....	<b>34</b>
11.1	StartCommunication service.....	34
11.1.1	Service definition.....	34
11.1.2	Implementation.....	35
11.2	StopCommunication service.....	36
11.2.1	Service definition.....	36
11.2.2	Implementation.....	36
11.3	AccessTimingParameter service.....	37
11.3.1	Service definition.....	37
11.3.2	Implementation.....	38
11.4	SendData service.....	40
11.4.1	Service definition.....	40
<b>12</b>	<b>Data collisions</b> .....	<b>41</b>
<b>13</b>	<b>Error handling</b> .....	<b>41</b>
13.1	Error handling during physical/functional 5-BAUD initialization.....	41
13.1.1	Client (external test equipment) error handling during physical/ functional 5-BAUD-INIT.....	41
13.1.2	Server (ECU) error handling during physical/functional 5-BAUD_INIT.....	42
13.2	Error handling during physical/functional FAST_INIT.....	42
13.2.1	Client (external test equipment) error handling during physical/ functional FAST_INIT.....	42
13.2.2	Server (ECU) error handling during physical FAST_INIT.....	43
13.2.3	Server (ECU) error handling during functional FAST_INIT (normal timing only).....	43
13.3	Error handling after physical/functional initialization.....	44
13.3.1	Client (external test equipment) communication error handling (after physical/functional initialization).....	44
13.3.2	Server (ECU) communication error handling after physical initialization.....	44
13.3.3	Server (ECU) error handling after functional initialization.....	45
	<b>Annex A (normative) Server and client addresses for 5-BAUD_INIT</b> .....	<b>46</b>
	<b>Annex B (informative) Recommended server and client addresses</b> .....	<b>47</b>
	<b>Annex C (informative) Protocol comparison of initialization sequence</b> .....	<b>48</b>
	<b>Bibliography</b> .....	<b>49</b>