

ISO 13185-4:2020-05 (E)

Intelligent transport systems - Vehicle interface for provisioning and support of ITS Services - Part 4: Unified vehicle interface protocol (UVIP) conformance test specification

| Contents | | Page |
|--------------------|--|-------------|
| Foreword | | viii |
| Introduction | | ix |
| 1 | Scope | 1 |
| 2 | Normative references | 1 |
| 3 | Terms, definitions and abbreviated terms | 1 |
| 3.1 | Terms and definitions | 1 |
| 3.2 | Abbreviated terms | 1 |
| 4 | Conventions | 2 |
| 5 | Conformance test plan (CTP) basic principles and clustering | 2 |
| 5.1 | Basic principles for CTC definition | 2 |
| 5.2 | CTC structure | 3 |
| 5.2.1 | CTC - General structure | 3 |
| 5.2.2 | Result criteria | 4 |
| 5.3 | CTC system setup | 4 |
| 5.4 | CTC clustering | 5 |
| 5.4.1 | General | 5 |
| 5.4.2 | Main CTC clusters | 5 |
| 6 | CT cluster 1 - Requesting V-ITS-SG and vehicle identification related information | 6 |
| 6.1 | CTC_UC 1.1 - Browsing available V-ITS-SGs | 6 |
| 6.1.1 | Overview | 6 |
| 6.1.2 | Test purpose | 6 |
| 6.1.3 | Configuration | 7 |
| 6.1.4 | Preamble (setup state) | 7 |
| 6.1.5 | Test execution | 7 |
| 6.1.6 | Postamble (setup state) | 8 |
| 6.2 | CTC_UC 1.2 - Browsing supported ECUs | 8 |
| 6.2.1 | Overview | 8 |
| 6.2.2 | Test purpose | 8 |
| 6.2.3 | Configuration | 9 |
| 6.2.4 | Preamble (setup state) | 9 |
| 6.2.5 | Test execution | 9 |
| 6.2.6 | Postamble (setup state) | 9 |
| 6.3 | CTC_UC 1.3 - Browsing supported data Ids | 9 |
| 6.3.1 | Overview | 9 |
| 6.3.2 | Test purpose | 9 |
| 6.3.3 | Configuration | 9 |
| 6.3.4 | Preamble (setup state) | 10 |
| 6.3.5 | Test execution | 10 |
| 6.3.6 | Postamble (setup state) | 10 |
| 7 | CT cluster 2 - Requesting vehicle and ECU data values | 10 |
| 7.1 | CTC_UC 2.1 - Requesting data ID values for single usage | 10 |

| | | |
|--------|---|-----------|
| 7.1.1 | Overview | 10 |
| 7.1.2 | Test purpose | 10 |
| 7.1.3 | Configuration | 10 |
| 7.1.4 | Preamble (setup state) | 11 |
| 7.1.5 | Test execution | 11 |
| 7.1.6 | Postamble (setup state) | 11 |
| 7.2 | CTC_UC 2.2 - Requesting data ID values for repeated usage | 12 |
| 7.2.1 | Overview | 12 |
| 7.2.2 | Test purpose | 12 |
| 7.2.3 | Configuration | 12 |
| 7.2.4 | Preamble (setup state) | 12 |
| 7.2.5 | Test execution | 12 |
| 7.2.6 | Postamble (setup state) | 13 |
| 7.3 | CTC_UC 2.3 - Requesting data ID text and data type information | 13 |
| 7.3.1 | Overview | 13 |
| 7.4 | CTC_UC 2.4 - Requesting data type definitions | 13 |
| 7.4.1 | Overview | 13 |
| 7.5 | CTC_UC 2.5 - Requesting all available text and data type information | 13 |
| 7.5.1 | Overview | 13 |
| 8 | CT cluster 3 - Requesting and clearing DTCs and related data | 13 |
| 8.1 | CTC_UC 3.1 - Requesting DTCs | 13 |
| 8.1.1 | Overview | 13 |
| 8.1.2 | Test purpose | 13 |
| 8.1.3 | Configuration | 14 |
| 8.1.4 | Preamble (setup state) | 14 |
| 8.1.5 | Test execution | 14 |
| 8.1.6 | Postamble (setup state) | 14 |
| 8.2 | CTC_UC 3.2 - Requesting additional DTC data | 14 |
| 8.2.1 | Overview | 14 |
| 8.2.2 | Test purpose | 14 |
| 8.2.3 | Configuration | 15 |
| 8.2.4 | Preamble (setup state) | 15 |
| 8.2.5 | Test execution | 15 |
| 8.2.6 | Postamble (setup state) | 15 |
| 8.3 | CTC_UC 3.3 - Clearing DTCs | 15 |
| 8.3.1 | Overview | 15 |
| 8.3.2 | Test purpose | 15 |
| 8.3.3 | Configuration | 16 |
| 8.3.4 | Preamble (setup state) | 16 |
| 8.3.5 | Test execution | 16 |
| 8.3.6 | Postamble (setup state) | 16 |
| 8.4 | CTC_UC 3.4 - SendOnChange - Provide DTC and status | 17 |
| 8.4.1 | Overview | 17 |
| 9 | CT cluster 4 - Unsolicited V-ITS-SG messages | 17 |
| 9.1 | CTC_UC 4.1 - SendOnEvent -- Emergency situation | 17 |
| 9.1.1 | Overview | 17 |
| 9.2 | CTC_UC 4.2 - SendOnEvent -- Critical driving situation | 17 |
| 9.2.1 | Overview | 17 |
| 9.3 | CTC_UC 4.3 - SendOnEvent -- Safety situation | 17 |
| 9.3.1 | Overview | 17 |
| 9.4 | CTC_UC 4.4 - SendOnEvent -- Warning situation | 17 |
| 9.4.1 | Overview | 17 |
| 9.5 | CTC_UC 4.5 - SendOnEvent -- Data ID value matches threshold | 18 |
| 9.5.1 | Overview | 18 |
| 10 | CT cluster 5 - Real-time data transmission | 18 |
| 10.1 | CTC_UC 5.1 - Real-time data ID value measurement | 18 |
| 10.1.1 | Overview | 18 |
| 10.2 | CTC_UC 5.2 - Real-time DTC reporting | 18 |

| | | |
|--------|--|----|
| 10.2.1 | Overview | 18 |
| 11 | CT cluster 6 - Controlling /adjusting various equipment of the vehicle | 18 |
| 11.1 | CTC_UC 6.1 - Learn settings of customer profile | 18 |
| 11.1.1 | Overview | 18 |
| 11.1.2 | Test purpose | 19 |
| 11.1.3 | Configuration | 19 |
| 11.1.4 | Preamble (setup state) | 19 |
| 11.1.5 | Test execution | 19 |
| 11.1.6 | Postamble (setup state) | 20 |
| 11.2 | CTC_UC 6.2 - Control convenience system | 20 |
| 11.2.1 | Overview | 20 |
| 11.2.2 | Test purpose | 20 |
| 11.2.3 | Configuration | 20 |
| 11.2.4 | Preamble (setup state) | 20 |
| 11.2.5 | Test execution | 20 |
| 11.2.6 | Postamble (setup state) | 21 |
| 11.3 | CTC_UC 6.3 - Control charging for EV | 21 |
| 11.3.1 | Overview | 21 |
| 11.3.2 | Test purpose | 21 |
| 11.3.3 | Configuration | 21 |
| 11.3.4 | Preamble (setup state) | 21 |
| 11.3.5 | Test execution | 22 |
| 11.3.6 | Postamble (setup state) | 22 |
| 12 | CT cluster 7 - Writing short- and long-term data to V-ITS-SG | 22 |
| 12.1 | CTC_UC 7.1 - Write data to V-ITS-SG's memory | 22 |
| 12.1.1 | Overview | 22 |
| 12.1.2 | Test purpose | 22 |
| 12.1.3 | Configuration | 23 |
| 12.1.4 | Preamble (setup state) | 23 |
| 12.1.5 | Test execution | 23 |
| 12.1.6 | Postamble (setup state) | 23 |
| 12.2 | CTC_UC 7.2 - Write vehicle profile to V-ITS-SG's memory | 23 |
| 12.2.1 | Overview | 23 |
| 12.3 | CTC_UC 7.3 - Enable/disable functional system related data IDs | 24 |
| 12.3.1 | Overview | 24 |
| 12.4 | CTC_UC 7.4 - Write data ID thresholds to V-ITS-SG's memory | 24 |
| 12.4.1 | Overview | 24 |
| 13 | CT cluster 8 - V-ITS-SG accessibility restrictions and firewall protection cluster | 24 |
| 13.1 | CTC_UC 8.1 - Secure access to V-ITS-SG | 24 |
| 13.1.1 | Overview | 24 |
| 13.1.2 | Test purpose | 24 |
| 13.1.3 | Configuration | 24 |
| 13.1.4 | Preamble (setup state) | 24 |
| 13.1.5 | Test execution | 24 |
| 13.1.6 | Postamble (setup state) | 25 |
| 13.2 | CTC_UC 8.2 - Request V-ITS-SG firewall status | 25 |
| 13.2.1 | Overview | 25 |
| 13.3 | CTC_UC 8.3 - Configuration of V-ITS-SG firewall | 25 |
| 13.3.1 | Overview | 25 |
| 13.3.2 | Test purpose | 25 |
| 13.3.3 | Configuration | 25 |
| 13.3.4 | Preamble (setup state) | 26 |
| 13.3.5 | Test execution | 26 |
| 13.3.6 | Postamble (setup state) | 26 |
| 14 | CT cluster 9 - V-ITS-SG special features | 26 |
| 14.1 | CTC_UC 9.1 - General data exchange | 26 |
| 14.1.1 | Overview | 26 |
| 14.2 | CTC_UC 9.2 - V-ITS-SG activation mode | 27 |

| | | |
|--------|--|----|
| 14.2.1 | Overview | 27 |
| 14.3 | CTC_UC 9.3 - Upload EventLogFile from V-ITS-SG | 27 |
| 14.3.1 | Overview | 27 |
| 14.3.2 | Test purpose | 27 |
| 14.3.3 | Configuration | 27 |
| 14.3.4 | Preamble (setup state) | 27 |
| 14.3.5 | Test execution | 27 |
| 14.3.6 | Postamble (setup state) | 28 |
| 15 | CT cluster 10 - Vehicle diagnostics | 28 |
| 15.1 | CTC_UC 10.1 - Perform functional group OBD | 28 |
| 15.1.1 | Overview | 28 |
| 15.1.2 | Test purpose | 28 |
| 15.1.3 | Configuration | 28 |
| 15.1.4 | Preamble (setup state) | 28 |
| 15.1.5 | Test execution | 28 |
| 15.1.6 | Postamble (setup state) | 29 |
| 15.2 | CTC_UC 10.2 - Perform enhanced OBD | 29 |
| 15.2.1 | Overview | 29 |
| 15.2.2 | Test purpose | 29 |
| 15.2.3 | Configuration | 29 |
| 15.2.4 | Preamble (setup state) | 29 |
| 15.2.5 | Test execution | 29 |
| 15.2.6 | Postamble (setup state) | 30 |
| 15.3 | CTC_UC 10.3 - Upload VSOCLogFile from V-ITS-SG | 30 |
| 15.3.1 | Overview | 30 |
| 15.3.2 | Test purpose | 30 |
| 15.3.3 | Configuration | 30 |
| 15.3.4 | Preamble (setup state) | 30 |
| 15.3.5 | Test execution | 30 |
| 15.3.6 | Postamble (setup state) | 31 |
| 16 | CT cluster 11 - Electric vehicle system status | 31 |
| 16.1 | CTC_UC 11.1 - Monitor battery charge status | 31 |
| 16.1.1 | Overview | 31 |
| 16.1.2 | Test purpose | 31 |
| 16.1.3 | Configuration | 31 |
| 16.1.4 | Preamble (setup state) | 31 |
| 16.1.5 | Test execution | 31 |
| 16.1.6 | Postamble (setup state) | 32 |
| 16.2 | CTC_UC 11.2 - Monitor connection between charging station and EV | 32 |
| 16.2.1 | Overview | 32 |
| 16.2.2 | Test purpose | 32 |
| 16.2.3 | Configuration | 32 |
| 16.2.4 | Preamble (setup state) | 32 |
| 16.2.5 | Test execution | 32 |
| 16.2.6 | Postamble (setup state) | 33 |
| 16.3 | CTC_UC 11.3 - Battery charge start/stop notification | 33 |
| 16.3.1 | Overview | 33 |
| 17 | CT cluster 12 - V-ITS-SG maintenance | 33 |
| 17.1 | CTC_UC 12.1 - Update core software of V-ITS-SG | 33 |
| 17.1.1 | Overview | 33 |
| 17.1.2 | Test purpose | 33 |
| 17.1.3 | Configuration | 34 |
| 17.1.4 | Preamble (setup state) | 34 |
| 17.1.5 | Test execution | 34 |
| 17.1.6 | Postamble (setup state) | 34 |
| 17.2 | CTC_UC 12.2 - Perform a Reset in V-ITS-SG | 34 |
| 17.2.1 | Overview | 34 |
| 17.2.2 | Test purpose | 34 |
| 17.2.3 | Configuration | 35 |

| | | |
|---------------------------|---|-----------|
| 17.2.4 | Preamble (setup state) | 35 |
| 17.2.5 | Test execution | 35 |
| 17.2.6 | Postamble (setup state) | 35 |
| 17.3 | CTC_UC 12.3 - Perform a reset in V-ITS-SG | 35 |
| 17.3.1 | Overview | 35 |
| 17.3.2 | Test purpose | 35 |
| 17.3.3 | Configuration | 35 |
| 17.3.4 | Preamble (setup state) | 35 |
| 17.3.5 | Test execution | 36 |
| 17.3.6 | Postamble (setup state) | 36 |
| 17.4 | CTC_UC 12.4 - Upload V-ITS-SG configuration file | 36 |
| 17.4.1 | Overview | 36 |
| 17.4.2 | Test purpose | 36 |
| 17.4.3 | Configuration | 36 |
| 17.4.4 | Preamble (setup state) | 36 |
| 17.4.5 | Test execution | 36 |
| 17.4.6 | Postamble (setup state) | 37 |
| 17.5 | CTC_UC 12.5 - Download V-ITS-SG configuration file | 37 |
| 17.5.1 | Overview | 37 |
| 17.5.2 | Test purpose | 37 |
| 17.5.3 | Configuration | 37 |
| 17.5.4 | Preamble (setup state) | 37 |
| 17.5.5 | Test execution | 37 |
| 17.5.6 | Postamble (setup state) | 38 |
| Bibliography | | 39 |