

# ISO 13185-4:2020-05 (E)

## Intelligent transport systems - Vehicle interface for provisioning and support of ITS Services - Part 4: Unified vehicle interface protocol (UVIP) conformance test specification

<b>Contents</b>		<b>Page</b>
Foreword .....		viii
Introduction .....		ix
<b>1</b>	<b>Scope .....</b>	<b>1</b>
<b>2</b>	<b>Normative references .....</b>	<b>1</b>
<b>3</b>	<b>Terms, definitions and abbreviated terms .....</b>	<b>1</b>
3.1	Terms and definitions .....	1
3.2	Abbreviated terms .....	1
<b>4</b>	<b>Conventions .....</b>	<b>2</b>
<b>5</b>	<b>Conformance test plan (CTP) basic principles and clustering .....</b>	<b>2</b>
5.1	Basic principles for CTC definition .....	2
5.2	CTC structure .....	3
5.2.1	CTC - General structure .....	3
5.2.2	Result criteria .....	4
5.3	CTC system setup .....	4
5.4	CTC clustering .....	5
5.4.1	General .....	5
5.4.2	Main CTC clusters .....	5
<b>6</b>	<b>CT cluster 1 - Requesting V-ITS-SG and vehicle identification related information .....</b>	<b>6</b>
6.1	CTC_UC 1.1 - Browsing available V-ITS-SGs .....	6
6.1.1	Overview .....	6
6.1.2	Test purpose .....	6
6.1.3	Configuration .....	7
6.1.4	Preamble (setup state) .....	7
6.1.5	Test execution .....	7
6.1.6	Postamble (setup state) .....	8
6.2	CTC_UC 1.2 - Browsing supported ECUs .....	8
6.2.1	Overview .....	8
6.2.2	Test purpose .....	8
6.2.3	Configuration .....	9
6.2.4	Preamble (setup state) .....	9
6.2.5	Test execution .....	9
6.2.6	Postamble (setup state) .....	9
6.3	CTC_UC 1.3 - Browsing supported data Ids .....	9
6.3.1	Overview .....	9
6.3.2	Test purpose .....	9
6.3.3	Configuration .....	9
6.3.4	Preamble (setup state) .....	10
6.3.5	Test execution .....	10
6.3.6	Postamble (setup state) .....	10
<b>7</b>	<b>CT cluster 2 - Requesting vehicle and ECU data values .....</b>	<b>10</b>
7.1	CTC_UC 2.1 - Requesting data ID values for single usage .....	10

7.1.1	Overview .....	10
7.1.2	Test purpose .....	10
7.1.3	Configuration .....	10
7.1.4	Preamble (setup state) .....	11
7.1.5	Test execution .....	11
7.1.6	Postamble (setup state) .....	11
7.2	<b>CTC_UC 2.2 - Requesting data ID values for repeated usage .....</b>	<b>12</b>
7.2.1	Overview .....	12
7.2.2	Test purpose .....	12
7.2.3	Configuration .....	12
7.2.4	Preamble (setup state) .....	12
7.2.5	Test execution .....	12
7.2.6	Postamble (setup state) .....	13
7.3	<b>CTC_UC 2.3 - Requesting data ID text and data type information .....</b>	<b>13</b>
7.3.1	Overview .....	13
7.4	<b>CTC_UC 2.4 - Requesting data type definitions .....</b>	<b>13</b>
7.4.1	Overview .....	13
7.5	<b>CTC_UC 2.5 - Requesting all available text and data type information .....</b>	<b>13</b>
7.5.1	Overview .....	13
8	<b>CT cluster 3 - Requesting and clearing DTCs and related data .....</b>	<b>13</b>
8.1	<b>CTC_UC 3.1 - Requesting DTCs .....</b>	<b>13</b>
8.1.1	Overview .....	13
8.1.2	Test purpose .....	13
8.1.3	Configuration .....	14
8.1.4	Preamble (setup state) .....	14
8.1.5	Test execution .....	14
8.1.6	Postamble (setup state) .....	14
8.2	<b>CTC_UC 3.2 - Requesting additional DTC data .....</b>	<b>14</b>
8.2.1	Overview .....	14
8.2.2	Test purpose .....	14
8.2.3	Configuration .....	15
8.2.4	Preamble (setup state) .....	15
8.2.5	Test execution .....	15
8.2.6	Postamble (setup state) .....	15
8.3	<b>CTC_UC 3.3 - Clearing DTCs .....</b>	<b>15</b>
8.3.1	Overview .....	15
8.3.2	Test purpose .....	15
8.3.3	Configuration .....	16
8.3.4	Preamble (setup state) .....	16
8.3.5	Test execution .....	16
8.3.6	Postamble (setup state) .....	16
8.4	<b>CTC_UC 3.4 - SendOnChange - Provide DTC and status .....</b>	<b>17</b>
8.4.1	Overview .....	17
9	<b>CT cluster 4 - Unsolicited V-ITS-SG messages .....</b>	<b>17</b>
9.1	<b>CTC_UC 4.1 - SendOnEvent -- Emergency situation .....</b>	<b>17</b>
9.1.1	Overview .....	17
9.2	<b>CTC_UC 4.2 - SendOnEvent -- Critical driving situation .....</b>	<b>17</b>
9.2.1	Overview .....	17
9.3	<b>CTC_UC 4.3 - SendOnEvent -- Safety situation .....</b>	<b>17</b>
9.3.1	Overview .....	17
9.4	<b>CTC_UC 4.4 - SendOnEvent -- Warning situation .....</b>	<b>17</b>
9.4.1	Overview .....	17
9.5	<b>CTC_UC 4.5 - SendOnEvent -- Data ID value matches threshold .....</b>	<b>18</b>
9.5.1	Overview .....	18
10	<b>CT cluster 5 - Real-time data transmission .....</b>	<b>18</b>
10.1	<b>CTC_UC 5.1 - Real-time data ID value measurement .....</b>	<b>18</b>
10.1.1	Overview .....	18
10.2	<b>CTC_UC 5.2 - Real-time DTC reporting .....</b>	<b>18</b>

10.2.1	Overview .....	18
11	CT cluster 6 - Controlling /adjusting various equipment of the vehicle .....	18
11.1	CTC_UC 6.1 - Learn settings of customer profile .....	18
11.1.1	Overview .....	18
11.1.2	Test purpose .....	19
11.1.3	Configuration .....	19
11.1.4	Preamble (setup state) .....	19
11.1.5	Test execution .....	19
11.1.6	Postamble (setup state) .....	20
11.2	CTC_UC 6.2 - Control convenience system .....	20
11.2.1	Overview .....	20
11.2.2	Test purpose .....	20
11.2.3	Configuration .....	20
11.2.4	Preamble (setup state) .....	20
11.2.5	Test execution .....	20
11.2.6	Postamble (setup state) .....	21
11.3	CTC_UC 6.3 - Control charging for EV .....	21
11.3.1	Overview .....	21
11.3.2	Test purpose .....	21
11.3.3	Configuration .....	21
11.3.4	Preamble (setup state) .....	21
11.3.5	Test execution .....	22
11.3.6	Postamble (setup state) .....	22
12	CT cluster 7 - Writing short- and long-term data to V-ITS-SG .....	22
12.1	CTC_UC 7.1 - Write data to V-ITS-SG's memory .....	22
12.1.1	Overview .....	22
12.1.2	Test purpose .....	22
12.1.3	Configuration .....	23
12.1.4	Preamble (setup state) .....	23
12.1.5	Test execution .....	23
12.1.6	Postamble (setup state) .....	23
12.2	CTC_UC 7.2 - Write vehicle profile to V-ITS-SG's memory .....	23
12.2.1	Overview .....	23
12.3	CTC_UC 7.3 - Enable/disable functional system related data IDs .....	24
12.3.1	Overview .....	24
12.4	CTC_UC 7.4 - Write data ID thresholds to V-ITS-SG's memory .....	24
12.4.1	Overview .....	24
13	CT cluster 8 - V-ITS-SG accessibility restrictions and firewall protection cluster .....	24
13.1	CTC_UC 8.1 - Secure access to V-ITS-SG .....	24
13.1.1	Overview .....	24
13.1.2	Test purpose .....	24
13.1.3	Configuration .....	24
13.1.4	Preamble (setup state) .....	24
13.1.5	Test execution .....	24
13.1.6	Postamble (setup state) .....	25
13.2	CTC_UC 8.2 - Request V-ITS-SG firewall status .....	25
13.2.1	Overview .....	25
13.3	CTC_UC 8.3 - Configuration of V-ITS-SG firewall .....	25
13.3.1	Overview .....	25
13.3.2	Test purpose .....	25
13.3.3	Configuration .....	25
13.3.4	Preamble (setup state) .....	26
13.3.5	Test execution .....	26
13.3.6	Postamble (setup state) .....	26
14	CT cluster 9 - V-ITS-SG special features .....	26
14.1	CTC_UC 9.1 - General data exchange .....	26
14.1.1	Overview .....	26
14.2	CTC_UC 9.2 - V-ITS-SG activation mode .....	27

14.2.1	Overview .....	27
14.3	CTC_UC 9.3 - Upload EventLogFile from V-ITS-SG .....	27
14.3.1	Overview .....	27
14.3.2	Test purpose .....	27
14.3.3	Configuration .....	27
14.3.4	Preamble (setup state) .....	27
14.3.5	Test execution .....	27
14.3.6	Postamble (setup state) .....	28
15	CT cluster 10 - Vehicle diagnostics .....	28
15.1	CTC_UC 10.1 - Perform functional group OBD .....	28
15.1.1	Overview .....	28
15.1.2	Test purpose .....	28
15.1.3	Configuration .....	28
15.1.4	Preamble (setup state) .....	28
15.1.5	Test execution .....	28
15.1.6	Postamble (setup state) .....	29
15.2	CTC_UC 10.2 - Perform enhanced OBD .....	29
15.2.1	Overview .....	29
15.2.2	Test purpose .....	29
15.2.3	Configuration .....	29
15.2.4	Preamble (setup state) .....	29
15.2.5	Test execution .....	29
15.2.6	Postamble (setup state) .....	30
15.3	CTC_UC 10.3 - Upload VSOCLogFile from V-ITS-SG .....	30
15.3.1	Overview .....	30
15.3.2	Test purpose .....	30
15.3.3	Configuration .....	30
15.3.4	Preamble (setup state) .....	30
15.3.5	Test execution .....	30
15.3.6	Postamble (setup state) .....	31
16	CT cluster 11 - Electric vehicle system status .....	31
16.1	CTC_UC 11.1 - Monitor battery charge status .....	31
16.1.1	Overview .....	31
16.1.2	Test purpose .....	31
16.1.3	Configuration .....	31
16.1.4	Preamble (setup state) .....	31
16.1.5	Test execution .....	31
16.1.6	Postamble (setup state) .....	32
16.2	CTC_UC 11.2 - Monitor connection between charging station and EV .....	32
16.2.1	Overview .....	32
16.2.2	Test purpose .....	32
16.2.3	Configuration .....	32
16.2.4	Preamble (setup state) .....	32
16.2.5	Test execution .....	32
16.2.6	Postamble (setup state) .....	33
16.3	CTC_UC 11.3 - Battery charge start/stop notification .....	33
16.3.1	Overview .....	33
17	CT cluster 12 - V-ITS-SG maintenance .....	33
17.1	CTC_UC 12.1 - Update core software of V-ITS-SG .....	33
17.1.1	Overview .....	33
17.1.2	Test purpose .....	33
17.1.3	Configuration .....	34
17.1.4	Preamble (setup state) .....	34
17.1.5	Test execution .....	34
17.1.6	Postamble (setup state) .....	34
17.2	CTC_UC 12.2 - Perform a Reset in V-ITS-SG .....	34
17.2.1	Overview .....	34
17.2.2	Test purpose .....	34
17.2.3	Configuration .....	35

17.2.4	Preamble (setup state) .....	35
17.2.5	Test execution .....	35
17.2.6	Postamble (setup state) .....	35
17.3	<b>CTC_UC 12.3 - Perform a reset in V-ITS-SG .....</b>	<b>35</b>
17.3.1	Overview .....	35
17.3.2	Test purpose .....	35
17.3.3	Configuration .....	35
17.3.4	Preamble (setup state) .....	35
17.3.5	Test execution .....	36
17.3.6	Postamble (setup state) .....	36
17.4	<b>CTC_UC 12.4 - Upload V-ITS-SG configuration file .....</b>	<b>36</b>
17.4.1	Overview .....	36
17.4.2	Test purpose .....	36
17.4.3	Configuration .....	36
17.4.4	Preamble (setup state) .....	36
17.4.5	Test execution .....	36
17.4.6	Postamble (setup state) .....	37
17.5	<b>CTC_UC 12.5 - Download V-ITS-SG configuration file .....</b>	<b>37</b>
17.5.1	Overview .....	37
17.5.2	Test purpose .....	37
17.5.3	Configuration .....	37
17.5.4	Preamble (setup state) .....	37
17.5.5	Test execution .....	37
17.5.6	Postamble (setup state) .....	38
<b>Bibliography .....</b>		<b>39</b>