

# DIN CEN ISO/TS 21176:2021-02 (E)

Cooperative intelligent transport systems (C-ITS) - Position, velocity and time functionality in the ITS station (ISO/TS 21176:2020); English version CEN ISO/TS 21176:2020

---

<b>Contents</b>		Page
<b>Foreword</b>		<b>iv</b>
<b>Introduction</b>		<b>v</b>
<b>1</b>	<b>Scope</b>	<b>1</b>
<b>2</b>	<b>Normative references</b>	<b>1</b>
<b>3</b>	<b>Terms and definitions</b>	<b>2</b>
<b>4</b>	<b>Abbreviated terms</b>	<b>4</b>
<b>5</b>	<b>Conformance</b>	<b>5</b>
<b>6</b>	<b>PVT service in the ITS station and communication architecture</b>	<b>5</b>
6.1	ITS station and communication architecture	5
6.2	ITS-S application processes (ITS-S-APs)	6
6.3	ITS-S facilities layer services	6
6.4	PVT service provided by the ITS-S facilities layer	8
6.5	Access to the PVT service	8
6.6	PVT-augmented ADUs	9
<b>7</b>	<b>PVT service</b>	<b>9</b>
7.1	PVT service reference model	9
7.2	PVT-related input parameters	10
7.3	PVT output parameters	11
7.3.1	General	11
7.3.2	PvtInfoEcdd	12
7.3.3	PvtInfoEcdd-PosVelocityTime	16
7.3.4	PvtInfoEcdd-PosTime	16
7.3.5	PvtInfoEcdd-VelocityAccelerationTime	16
7.3.6	PvtInfoEcdd-VelocityTime	16
7.3.7	PvtInfoEcdd-SpeedTime	16
7.3.8	PvtInfoNmeaData	17
<b>8</b>	<b>PVT-SAP service primitives</b>	<b>17</b>
8.1	General	17
8.1.1	Overview	17
8.1.2	PVTinit	18
8.1.3	Return codes	18
8.2	Get-PVT	18
8.3	Subscribe-PVT-related service primitives	19
8.3.1	Subscribe-PVT	19
8.3.2	Notify-PVT	20
8.3.3	Cancel-PVT	20
<b>9</b>	<b>PVT capability</b>	<b>20</b>
<b>Annex A (normative) PVT data type specifications</b>		<b>22</b>
<b>Annex B (normative) Implementation conformance statement proforma</b>		<b>23</b>
<b>Bibliography</b>		<b>27</b>