ISO/TS 22133:2023-03 (E)

Road vehicles - Test object monitoring and control for active safety and automated/autonomous vehicle testing - Functional requirements, specifications and communication protocol

Contents

Page

Introduction vii

1 Scope 1

2 Normative references 1

3 Terms and definitions 1

4 Abbreviated terms 4

5 Test scenario illustration 5

6 General requirements and recommendations 6
6.1 Function overview 6
6.2 Test object coordinate system 6
6.2.1 Vehicle 6
6.2.2 Moveable test objects other than vehicle 7
6.3 Test scenario coordinate system 9
6.3.1 Background info: tectonic/continental plate drift 9
6.3.2 Coordinate system – Tests on proving ground 9
6.3.3 Coordinate system – Test on other test areas 10
6.4 Time requirements 10
6.4.1 General time requirements 10
6.4.2 Time representation 10
6.4.3 Absolute time 10
6.4.4 Relative time 11
6.4.5 Time resolution 11
6.4.6 Time accuracy (and precision) 11
6.4.7 Time synchronization 11
6.4.8 Date synchronization 12
6.4.9 Network delay 12
6.5 Communication requirements and permissions 13

7 Safety and risk assessment requirements and recommendations 14
7.1 General 14
7.2 Local test object fence and global geofence 15
7.2.1 Common requirements and recommendations 15
7.2.2 Global geofence 15
7.2.3 Local test object fence 15

8 Communication security requirements 17

9 Architecture and interfaces 17
9.1 General 17
9.2 Control centre and test object states 18
9.2.1 General 18
9.2.2 Test objects state diagram 18
9.2.3 Test object state change conditions 20
9.2.4 Control centre state diagram 20
9.2.5 Control centre state change triggers 21
9.3 Communication setup 22

9.3.1 General 22
9.3.2 Test object discovery 22
9.3.3 TCP communication setup (control channel) 22
9.3.4 UDP communication setup (process channel) 23
9.3.5 File transfer protocol (FTP) 25
9.4 Control functionalities 25
9.4.1 Automated and non-automated drive 25
9.4.2 Remote-control manoeuvring 26

10 Trajectory and scenario-based testing 28
10.1 Introduction to trajectory and scenario-based testing 28
10.2 Static trajectories 28
10.3 Dynamic trajectories 28
10.4 Scenario-description languages 29

11 Functional requirements 29
11.1 Device interface description XML (DIDX) 29
11.2 Control centre requirements and recommendations 30
11.3 Stationary test object requirements 30
11.4 Moveable test object requirements and recommendations 30
11.5 Functions with behaviour description 31
11.5.1 Arm and disarm test object 31
11.5.2 Start test 32
11.5.3 Emergency stop of test scenario (initiated by the CC) 33
11.5.4 Emergency stop of test scenario (upon request from test object) 34
11.5.5 Normal stop of test scenario 35
11.5.6 Download static (pre planned) trajectories 36
11.5.7 Cyclic monitor and heartbeat 36
11.5.8 Adaptive synchronization point 36
11.5.9 Remote-control manoeuvring 39
11.5.10 Trigger and action 40

12 Interface requirements 41
12.1 General 41
12.2 Message 42
12.2.1 Message structure 42
12.2.2 Sequential byte order 42
12.2.3 Message header 43
12.2.4 Message content 44
12.2.5 Message footer 45
12.2.6 Protocol tunnel 45
12.2.7 Vendor-specific messages 46
12.3 Collective message overview 46
12.3.1 Trajectory object message - TRAJ (MsgID 0x0001) 48
12.3.2 Object setting message – OSEM (MsgID 0x0002) 51
12.3.3 Object state change request message – OSTM (MsgID 0x0003) 58
12.3.4 Start message -STRT (MsgID 0x0004) 58
12.3.5 Heartbeat message – HEAB (MsgID 0x0005) 59
12.3.6 Monitor message – MONR (MsgID 0x0006) 61
12.3.7 Monitor message 2 – MONR2 (MsgID 0x0007) 64
12.3.8 GPS second of week roll over message – SOWM (MsgID 0x0008) 66
12.3.9 Synchronization point configuration message – SYPM (MsgID 0x000B) 67
12.3.10 Master time to synchronization point message -MTSP (MsgID 0x000C) 68
12.3.11 Remote-control manoeuvring message – RCMM (MsgID 0x000A) 68
12.3.12 Remote-control manoeuvring message 2 – RCMM2 (MsgID 0x0016) 71
12.3.13 Trigger configuration message – TRCM (MsgID 0x0021) 73

12.3.14 Action configuration message – ACCM (MsgID 0x0022) 76
12.3.15 Trigger event occured message – TREO (MsgID 0x0023) 78
12.3.16 Execute action message – EXAC (MsgID 0x0024) 79
12.3.17 Cancel or delete trigger and action – CADE (MsgID 0x0025) 80
12.3.18 Action performed message – APEM (MsgID 0x0026) 80
12.3.19 Discovery request DREQ (MsgID 0x0010) 81
12.3.20 Discovery response DRES (MsgID 0x0011) 81
12.3.21 Parameter request message – PREQ (MsgID 0x0012) 82
12.3.22 Parameter response message PRES (MsgID 0x0013) 83
12.3.23 GeoFence message GEOF (MsgID 0x0009) 84
12.3.24 General data message - GEDM (MsgID 0x0017) 85
12.3.25 General response message - GREM (MsgID 0x0018) 87
Annex A (normative) Trajectory file format 89
Annex B (informative) Message footer checksum calculation 92
Annex C (informative) Trigger and action 95
Annex D (normative) Device interface description XML (DIDX) 100
Bibliography 102