DIN EN 16454:2024-03 (E)

Intelligent transport systems - ESafety - ECall end to end conformance testing

Contents

Page

European foreword 9

Introduction 10

1 Scope 11

2 Normative references 11

3 Terms and definitions 12

4 Symbols and abbreviations 18

5 Conformance 20
5.1 General 20
5.2 General conditions 20

6 General overview of the eCall transaction for pan-European eCall 20

7 How to use this document 25
7.1 Layout and procedures 25
7.2 System under test 26
7.3 Accelerated test procedures 27
7.4 Accelerated test procedures for IVSs 27
7.4.1 Accelerated test procedures for all types of PE eCall IVS 27
7.4.2 Additional accelerated test procedures for PE eCall only IVS 29
7.5 Accelerated test procedures for MNOs 29
7.6 Accelerated test procedures for PSAPs - PE eCall 30
7.7 Accelerated test procedures for PSAPs - TPS-eCall 31
7.8 Accelerated test procedures for TPSPs 31

8 Requirements 31
8.1 Requirements - General objectives 31
8.1.1 State transitions 31
8.1.2 Classification of testing 41
8.1.3 CTP naming conventions 43
8.1.4 CTP <stage> naming convention for IVS conformance tests 44
8.2 CTP structure 44
8.3 eCall timers 47

9 Conformance test requirements for in-vehicle user equipment and systems (IVS) 47
9.1 Conformance test requirements for in-vehicle user equipment and systems for Pan European eCall 47
9.2 Test objectives and purposes 47
9.3 Classification of testing and referenced tests for in-vehicle user equipment for Pan European eCall IVS 47
9.3.1 Taxonomy of testing 47
9.3.2 Referenced tests 48
9.4 State transition conformance tests for in-vehicle equipment and system to comply to Standards for pan European eCall 48
9.4.1 Conformance requirement 48
9.4.2 Use case test objectives by stage 48
9.4.3 CTP 1.1.0.1 Conformance to ETSI TS 102 936-1 and ETSI TS 102 936-2 - PE eCall IVS 52

9.4.4 CTP 1.1.0.2 Test for conformance to valid SIM/USIM - PE eCall IVS 53
9.4.5 CTP 1.1.0.3 Automatic eCall triggering does not occur when ignition OFF - PE eCall IVS 54
9.4.6 CTP 1.1.1.1 Power on and self test - PE eCall IVS 55
9.4.7 CTP 1.1.2.1 eCall automatically activated - PE eCall IVS 56
9.4.8 CTP 1.1.2.2 Automatically triggered eCall in progress was not disconnected upon a new eCall trigger - PE eCall IVS 57
9.4.9 CTP 1.1.2.3 Post-side-crash performance of automatic trigger - PE eCall IVS 58
9.4.10 CTP 1.1.2.4 Post-frontal-crash performance of automatic trigger - PE eCall IVS 59
9.4.11 CTP 1.1.2.5 Performance of automatic trigger - different crash types - PE eCall IVS 60
9.4.12 CTP 1.1.3.1 eCall manually activated - PE eCall IVS 61
9.4.13 CTP 1.1.3.2 Manually triggered eCall in progress was not disconnected upon a new eCall trigger - PE eCall IVS 62
9.4.14 CTP 1.1.4.1 Test eCall activated - PE eCall IVS 63
9.4.15 CTP 1.1.5.1 Network registration - PE eCall IVS 64
9.4.16 CTP 1.1.5.2 Manual termination of eCall by vehicle occupants not allowed (automatically triggered eCall) - PE eCall IVS 65
9.4.17 CTP 1.1.5.3.1 Manual termination of eCall by vehicle occupants not allowed (manually triggered eCall) - PE eCall IVS 66
9.4.18 CTP 1.1.5.3.2 Manual termination of eCall by vehicle occupants allowed (manually triggered eCall) - PE eCall IVS 67
9.4.19 CTP 1.1.5.4 Automatically triggered eCall in progress was not disconnected when ignition is switched to OFF - PE eCall IVS 68
9.4.20 CTP 1.1.5.5 Manually triggered eCall in progress was not disconnected when ignition is switched to OFF - PE eCall IVS 69
9.4.21 CTP 1.1.5.6 Priority over conflicting communication - PE eCall IVS 70
9.4.22 CTP 1.1.6.1 Mute IVS and vehicle audio - PE eCall IVS 71
9.4.23 CTP 1.1.7.1 Set-up TS12 call with eCall identifier (flag) set to 'automatic' - PE eCall IVS 72
9.4.24 CTP 1.1.8.1 Set-up TS12 call with eCall identifier (flag) set to 'manual' - PE eCall IVS 73
9.4.25 CTP 1.1.9.1 Set-up TS11 call to test number - PE eCall IVS 74
9.4.26 CTP 1.1.10.1 eCall is attempted when no networks are available (limited service condition) - PE eCall IVS 75
9.4.27 CTP 1.1.10.2 Re-dial attempt completed within 2 minutes after eCall is dropped - PE eCall IVS 76
9.4.28 CTP 1.1.10.3 Duration of eCall Initiation signal - PE eCall IVS 77
9.4.29 CTP 1.1.10.5 Test eCall is not attempted in limited service condition - PE eCall IVS 78
9.4.30 CTP 1.1.11.1 Send MSD with indicator set to 'Automatically Initiated eCall' (AleC) - PE eCall IVS 79
9.4.31 CTP 1.1.12.1 Send MSD with indicator set to 'Manually Initiated eCall' (MleC) - PE eCall IVS 80
9.4.32 CTP 1.1.13.1 Send MSD with indicator set to 'Test Call' - PE eCall IVS 81
9.4.33 CTP 1.1.14.1 Verify MSD transfer - PE eCall IVS 82
9.4.34 CTP 1.1.14.2 Un-mute IVS audio when AL-ACK received - PE eCall IVS 83
9.4.35 CTP 1.1.15.1 Establish voice link to PSAP - PE eCall IVS 84
9.4.36 CTP 1.1.15.2 MSD transfer request while eCall conversation in progress - PE eCall IVS 85
9.4.37 CTP 1.1.15.3 eCall continuation when SEND MSD request not received (timer T5 expired) - PE eCall IVS 86

9.4.38 CTP 1.1.15.4 Call continuation when AL-ACK not received (timer T6 expired) - PE eCall IVS 87
9.4.39 CTP 1.1.15.5 MSD is transferred continuously until timer T7 expires and IVS reconnects loudspeaker and microphone on its expiry - PE eCall IVS 88
9.4.40 CTP 1.1.16.1 Clear down call automatically - PE eCall IVS 89
9.4.41 CTP 1.1.16.2 IVS clears down the eCall upon timer T2 expiry - PE eCall IVS 90
9.4.42 CTP 1.1.16.3 IVS registers recent eCalls - PE eCall IVS 91
9.4.43 CTP 1.1.17.1 Call-back allowed and able to be answered by IVS - PE eCall IVS 92
9.4.44 CTP 1.1.17.2 Call-back answered by IVS in the event of abnormal termination - PE eCall IVS 93
9.4.45 CTP 1.1.17.3 MSD transfer occurs upon PSAP request during call-back - PE eCall IVS 94
9.4.46 CTP 1.1.17.4 Remain registered for ≥1 hr - PE eCall IVS 95
9.4.47 CTP 1.1.18.1 Compliance with MSD version 3 - PE eCall IVS 96
9.5 State transition test scripts for in-vehicle equipment and system to comply to Standards for pan European eCall - additional tests for eCall only systems 98
9.5.1 General 98
9.5.2 CTP 1.1.1.2 IVS does not perform registration after power-up - PE eCall only IVS 100
9.5.3 CTP1.1.10.4 Verify that PLMN registration procedure is executed upon initiating an eCall - PE eCall only IVS 101
9.5.4 CTP 1.1.17.5 Remain registered for ≥1 hr ≤12 hr - PE eCall only IVS 102
9.6 State transition conformance test requirements for in-vehicle user equipment for eCall TPS-IVS via a third party service provider 103
9.6.1 General 103
9.6.2 Test objectives and purposes 103
9.6.3 Taxonomy of testing and referenced tests 103
9.6.4 Taxonomy of testing 103
9.7 Use case conformance tests for in-vehicle equipment and system to comply to Standards for third party service provider eCall 103
9.7.1 Conformance requirement 103
9.7.2 Use case test objectives by stage 103
9.8 State transition test scripts for TPS in-vehicle equipment and system to comply to Standards for third party services supported eCall 106
9.8.1 General 106
9.8.2 CTP 1.2.0 Pre operation - TPS-IVS 107
9.8.3 CTP 1.2.1 Power on self test - TPS-IVS 109
9.8.4 CTP 1.2.2 Automatically activate eCall - TPS-IVS 110
9.8.5 CTP 1.2.3 Manually activate eCall - TPS-IVS 118
9.8.6 CTP 1.2.4 Stop conflicting communication - TPS-IVS 122
9.8.7 CTP 1.2.5 Establish voice link to TPSP - TPS-IVS 123
9.8.8 CTP 1.2.6 Send IVS dataset to TPSP - TPS-IVS 127
9.8.9 CTP 1.2.7.1 Establish direct bidirectional audio link between occupants and PSAP - TPS-IVS 132
9.8.10 CTP 1.2.8.1 No reconnect after termination - TPS-IVS 133
9.8.11 CTP 1.2.9 Allow call-cack into vehicle - TPS-IVS 134

10 Conformance tests for mobile network operators 138
10.1 Test objectives and purposes 138
10.1.1 General 138
10.1.2 Default assumptions 138
10.2 Taxonomy of testing and referenced tests 138
10.3 Use case conformance tests for mobile network operator systems to comply to Standards for pan European eCall 138

10.3.1 Conformance requirement 138
10.3.2 Use case test objectives by stage 138
10.4 State transition test scripts for mobile network operators to demonstrate compliance with Pan European eCall Standards 139
10.4.1 General 139
10.4.2 CTP 2.0.1 Keep SIMs/USIMs alive even though not in regular operation – MNO 141
10.4.3 CTP 2.0.2 MNO supports general eCall relevant requirements – MNO 142
10.4.4 CTP 2.0.3 Decommission SIM/USIM - MNO 143
10.4.5 CTP 2.0.4 Support eCall Flag – MNO 144
10.4.6 CTP 2.1.1 Accept registration - Home network - MNO 144
10.4.7 CTP 2.1.2 Accept registration - Roaming – MNO 145
10.4.8 CTP 2.2.1.1 Receive TS12 voice call (automatically initiated) – MNO 146
10.4.9 CTP 2.2.1.2 Route call to 'most appropriate' PSAP – MNO 147
10.4.10 CTP 2.2.1.3 Provide TS12 data/caller ID – MNO 148
10.4.11 CTP 2.2.2.1 Receive TS12 voice call (manual initiated) – MNO 149
10.4.12 CTP 2.2.3.1 Test for receiving test eCall (TS11) 149
10.4.13 CTP 2.2.3.2 Route call to non-emergency number - MNO 149
10.4.14 CTP 2.2.3.3 Provide TS11 data – MNO 150
10.4.15 CTP 2.3.1 Call in progress - MNO 150
10.4.16 CTP 2.4.1 Call cleardown – MNO 151
10.4.17 CTP 2.5.1 Support call-back – MNO 152
10.4.18 CTP 2.6.1 Maintain registration for 1-12 hours - MNO 152
10.4.19 CTP 2.7.1 Maintain call records - MNO 152
10.5 Use case conformance tests for mobile network operator systems to comply to Standards for TPS-eCall 153
10.5.1 Conformance requirement 153
10.5.2 Use case test objectives by stage 153
10.6 State transition test scripts for mobile network operators to demonstrate compliance with TPS-eCall Standards 153
10.6.1 CTP 2.11.1 MNO supports general TPS-eCall relevant requirements 153
10.6.2 CTP 2.11.2 Support call-back - MNO 153

11 Conformance tests for PSAP systems 154
11.1 Test objectives and purposes 154
11.2 Taxonomy of testing and referenced tests 154
11.2.1 Taxonomy of testing 154
11.2.2 Referenced tests 154
11.3 Use case conformance tests for PSAP systems to comply to Standards for pan European eCall 154
11.3.1 Conformance requirement 154
11.3.2 Use case test objectives by stage 154
11.4 State transition conformance tests for PSAPs - PE eCall 155
11.4.1 General 155
11.4.2 CTP 3.1.0.1 Provide MNOs with appropriate routing data - Member State/ PSAP PE eCall 157
11.4.3 CTP 3.1.0.2 Maintain map geo-information - PSAP PE eCall 158
11.4.4 CTP 3.1.1.1 Receive automatically initiated eCall - PSAP PE eCall 159
11.4.5 CTP 3.1.1.2 Receive manually initiated eCall - PSAP PE eCall 160
11.4.6 CTP 3.1.2 Receive TS12 data - Caller ID and location - PSAP PE eCall 161
11.4.7 CTP 3.1.3.1 Recognise eCall and route to in-band modem - PSAP PE eCall 162
11.4.8 CTP 3.1.3.2 PSAP equipment failure - PSAP PE eCall 163
11.4.9 CTP 3.1.3.3 PSAP modem failure before link layer ACK is sent PSAP PE eCall 163

11.4.10 CTP 3.1.4 eCall received at in-band modem – PSAP PE eCall 163
11.4.11 CTP 3.1.5.1 Validate initiation signal - PSAP PE eCall 164
11.4.12 CTP 3.1.5.2 Route to operator after timer T4 expiration - PSAP PE eCall 165
11.4.13 CTP 3.1.6.1 Request MSD after reception of initiation signal - PSAP PE eCall 166
11.4.14 CTP 3.1.6.2 Request MSD immediately - PSAP PE eCall 167
11.4.15 CTP 3.1.7.1 Receive MSD - PSAP PE eCall 168
11.4.16 CTP 3.1.7.2 Verify status bit in AL-ACK upon positive ACK– PSAP PE eCall ... 169
11.4.17 CTP 3.1.7.3 Verify MSD transfer upon timer T8 expiration - PSAP PE eCall .. 169
11.4.18 CTP 3.1.7.4 Verify transfer of corrupted MSD - PSAP PE eCall 170
11.4.19 CTP 3.1.7.5 Verify PSAP behaviour when MSD format check fails - PSAP PE eCall 171
11.4.20 CTP 3.1.7.6 Verify PSAP behaviour when MSD contains unknown optional additional data set - PSAP PE eCall 172
11.4.21 CTP 3.1.7.7 Verify PSAP behaviour when MSD contains ASN.1 extended data-elements - PSAP PE eCall 173
11.4.22 CTP 3.1.7.8 Verify PSAP behaviour when MSD contains ASN.1 extended data-values - PSAP PE eCall 174
11.4.23 CTP 3.1.7.9 Compliance with MSD version 2 - PSAP PE eCall 175
11.4.24 CTP 3.1.7.10 Compliance with MSD version 3 - PSAP PE eCall 177
11.4.25 CTP 3.1.8 ACK - PSAP PE eCall 178
11.4.26 CTP 3.1.9 Route voice and MSD to operator - PSAP PE eCall 178
11.4.27 CTP 3.1.10 Display TS12 data and MSD to operator - PSAP PE eCall 179
11.4.28 CTP 3.1.11 Decode VIN - PSAP PE eCall 180
11.4.29 CTP 3.1.12 Talk to vehicle occupants - PSAP PE eCall 181
11.4.30 CTP 3.1.13 Request new MSD before call cleardown - PSAP PE eCall 182
11.4.31 CTP 3.1.14.1 Call cleardown - PSAP PE eCall 183
11.4.32 CTP 3.1.14.2 Verify status bit in AL-ACK upon cleardown - PSAP PE eCall 184
11.4.33 CTP 3.1.15 Call-back to vehicle - PSAP PE eCall 185
11.4.34 CTP 3.1.16 Request new/updated MSD after call cleardown - PSAP PE eCall 186
11.5 State transition conformance tests for PSAPs - TPS-eCall 187
11.5.1 General 187
11.5.2 CTP 3.2.0.1 TPSP - PSAP agreement - PSAP TPS eCall 188
11.5.3 CTP 3.2.0.2 Provide areas of responsibility and contact numbers to approved TPSPs –PSAP TPS-eCall 189
11.5.4 CTP 3.2.0.3 Agreement on necessary language support - PSAP TPS eCall 191
11.5.5 CTP 3.2.0.4 Agree electronic data connection and provide details to approved TPSPs - PSAP TPS eCall 192
11.5.6 CTP 3.2.0.5 Provide PSAP data addresses and security access to approved TPSPs - PSAP TPS eCall 194
11.5.7 CTP 3.2.1 Receive eCall notification from TPSP (not TS12) - PSAP TPS eCall 195
11.5.8 CTP 3.2.2 Route call to operator - PSAP TPS eCall 196
11.5.9 CTP 3.2.3 Connection, TSD transmission, display relevant information to PSAP operator - PSAP TPS-eCall 197
11.5.10 CTP 3.2.4 PSAP Operator: Talk with TPSP operator and receive relevant information - PSAP TPS eCall 199
11.5.11 CTP 3.2.5 Talk to vehicle occupants - PSAP TPS-eCall 200
11.5.12 CTP 3.2.6 Request new TSD before call cleardown - PSAP TPS-eCall 201
11.5.13 CTP 3.2.7 Inform TPSP that call can be ended - PSAP TPS eCall 202
11.5.14 CTP 3.2.8 Call cleardown with TPSP - PSAP TPS-eCall 203
11.5.15 CTP 3.2.9 Call-back to TPSP - PSAP TPS-eCall 204
11.5.16 CTP 3.2.10 Call-back to vehicle - PSAP TPS eCall 205

11.5.17 CTP 3.2.11 Call cleardown with vehicle - PSAP TPS eCall 206

12 State transition conformance tests for TPS-eCall 207
12.1 Related specifications and conformance requirements 207
12.2 TPSP general tests (applicable to both TPS-eCall responder and TPS-eCall notifier) 207
12.2.1 General 207
12.2.2 CTP 4.0.1 Agree service level agreement and/or Standard ways of working with PSAPs – TPSP 209
12.2.3 CTP 4.0.2 Receive PSAP areas of responsibility and contact numbers – TPSP 210
12.2.4 CTP 4.0.3 Agree necessary language support - TPSP 211
12.2.5 CTP 4.0.4 Agree electronic data connection details with PSAPs – TPSP 213
12.2.6 CTP 4.0.5 Evidence quality procedures - TPSP 214
12.2.7 CTP 4.0.6 Verify automatic call distribution (ACD) system – TPSP 217
12.2.8 CTP 4.0.7 Check link from MNO – TPSP 218
12.2.9 CTP 4.0.8 Deal with transmission failures – TPSP 219
12.2.10 CTP 4.0.9 Update GIS – TPSP 220
12.2.11 CTP 4.0.10 Protection of privacy – TPSP 221
12.3 TPS-eCall responder tests - TPS-R 222
12.3.1 General 222
12.3.2 CTP 4.1.1 Receive TPS-eCall from vehicle - TPS-R 223
12.3.3 CTP 4.1.2 Process incoming call - TPS-R 226
12.3.4 CTP 4.1.3 Talk with vehicle occupants and receive relevant information - TPS-R 228
12.3.5 CTP 4.1.4 Trigger PSAP notification - TPS-R 231
12.3.6 CTP 4.1.5 Make voice connection between vehicle and PSAP if required - TPS-R 231
12.3.7 CTP 4.1.6 Confirmation received from PSAP that call with vehicle can be ended - TPS-R 232
12.3.8 CTP 4.1.7 Call cleardown with vehicle - TPS-R 233
12.3.9 CTP 4.1.8 Call-back to vehicle - TPS-R 234
12.4 TPS-eCall notifier tests - TPS-N 235
12.4.1 General 235
12.4.2 CTP 4.2.1 Emergency situation likely to require assistance - TPS-N 236
12.4.3 CTP 4.2.2 Establish contact with PSAP - TPS-N 236
12.4.4 CTP 4.2.3 Talk with PSAP operator and notify relevant information - TPS-N 241
12.4.5 CTP 4.2.4 Establish voice link between PSAP and vehicle occupants if required by PSAP - TPS-N 243
12.4.6 CTP 4.2.5 Respond to electronic data update request - TPS-N 245
12.4.7 CTP 4.2.6 PSAP informs that call can be ended - TPS-N 245
12.4.8 CTP 4.2.7 Call cleardown to PSAP - TPS-N 245
12.4.9 CTP 4.2.9 Call-back from PSAP - TPS-N 245

13 Marking, labelling and packaging 246

14 Declaration of patents and intellectual property 246

Annex A Void 247

Annex B Void 248

Annex C Void 249

Annex D Void 250

Annex E Void 251
Annex F (informative) **MSD examples for special PSAP tests 252**

Bibliography 264