ISO 17978-3:2026-03 (E)

Road vehicles - Service-oriented vehicle diagnostics (SOVD) - Part 3: Application programming interface (API)

Contents

Page

Foreword ..... **vii**

Introduction ..... **viii**

1 Scope **1**

2 Normative references **1**

3 Terms and definitions **2**

4 Symbols and abbreviated terms **3**
4.1 Symbols 3
4.2 Abbreviated terms 3

5 SOVD API general aspects **5**
5.1 Use cases overview 5
5.2 Accessing the API 5
5.2.1 HTTP REST based approach 5
5.2.2 Server-sent events 7
5.3 Entities 9
5.3.1 General 9
5.3.2 EntityTypes and collections 10
5.3.3 Entity hierarchy and relations 11
5.3.4 Entity identifier and path 13
5.3.5 Location of the SOVD server 13
5.3.6 Multi-SOVD server environments 13
5.4 Resources 14
5.4.1 General 14
5.4.2 Standardized resource collections 14
5.4.3 Standardized resources 15
5.4.4 Restricting access to entities and resources by authentication 16
5.4.5 Custom specific resource collections and types 16
5.5 Illustration of SOVD concepts for entities and resources 17
5.6 SOVD API versioning 18
5.7 Internationalization and localization 18
5.7.1 Internationalization 18
5.7.2 Unit definitions 18
5.7.3 Internationalization of enumerations 20
5.7.4 Other localization topics (numbers and dates) 20
5.8 Response status codes 21
5.8.1 General 21
5.8.2 Generic definition of status codes 21
5.8.3 Definition of error details 22
5.8.4 SOVD error codes for common cases 22
5.9 Common primitive data types 23
5.10 Definition of JSON schema and objects for vehicle responses 24
5.11 Discovery of the SOVD server for the co-located use case cluster 26
5.11.1 General concept 26
5.11.2 Network connection 26
5.11.3 Address an SOVD server using mDNS 26
5.11.4 Discovery of the SOVD server using DNS-SD 26
5.11.5 Example 27
5.12 Discovery of the SOVD server for the remote use case cluster 27

6 Capability description **27**
6.1 General 27

6.2 Capability description structure ... 28
6.2.1 General ... 28
6.2.2 Info object ... 28
6.2.3 Path item object ... 28
6.2.4 Operation object ... 30
6.2.5 Schema object ... 30
6.2.6 Header object ... 31
6.2.7 Predefined query parameter ... 31
6.2.8 `x-sovd-tags` object ... 32
6.3 Online and offline capability descriptions ... 33
6.3.1 General ... 33
6.3.2 Offline capability description ... 33
6.3.3 Online capability description ... 33
6.4 Variant handling in offline capability description ... 33
6.4.1 General ... 33
6.4.2 Extension: x-sovd-applicability ... 34
6.4.3 Usage of `x-sovd-applicability` by the SOVD client ... 35

7 SOVD REST API ... 36
7.1 General ... 36
7.2 Definition of conventions for API methods ... 36
7.2.1 Query parameters ... 36
7.2.2 Request body ... 36
7.3 Timeout definitions ... 36
7.4 API methods for access of supported SOVD server versions ... 37
7.4.1 General ... 37
7.4.2 Read all supported versions of the SOVD server ... 37
7.5 API methods for access to capability description content ... 38
7.5.1 General ... 38
7.5.2 Retrieve online capability description ... 39
7.6 API methods for discovery of Entities and resources ... 40
7.6.1 General ... 40
7.6.2 Query for Entities from an SOVD server ... 40
7.6.3 Query for capabilities of an entity ... 46
7.7 Enhancement of API methods for tagged Entities and resources ... 49
7.7.1 General ... 49
7.7.2 Query for tagged Entities and resources ... 49
7.7.3 Retrieve `tags` from entity or a resource ... 50
7.7.4 Query for tagged capabilities of an entity ... 52
7.8 API methods for fault handling ... 53
7.8.1 General ... 53
7.8.2 Query for faults from an entity ... 53
7.8.3 Read a fault resource ... 57
7.8.4 Delete all faults of an entity ... 59
7.8.5 Delete single fault of an entity ... 60
7.9 API methods for data resource read/write access ... 61
7.9.1 General ... 61
7.9.2 Retrieve of data resource categories and groups of an entity ... 62
7.9.3 Query for data from an entity ... 65
7.9.4 Read a data resource ... 67
7.9.5 Read multiple data values from an entity ... 70
7.9.6 Write a data resource ... 75
7.10 API methods for cyclic-subscriptions ... 77
7.10.1 General ... 77
7.10.2 Query for cyclic-subscriptions from an entity ... 77
7.10.3 Issue a new cyclic-subscription ... 78
7.10.4 Retrieve details of a cyclic-subscription ... 82
7.10.5 Update a cyclic-subscription ... 83
7.10.6 Delete a cyclic-subscription ... 84
7.11 API methods for triggers ... 85
7.11.1 General ... 85
7.11.2 Issue a new trigger ... 87
7.11.3 Query for triggers from an entity ... 93

7.11.4 Retrieve details of a trigger ... 95
7.11.5 Update a trigger ... 96
7.11.6 Delete a trigger ... 98
7.11.7 Trigger value reception ... 99
7.12 API methods for configuration ... 100
7.12.1 General ... 100
7.12.2 Query for configurations from an entity ... 100
7.12.3 Read a configuration resource ... 102
7.12.4 Write a configuration resource ... 105
7.12.5 Reset configuration ... 108
7.13 API methods for clearing data ... 110
7.13.1 General ... 110
7.13.2 Retrieve list of supported clear-data types ... 111
7.13.3 Start clearing of data ... 112
7.13.4 Retrieve status of clearing data ... 114
7.14 API methods for control of operations ... 116
7.14.1 General ... 116
7.14.2 Ensuring co-located diagnostics ... 116
7.14.3 Query for operations from an entity ... 116
7.14.4 Query for executions of an operation ... 118
7.14.5 Retrieve details of an operation ... 119
7.14.6 Start execution of an operation ... 122
7.14.7 Read the status of an operation execution ... 125
7.14.8 Terminate the execution of an operation ... 126
7.14.9 Support for execute / freeze / reset and custom capabilities ... 127
7.15 API methods for script execution ... 129
7.15.1 General ... 129
7.15.2 Upload a script ... 130
7.15.3 Query for scripts from an entity ... 132
7.15.4 Retrieve details of a script ... 133
7.15.5 Remove a script ... 135
7.15.6 Start execution of a script ... 136
7.15.7 Query for executions of a Script ... 139
7.15.8 Read the status of a script execution ... 140
7.15.9 Terminate the script execution ... 141
7.15.10 Remove the execution of a script ... 143
7.16 API methods for support of target modes ... 144
7.16.1 General ... 144
7.16.2 Query for modes of an entity ... 144
7.16.3 Retrieve details of a mode ... 146
7.16.4 Explicit control of entity states via their defined modes ... 147
7.16.5 Hint-based control of entity states via their defined modes ... 149
7.17 API methods for locking ... 149
7.17.1 General ... 149
7.17.2 Acquire a lock on an entity ... 152
7.17.3 Query for locks of an entity ... 154
7.17.4 Retrieve details of a lock ... 155
7.17.5 Modify the expiration time of a lock on an entity ... 156
7.17.6 Release an acquired lock on an entity ... 158
7.18 API methods for software update ... 159
7.18.1 General ... 159
7.18.2 Query for updates from an entity ... 161
7.18.3 Retrieve details of an update ... 163
7.18.4 Automated installation of an update ... 165
7.18.5 Prepare installation of an update ... 166
7.18.6 Execute installation of an update ... 168
7.18.7 Read the status of an update ... 170
7.18.8 Delete update package from an SOVD server ... 172
7.18.9 Register an update at the SOVD server ... 173

7.19 API methods for restarting an entity ... 174
7.19.1 General ... 174
7.19.2 Read the status of an entity ... 175
7.19.3 Start an entity ... 176
7.19.4 Restart an entity ... 178
7.19.5 Forced Restart an entity ... 179
7.19.6 Shutdown an entity ... 180
7.19.7 Forced Shutdown an entity ... 181
7.20 API methods for handling of bulk-data ... 183
7.20.1 General ... 183
7.20.2 Retrieve bulk-data categories of an entity ... 184
7.20.3 Retrieve details of bulk-data resource ... 186
7.20.4 Download and upload bulk-data ... 188
7.20.5 Delete bulk-data ... 192
7.21 API methods for logging ... 194
7.21.1 General ... 194
7.21.2 Retrieve resources of an SOVD log ... 195
7.21.3 Read log entries from an SOVD log ... 196
7.21.4 Configure SOVD log ... 199
7.21.5 Retrieve the current SOVD log configuration from an entity ... 200
7.21.6 Reset SOVD logging configuration to default ... 202
7.22 API methods for communication-logs ... 203
7.22.1 General ... 203
7.22.2 Query for communication-logs from an entity ... 203
7.22.3 Configure communication-logs for an entity ... 204
7.22.4 Read the status of a communication-log ... 206
7.22.5 Control a communication-log ... 207
7.22.6 Delete communication-log ... 208
7.23 Authentication of SOVD clients (informative) ... 210
7.23.1 Online and offline authentication and authorization ... 210
7.23.2 Securing connectionc ... 215
7.23.3 Verifying SOVD client credentials and requesting a token at the backend ... 215
7.23.4 Verifying SOVD client credentials ... 215
7.23.5 Requesting a token ... 216
7.23.6 Request header for access-restricted resources ... 217
7.23.7 Validating a token ... 218

8 Classic diagnostic adapter ... 218
8.1 General ... 218
8.2 Access to UDS based entities ... 218
8.3 Specific mapping of UDS services to SOVD modes ... 219
8.3.1 Mapping of DiagnosticSessionControl (10_{16}) subfunctions to SOVD modes ... 219
8.3.2 Mapping of SecurityAccess (27_{16}) subfunctions to SOVD modes ... 220
8.3.3 Mapping of Authentication (29_{16}) to SOVD modes ... 220
8.3.4 Mapping of CommunicationControl (28_{16}) subfunctions to SOVD modes ... 220
8.3.5 Mapping of ControlDTC Setting (85_{16}) subfunctions to SOVD modes ... 220
8.4 Mapping of UDS services to data resources ... 220
8.5 Mapping of UDS services to fault resources ... 221
8.6 Mapping of UDS services to operation resources ... 221
8.6.1 Mapping of Routine (31_{16}) and InputOutputControlByIdentifier ($2F_{16}$) services to operation resources ... 221
8.6.2 DEPRECATED — Mapping of EcuReset service (11_{16}) to operation resources ... 221
8.7 Mapping of EcuReset service (11_{16}) to restart an entity resource ... 221

Annex A (normative) **Access to legally required diagnostics ... 222**

Annex B (informative) **SOVD API common example ... 225**

Bibliography ... 235