ISO 15830-4:2005-12 (E)

Road vehicles - Design and performance specifications for the WorldSID 50th percentile male side impact dummy - Part 4: User's manual

Contents

Page

Foreword xi

Introduction xii

1 Scope 1

2 Normative references 1

3 Terms and definitions 1

4 Requirements 2
4.1 Disassembly and assembly 2
4.2 Full arm changeover 2

Annex A (normative) Procedures for disassembling and assembling the WorldSID 3

A.1 Head 3
A.1.1 Parts list for head 3
A.1.2 Disassembling 5
A.1.3 Assembling 6
A.1.4 Instrumentation mounting 7
A.2 Neck 8
A.2.1 Parts lists for neck 8
A.2.2 Disassembling 10
A.2.3 Assembling 12
A.2.4 Instrumentation mounting 14
A.3 Thorax, abdomen and shoulder 14
A.3.1 Parts list 14
A.3.2 Disassembling 20
A.3.3 Assembling 27
A.3.4 Instrumentation mounting 32
A.4 Full arm 35
A.4.1 Parts list 35
A.4.2 Disassembling 42
A.4.3 Assembling the arm 44
A.4.4 Adjusting the arm 46
A.4.5 Changing full arm from left to right side impact 49
A.5 Half arm 50
A.5.1 Parts list for half arm 50
A.5.2 Disassembling 51
A.5.3 Assembling 51
A.6 Pelvis 52
A.6.1 Parts list for pelvis 52
A.6.2 Disassembling 57
A.6.3 Assembling the pelvis 66
A.6.4 Instrumentation mounting 67
A.7 Full leg assembly 67
A.7.1 Parts list 67
A.7.2 Disassembling 74
A.7.3 Assembling the leg 76
A.7.4 Adjusting the leg 80

A.8 Suit assembly 82
A.8.1 Parts list for suit 82
A.8.2 Disassembly 82
A.8.3 Assembly 82

Annex B (informative) Overview of an example permissible internal data acquisition system 83

B.1 General 83
B.2 System components 83
B.2.1 G5 module 84
B.2.2 G5 docking station 84
B.2.3 G5-DB 84
B.2.4 Docking station to G5-DB cable 84
B.2.5 In-dummy battery and cable 86
B.2.6 G5-DB to battery and temperature sensor cable 86
B.2.7 G5-DB to dummy exit cable 86
B.2.8 Dummy exit to TDAS status box cable 86
B.2.9 TDAS status box 86
B.2.10 DC/DC converter 87
B.2.11 AC/DC converter 87
B.2.12 TDAS power supply 87
B.2.13 TDAS software 87
B.2.14 Status box to PC cable 87
B.2.15 Notebook PC 87
B.3 Dummy exit to status box cable pinout 88
B.4 Sensor cable length 89

Annex C (normative) Fastener torque values 91

Annex D (informative) Fastener abbreviations and ISO references for user convenience 92

Annex E (informative) Recommended WorldSID general practices 93

E.1 Certification test intervals 93
E.2 Recommended inspection practices 93
E.3 WorldSID thorax half width 94
E.4 Avoiding possible connector damage 94
E.5 Temperature range 94
E.6 Dummy handling 94
E.6.1 General 94
E.6.2 Procedures for using the lifting bracket are as follows 95
E.7 Dummy storage 95

Annex F (informative) Recommended WorldSID seating procedure 96

F.1 Placement procedures for the driver seat position 96
F.1.1 General 96
F.1.2 Electronic spreadsheets 96
F.2 Placement procedures for the rear seat position 96
F.2.1 ATD preparation 96
F.2.2 Position the seat 96
F.2.3 Dummy placement 96

Annex G (informative) Suggested WorldSID wiring procedures 98

G.1 Head wiring 98
G.2 Neck 98
G.3 Shoulder rib and 1st thorax rib 99
G.4 2nd and 3rd Thorax ribs and abdomen ribs 100
G.5 Pelvis cable routing 100
G.6 Installation of sensor connectors to the thorax connector station 101
G.7 Instrumented arm cable routing 107

G.7.1 General considerations 107
G.7.2 Lower arm cables 107
G.7.3 Upper arm cables 108
G.7.4 Elbow cables 108
G.7.5 Routing wires through flesh component 109
G.8 Instrumented leg cable routing 110
G.8.1 Lower leg cable routing 110
G.8.2 Knee cable routing 111
G.8.3 Femoral neck cable routing 112
G.9 Wiring with an external DAS 113

Annex H (informative) WorldSID temperature information 114

H.1 Temperature sensitivity of WorldSID 114
H.2 Monitoring of temperature variations of WorldSID 114
H.3 Effect of internal DAS on dummy temperature 115
H.4 Practical notes for full body testing related to temperature 115

Annex I (normative) Recommended WorldSID grounding scheme 116

I.1 Parts list 116
I.2 Grounding procedures 116

Figures Figure A.1 -- WorldSID head components 4

Figure A.2 -- Removal of moulded head 5

Figure A.3 -- Separating the head core from the neck 5

Figure A.4 -- Removing upper neck load cell from instrumented head core 6

Figure A.5 -- Wire routing for head instrumentation 7

Figure A.6 -- WorldSID head instrumentation 8

Figure A.7 -- WorldSID neck components 9

Figure A.8 -- Removing lower neck bracket 10

Figure A.9 -- Removing upper neck bracket 10

Figure A.10 -- Using clamp to remove neck interface plate 11

Figure A.11 -- Neck dampers are free to be removed when interface plates are removed 11

Figure A.12 -- Lateral positions for neck buffers 12

Figure A.13 -- Assembling of neck buffers 13

Figure A.14 -- Neck triaxial accelerometer installation 14

Figure A.15 -- Components of WorldSID thorax and abdomen 17

Figure A.16 -- Shoulder 18

Figure A.17 -- WorldSID spine box assembly 20

Figure A.18 -- Removing shoulder load cell assembly 21

Figure A.19 -- Detaching shoulder rib at front from sternum 22

Figure A.20 -- Detaching the rib from the spine box at the rear 22

Figure A.21 -- Battery assembly 24

Figure A.22 -- Internal spine box assembly 25

Figure A.23 -- Angular accelerometer assembling 26

Figure A.24 -- IR-TRACC ball joint assemblies are mounted to the struck-side plate of the spine box 27

Figure A.25 -- Shoulder rib is grey, the first thoracic rib is red, and the second and third thoracic ribs and abdominal ribs are white 28

Figure A.26 -- Components of thorax rib 29

Figure A.27 -- Wire routing for rib instrumentation 30

Figure A.28 -- Plugging rib instrumentation cables into the front of the G5 modules mounted in the spine box 30

Figure A.29 -- The rib and abdominal couplers are attached to the ribs after instrumentation is plugged in 31

Figure A.30 -- Installation of G5 modules 32

Figure A.31 -- WorldSID rib instrumentation 33

Figure A.32 -- G5 DAS module 34

Figure A.33 -- Interposer connector 34

Figure A.34 -- DAS connector 34

Figure A.35 -- Arrangement of DAS, interposer connector, and connector 35

Figure A.36 -- Full arm, exploded 37

Figure A.37 -- Shoulder-arm detail 38

Figure A.38 -- Upper arm, exploded 39

Figure A.39 -- Elbow section 40

Figure A.40 -- Lower arm, exploded 41

Figure A.41 -- Wrist 42

Figure A.42 -- 'Z' Pivot and upper arm tube 43

Figure A.43 -- Elbow potentiometer 45

Figure A.44 -- Elbow potentiometer wiring 45

Figure A.45 -- Arm joint rotation 46

Figure A.46 -- Arm joint tension points 47

Figure A.47 -- Elbow adjustment 48

Figure A.48 -- Elbow friction adjustment 49

Figure A.49 -- Change-over components 50

Figure A.50 -- Arm assembly 51
Figure A.51 -- WorldSID pelvis components 54
Figure A.52 -- Rear view of pelvis assembly 55
Figure A.53 -- Front view of pelvis assembly 55
Figure A.54 -- Close-up view of pubic assembly 56
Figure A.55 -- Close-up view of lumbar assembly 56
Figure A.56 -- Removing spine box from the pelvis 57
Figure A.57 -- Detaching the femur assemblies 58
Figure A.58 -- Pelvis flesh 59
Figure A.59 -- Removing sacroiliac backing plates to separate the pelvic bone-pubis assembly 59
Figure A.60 -- Separating moulded pelvis bone from pubis assembly 60
Figure A.61 -- Separating pubic buffers from pubic load cell structural replacement 60
Figure A.62 -- Detaching the lumbar spine 61
Figure A.63 -- Separating the upper lumbar clamping plate and lumbar mounting wedge from the lumbar spine 61
Figure A.64 -- Removing the lower lumbar mounting bracket weldment 62
Figure A.65 -- Removing the sacroiliac load cell interface 62
Figure A.66 -- Removing pelvis instrumentation cover plate 63
Figure A.67 -- Removing the pelvis instrumentation bracket 63
Figure A.68 -- Removing the DAS cover 64
Figure A.69 -- Removing the docking station 64
Figure A.70 -- Removing interposer mass replacement 65
Figure A.71 -- Separating the sacroiliac and lumbar spine load cell structural replacements 65
Figure A.72 -- Routing of wires for pelvis instrumentation 67
Figure A.73 -- Femoral neck 68
Figure A.74 -- Upper leg assembly 69
Figure A.75 -- Knee 70
Figure A.76 -- Lower leg tube assembly 71
Figure A.77 -- Foot and ankle 72
Figure A.78 -- Ankle assembly 73
Figure A.79 -- Ankle 75

Figure A.80 -- Knee assembling 76

Figure A.81 -- Knee potentiometer wiring 77

Figure A.82 -- Knee potentiometer installation 77

Figure A.83 -- Torquing the knee contact load cell 78

Figure A.84 -- Ankle potentiometer wiring 79

Figure A.85 -- 'X' and 'Y' version assembling 79

Figure A.86 -- Ankle assembly potentiometers 80

Figure A.87 -- Knee assembly 81

Figure A.88 -- Leg joint adjustments 81

Figure A.89 -- Ankle adjustment 82

Figure B.1 -- WorldSID G5 DAS system diagram 85

Figure B.2 -- Dummy exit to TDAS status box cable 2B 14-pin lemo connector wiring side view sockets 88

Figure B.3 -- Dummy exit to TDAS status box cable 2B 19-pin lemo connector, wiring side view, pins 89

Figure E.1 -- Lifting bracket assembly 95

Figure G.1 -- Cable routing for the head 98

Figure G.2 -- WorldSID neck cable routing 99

Figure G.3 -- IR-TRACC and linear accelerometer routing for shoulder and 1st thorax ribs 99

Figure G.4 -- Cable routing for IR-TRACC and linear triax accelerometers of the 2nd, 3rd thorax ribs and abdomen ribs 100

Figure G.5 -- Pelvis cable routing 101

Figure G.6 -- Installations of sensor connectors to the thorax connector station 101

Figure G.7 -- Cable routing for the thorax connector station 103

Figure G.8 -- Thorax cable routing 104

Figure G.9 -- Shoulder area final cable routing 104

Figure G.10 -- Pelvis cable and dummy exit cable routing 105

Figure G.11 -- Thorax cable routing 105

Figure G.12 -- DAS exit cable and tilt sensor cables 106

Figure G.13 -- Shoulder load cell cable rounting 106

Figure G.14 -- WorldSID final dummy wiring 107

Figure G.15 -- Lower arm cables 108

Figure G.16 -- Upper arm cables 108

Figure G.17 -- Cables in the elbow region 109

Figure G.18 -- Lower arm flesh 109

Figure G.19 -- Upper arm flesh 110

Figure G.20 -- Lower arm suit 110

Figure G.21 -- Lower leg cables 111

Figure G.22 -- Knee area cable routing 111

Figure G.23 -- Knee area cable routing 112

Figure G.24 -- Knee area cable routing and flesh 112

Figure G.25 -- Femoral neck cable routing 113

Figure H.1 -- Location of temperature sensors used for internal temperature survey 114

Figure I.1 -- Cable attachment to the upper neck load cell 116

Figure I.2 -- Spine box cable routing 117

Figure I.3 -- Spine box cable attachment 117

Figure I.4 -- Spine box cable attachment 118

Figure I.5 -- Lumbar cable attachment 118

Figure I.6 -- Pelvic load cell cable attachment 119

Figure I.7 -- Knee cable attachment 119

Figure I.8 -- Cable attachment 120

Figure I.9 -- Tibia cable attachment 120

Tables Table A.1 -- Parts list for WorldSID head 3

Table A.2 -- Parts list for WorldSID neck 8

Table A.3 -- Parts list for the WorldSID thorax, abdomen and shoulder 15

Table A.4 -- Parts list for shoulder assembly 18

Table A.5 -- Parts list for WorldSID spine box 19

Table A.6 -- Parts list for full arm 36

Table A.7 -- Parts list for shoulder-arm 37

Table A.8 -- Parts for upper arm 38

Table A.9 -- Parts list for elbow 39

Table A.10 -- Parts for lower arm 40

Table A.11 -- Parts list for wrist 41

Table A.12 -- Parts list for WorldSID 50

Table A.13 -- Parts list for WorldSID pelvis 52

Table A.14 -- Parts list for femoral neck (W50-51034) 68

Table A.15 -- Parts for upper leg 68

Table A.16 -- Parts list for knee 69

Table A.17 -- Parts list for lower leg tube 70

Table A.18 -- Parts list for ankle-foot 71

Table A.19 -- Parts list for ankle 72

Table B.1 -- WorldSID G5 DAS parts list 83

Table B.2 -- Dummy exit to status box cable pinout 88

Table B.3 -- Example instrumentation cable lengths 89

Table C.1 -- Screw torques 91

Table D.1 -- Summary of fasteners abbreviations, descriptions and ISO references 92

Table E.1 -- Parts list for lifting bracket assembly 94

Table H.1 -- Effect of internal and external DAS on WorldSID internal air temperature 115

Table I.1 -- List of ground cables 116